

LINKUSB232CONV

USB-serial adaptor



Installation guide



There are two different models of LINKUSB232CONV adaptors:

- A - Model with sockets
- B - Model with sockets and 1m cable

The drivers for the LINKUSB232CONV installation are available within the installation folder of SmartLeague software, specifically in the following folder:

c:\program_files\inim\smartleague\drivers\convertitore\setup

Do not plug the adaptor into the PC either before or during the installation of the adaptor, but only when the installation is complete.

ATTENTION!

The driver to use depends on the adaptor model:

- PL2303_Prolific_GPS_Allinone_xxx.exe - for the model with sockets (A)
- PL2303_Prolific_Driverinstaller_vxxx.exe - for the model with sockets and cable (B)

Below we provide the installation procedure, which is the same for the two different types of driver:

1. Locate the right driver of your adaptor model.
2. Double-click on the driver icon to start the installation.
3. Follow the wizard until the end.
4. Plug into the PC the adaptor that will be automatically associated with the driver and assigned to a serial port.

This instruction sheet is for informational purposes only and is by no means binding.

The company reserves the right to alter or change the information contained herein without prior notice.

INIM Electronics s.r.l.
via Fosso Antico, Centobuchi
63033, Monteprandone, (AP) Italy
Tel. +39 0735 70 50 07
Fax + 39 0735 70 49 12
www.inim.biz info@inim.biz