



























































Now you can see!

Model	Junction boxes	Installation
Dome  DI-VF	Wall A  PR-WB-A	IP66 IP64  PR-JB14IP66 PR-JB14IP64
	OR	Installation Wall B Ceiling Pole Corner  PR-WB14 PR-B10EX PR-CB14 PR-B10EX PR-B50PB PR-WB14 PR-B50ECB PR-WB14
Dome  DI-FIX	Wall A  PR-WB-A	IP66 IP64  PR-JB12IP66 PR-JB12IP64
	OR	Installation Wall B Ceiling Pole Corner  PR-WB12 PR-B10EX PR-CB12 PR-B10EX PR-B50PB PR-WB12 PR-B50ECB PR-WB12
Dome  DAI-VF	IP66 *  PR-JB14IP66	Installation Wall Ceiling Pole Corner Ceiling  PR-WB14 PR-B10EX PR-CB14 PR-B10EX PR-B50PB PR-WB14 PR-B50ECB PR-WB14 PR-ICB23
	+	OR
Dome  DAI-FIX	Wall A  PR-WB-A	IP66 *  PR-JB12IP66
	+	OR
	OR	Installation Wall Ceiling Pole Corner Ceiling  PR-WB12 PR-B10EX PR-CB12 PR-B10EX PR-B50PB PR-WB12 PR-B50ECB PR-WB12 PR-ICB21
	OR	OR
Dome  FEI	IP66  PR-B50JB	Installation Wall Ceiling  PR-WB50 PR-B10EX PR-CB50 PR-B10EX
	+	OR

*** For DAI Installations, please remove the junctions box cover and connect the camera directly to the junction box**

PROVISION ISR[®] Junction boxes

Now you can see!

Model	Junction boxes		Installation							
Bullet  I6	IP66  PR-JB14IP66	IP64  PR-JB14IP64	Wall   optional PR-WB14 PR-B10EX		Ceiling   optional PR-CB14 PR-B10EX		Pole   optional PR-B50PB PR-CB14		Corner   optional PR-B50ECB PR-CB14	
Bullet  I4	IP66  PR-JB12IP66	IP64  PR-JB12IP64	Wall   optional PR-WB12 PR-B10EX		Ceiling   optional PR-CB12 PR-B10EX		Pole   optional PR-B50PB PR-CB12		Corner   optional PR-B50ECB PR-CB12	
Bullet  I2	IP66  PR-JB12IP66	IP64  PR-JB12IP64	Wall   optional PR-WB12 PR-B10EX		Ceiling   optional PR-CB12 PR-B10EX		Pole   optional PR-B50PB PR-CB12		Corner   optional PR-B50ECB PR-CB12	
Dome  DMA	Wall A  PR-WB-A	OR  PR-B10BJB	Wall B   optional PR-WB12 PR-B10EX		Ceiling   optional PR-CB12 PR-B10EX					