




BOSCH

AVENAR detector 4000

FAP-425-O|FAP-425-O-R|FAP-425-OT|FAP-425-OT-R|

FAP-425-DO-R|FAP-425-DOT-R|FAP-425-DOTC-R|

FAP-425-DOTCO-R|FAH-425-T-R|FAD-425-O-R



Installation manual

български

česky

deutsch

english

español

français

hrvatski

magyar

italiano

nederlands

polski

português

русский

svenska

türkçe

繁體中文



www.boschsecurity.com/xc/en/weee/





www.boschsecurity.com




Graphics

FAP-425-O-R|FAP-425-OT-R|FAP-425-DO-R|


FAP-425-DOT-R|FAP-425-DOTC-R|

FAP-425-DOTCO-R|FAH-425-T-R|FAD-425-O-R



   A	LSN improved version	LSN classic
0 0 0	✓	-
001 ... 254	✓	-
CL 0 0	✓	✓
255 ... 299	-	-

FAP-425-O|FAP-425-OT



Bosch Sicherheitssysteme GmbH

Robert-Bosch-Ring 5

85630 Grasbrunn

Germany

www.boschsecurity.com

© Bosch Sicherheitssysteme GmbH, 2022

Building solutions for a better life.

202203291104