


DeepBase W / DeepBase R

Installation Manual

	DeepBase W	DeepBase R
	RAL 9016	RAL 3020
	ABS	-10°C ÷ +60°C (93±3)%@+40°C
	~32g	0.4-2.5 mm ²




- 1 50x32mm;
- 2 4xM20;
- 3 2x (according the mounting surface)
- 4 2x3.5/13 DIN7981C;

1 SF100; SensoIRIS BSxx (Mounting plane basis)

Compatible Products		
SF100 WSST	✓	
SF100 RSST		✓
SF100 RSND		✓
SensoIRIS BSOU	✓	
SensoIRIS BSOU IS	✓	
SensoIRIS BSST	✓	
SensoIRIS BSST IS	✓	

2

SensoMAG B24/B24D/B24RD; SensoMAG B12L/U (Fire bases for conventional detectors)




Compatible Products



SensoMAG F10	✓	
SensoMAG R20	✓	
SensoMAG S30	✓	
SensoMAG M40	✓	

3

SensoIRIS B124 (Fire base for addressable detectors and sounders)



Compatible Products



SensoIRIS T110	✓	
SensoIRIS T110 IS	✓	
SensoIRIS S130	✓	
SensoIRIS S130 IS	✓	
SensoIRIS M140	✓	
SensoIRIS M140 IS	✓	
SensoIRIS WSST	✓	✓
SensoIRIS WSST IS	✓	✓
SensoIRIS WSOU		✓
SensoIRIS WSOU IS		✓
SensoIRIS WS		✓
SensoIRIS WS IS		✓