Configuración de cámara IP Lenx

1. Inicialización
2. Preguntas de seguridad
3. Cambio de parámetros de red
4. Añadir y activar usuario ONVIF

IP POR DEFECTO 192.168.1.64
USAR SOLO INTERNET EXPLORER O COMPLEMENTO IETAB

Introducir una contraseña según los criterios



http://192.168.1.64/doc/page/login.asp?_1714118923972

Activation

User Name admin

Password ⓧ The item cannot be empty.

8 to 16 characters allowed, including upper-case letters, lower-case letters, digits and special characters (!\\\"#$%&'()*+,-./:;<=>?@[\\\\]^_`{|}~ space). At least two of above mentioned types are required.

Confirm ⓧ The item cannot be empty.

Preguntas de seguridad



admin

•••••••••••••

Security Question Configuration

Security Question1: Your father's name?

Answer:

Security Question2: Your mother's name?

Answer:

Security Question3: Your head teacher's name in senior high schoo

Answer:

Forgot password?
Login
OK
Cancel

LENX


Address: http://192.168.1.64/doc/page/preview.asp

LENX
Live View
Playback
Picture
Configuration
04-26-2024 Fri 16:10:29

AGUSTES PARAMETROS DE RED


LENX
Live View
Playback
Picture
Configuration
Local
System
Network
Basic Settings
Advanced Settings
Video/Audio
Image
Event
Storage
TCP/IP
DDNS
Port
NAT
Test
View Route Advertisement
Save

NIC Type: Auto

☐ DHCP

IPv4 Address: 192.168.15.64

IPv4 Subnet Mask: 255.255.255.0

IPv4 Default Gateway: 192.168.15.1

IPv6 Mode: Route Advertisement

IPv6 Address:

IPv6 Subnet Mask:

IPv6 Default Gateway: ::

Mac Address: 98:df:82:57:e4:d7

MTU: 1500

Multicast Address:

☑ Enable Multicast Discovery

DNS Server

Preferred DNS Server: 8.8.8.8

Alternate DNS Server:

Creación de usuario ONVIF


Live View
Playback
Picture
Configuration
Local
System
Network
Basic Settings
Advanced Settings
Video/Audio
Image
Event
Storage
FTP
Email
Platform Access
HTTPS
QoS
802.1x
Integration Protocol
Network Service
HTTP Listening
Add
Modify
Delete
Save

Address: http://192.168.15.64/doc/page/config.asp

☑ Enable ONVIF

ONVIF Version 18.12

User List

No.	User Name	Level
1	admin	Administrator


LENX
Live View
Playback
Picture
Configuration
admin
Logout
Local
System
Network
Basic Settings
Advanced Settings
Video/Audio
Image
Event
Storage
FTP
Email
Platform Access
HTTPS
QoS
802.1x
Integration Protocol
Network Service
HTTP Listening
Add
Modify
Delete
Save
OK
Cancel

☑ Enable ONVIF

ONVIF Version 16.12

User List

No	User Name	Level
1	admin	

Add user

User Name

Digits, lower-case letters, upper-case letters, and special characters (!#$%&'()*+,-./:;<=>?@[\\\]^_`{|}~ space) are allowed.

Password

8 to 16 characters allowed, including upper-case letters, lower-case letters, digits and special characters (!\\\"#$%&'()*+,-./:;<=>?@[\\\]^_`{|}~ space). At least two of above mentioned types are required.

Confirm

Level
● Media user
○ Operator
○ Administrator