



DSS Professional

User's Manual








Foreword

General











This user's manual introduces the functions and operations of DSS Professional (hereinafter referred to as "the system" or "the platform").

Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, reductions in performance, or unpredictable results.
 TIPS	Provides methods to help you solve a problem or save time.
 NOTE	Provides additional information as a supplement to the text.

Frequently Used Functions

Icon/Parameter	Description
	View the details of an item.
	Clear all selected options.
	Search for items by keywords or specified content.
 or Delete	Delete items one by one or in batches.
 or 	Edit an item.
 or  Enable , or Disable	Enable or disable items one by one or in batches.
 or Export	Exported the selected content to your local computer.
 or Refresh	Refresh the content.
*	A parameter that must be configured.

Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.
- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper user's manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Table of Contents

Foreword	I
1 Overview	1
1.1 Introduction	1
1.2 Highlights.....	1
2 Installation and Deployment	2
2.1 Standalone Deployment.....	5
2.1.1 Server Requirements	5
2.1.2 Installing DSS.....	5
2.1.3 Configuring Server IP Address	8
2.1.4 Managing System Services.....	8
2.1.5 Installing and Logging into DSS Client	10
2.1.5.1 Installing DSS Client	10
2.1.5.1.1 DSS Client Requirements	10
2.1.5.1.2 Downloading and Installing DSS Client.....	11
2.1.5.2 Logging in to DSS Client	11
2.1.5.3 Homepage of DSS Client.....	13
2.1.6 Licensing	14
2.1.6.1 Applying for a License	15
2.1.6.2 Activating License	15
2.1.6.2.1 Online Activation.....	15
2.1.6.2.2 Offline Activation	16
2.2 Distributed Deployment.....	18
2.2.1 Installing Main Server	18
2.2.2 Installing Sub Server	18
2.3 Hot Standby	20
2.4 Cascade	20
2.5 N+M.....	21
2.6 Configuring LAN or WAN	22
2.6.1 Configuring Router.....	22
2.6.2 Mapping IP or Domain Name	22
3 Basic Configurations	24
3.1 Managing Resources	24
3.1.1 Adding Organization	24
3.1.2 Managing Device.....	25
3.1.2.1 Searching for Online Devices.....	25

3.1.2.2 Initializing Devices	26
3.1.2.3 Changing Device IP Address	27
3.1.2.4 Adding Devices	27
3.1.2.4.1 Adding Devices One by One	27
3.1.2.4.2 Adding Devices through Searching	29
3.1.2.4.3 Importing Devices	30
3.1.2.5 Editing Devices	31
3.1.2.5.1 Changing IP Address	31
3.1.2.5.2 Modifying Device Information	31
3.1.2.5.3 Configuring Channel Features in Batches	33
3.1.2.5.4 Modifying Device Organization	33
3.1.2.5.5 Changing Device Password	34
3.1.2.6 Logging in to Device Webpage	34
3.1.2.7 Exporting Devices	35
3.1.2.8 Modifying Device Time Zone	36
3.1.3 Binding Resources	37
3.1.4 Adding Recording Plan	39
3.1.4.1 Adding Recording Plan One by One	40
3.1.4.2 Adding Center Recording Plans in Batches	41
3.1.4.2.1 General Recording Plan	42
3.1.4.2.2 Motion Detection Recording Plan	42
3.1.5 Adding Retrieval Plan One by One	44
3.1.6 Adding Retrieval Plans in Batches	45
3.1.7 Adding Retrieval Plan for MPT Devices	46
3.1.7.1 Adding One by One	48
3.1.7.2 Adding in Batches	48
3.1.8 Adding Time Template	50
3.1.9 Configuring Video Retention Period	50
3.1.10 Configuring Events	51
3.1.11 Configuring Device Parameters	52
3.1.11.1 Configuring Camera Properties	52
3.1.11.1.1 Configuring Property Files	52
3.1.11.1.2 Applying Configuration Files	58
3.1.11.2 Video	60
3.1.11.2.1 Video Stream	60
3.1.11.2.2 Snapshot Stream	63
3.1.11.2.3 Overlay	64

3.1.11.3 Audio	67
3.1.12 Synchronizing People Counting Rules	69
3.2 Adding Role and User	69
3.2.1 Adding User Role	70
3.2.2 Adding User	71
3.2.3 Importing Domain User	72
3.2.4 Syncing Domain User.....	73
3.2.5 Password Maintenance.....	74
3.2.5.1 Changing Password for the Current User	74
3.2.5.2 Changing Password for Other Users.....	75
3.2.5.3 Resetting User Password	75
3.3 Configuring Storage	76
3.3.1 Configuring Network Disk.....	76
3.3.2 Configuring Server Disk	78
3.3.3 Configuring Disk Group.....	79
3.3.4 Configuring Device Storage.....	79
3.4 Connecting to Multiple Sites.....	80
4 Businesses Configuration	82
4.1 Configuring Events	82
4.1.1 Configuring Event Linkage	82
4.1.2 Configuring Combined Events	85
4.1.3 Filtering Repetitive Alarms	86
4.2 Configuring Map	86
4.2.1 Preparations	86
4.2.2 Adding Map	86
4.2.2.1 Adding Vector Map	86
4.2.2.2 Adding Raster Map.....	88
4.2.3 Marking Devices	90
4.2.4 Configuring Radar-PTZ Linkage.....	90
4.2.4.1 Configuring Linkage.....	91
4.2.4.2 Configure a Radar Event	92
4.3 Personnel and Vehicle Management.....	92
4.3.1 Adding Person and Vehicle Groups.....	92
4.3.2 Configuring Personnel Information	93
4.3.2.1 Adding a Person	93
4.3.2.2 Importing Multiple Persons.....	99
4.3.2.3 Extracting Personnel Information	101

4.3.2.4 Issuing Cards in Batches	103
4.3.2.5 Editing Person Information	105
4.3.3 Vehicle Management	105
4.4 Watch List Configuration	107
4.4.1 Face Watch List	108
4.4.1.1 Creating Face Comparison Group	108
4.4.1.2 Adding Faces	109
4.4.1.3 Arming Faces	110
4.4.2 Vehicle Watch List	111
4.4.2.1 Creating Vehicle Arming Group	111
4.4.2.2 Adding Vehicles	112
4.4.2.3 Arming Vehicles	112
4.5 Access Control	113
4.5.1 Preparations	113
4.5.2 Configuring Door Groups	113
4.5.3 Configuring Access Permission Groups	114
4.5.4 Configuring Public Passwords	115
4.5.5 Configuring Advanced Functions	115
4.5.5.1 First Card Unlock	115
4.5.5.2 Multi-Card Unlock	117
4.5.5.3 Anti-passback	119
4.5.5.4 Multi-door Interlock	120
4.5.5.5 Remote Verification	122
4.5.6 Synchronizing Records	122
4.5.7 Configuring Time Templates	123
4.5.8 Configuring Holidays	124
4.5.9 Configuring Access Control Devices	125
4.5.10 Configuring Door Information	126
4.6 Video Intercom	128
4.6.1 Preparations	128
4.6.2 Call Management	128
4.6.2.1 Configuring Call Group	129
4.6.2.2 Adding Manager Group	129
4.6.2.3 Configuring Relation Group	130
4.6.3 Configuring Building/Unit and Call Mode	131
4.6.4 Configuring Room	132
4.6.5 Synchronizing Contacts	132

4.6.6 Setting Private Password	133
4.6.7 QR Codes	133
4.6.8 App User	134
4.7 Granting Lift Control Permissions in Batches	134
4.8 Attendance Management	135
4.8.1 Preparations	135
4.8.2 Configuring Attendance Terminal	136
4.8.3 Configuring Statistics Rule	137
4.8.4 Configuring Attendance Period	137
4.8.5 Configuring Holiday Plans	140
4.8.6 Configuring Attendance Shift	141
4.8.7 Shift Management	143
4.8.7.1 Personnel/Department Shift Arrangement	143
4.8.7.2 Temporary Shift	144
4.9 Visitor Management	145
4.9.1 Preparations	145
4.9.2 Configuring Visit Settings	145
4.10 Parking Lot	147
4.10.1 Preparations	147
4.10.2 Configuring Parking Lot	148
4.10.2.1 Basic Information	148
4.10.2.2 Reserved Parking Space	154
4.10.2.3 Parking Lot Layer	154
4.10.2.4 Event Parameter	155
4.10.2.5 Vehicle Finder	156
4.10.3 Managing Vehicle Group	157
4.11 Intelligent Analysis	158
4.11.1 People Counting Group	158
4.11.2 Scheduled Report	159
4.12 Synthesis	160
4.12.1 Synchronizing Events	160
4.12.2 Synchronizing Data	165
4.13 Maintenance Center	168
4.13.1 Configuring Video Storage Detection	168
4.13.2 Configuring Scheduled Report	169
5 Businesses Operation	171
5.1 Monitoring Center	171

5.1.1 Main Page	171
5.1.2 Video Monitoring	172
5.1.2.1 Viewing Live Video	172
5.1.2.2 View	183
5.1.2.2.1 Creating View	183
5.1.2.2.2 Viewing View	184
5.1.2.3 Favorites	185
5.1.2.3.1 Creating Favorites	185
5.1.2.3.2 Viewing Favorites	186
5.1.2.4 PTZ	186
5.1.2.4.1 Configuring Preset	186
5.1.2.4.2 Configuring Tour	187
5.1.2.4.3 Configuring Pattern	188
5.1.2.4.4 Configuring Scan	189
5.1.2.4.5 Enabling/Disabling Pan	190
5.1.2.4.6 Enabling/Disabling Wiper	190
5.1.2.4.7 Enabling/Disabling Light	190
5.1.2.4.8 Configuring Custom Command	191
5.1.2.4.9 PTZ Menu	191
5.1.2.5 Fisheye-PTZ Smart Track	193
5.1.2.5.1 Preparations	193
5.1.2.5.2 Configuring Fisheye-PTZ Smart Track	194
5.1.2.5.3 Applying Fisheye-PTZ Smart Track	195
5.1.3 Playback	196
5.1.3.1 Page Description	196
5.1.3.2 Playing Back Recordings	197
5.1.3.3 Locking Videos	200
5.1.3.4 Tagging Videos	202
5.1.3.5 Filtering Recording Type	203
5.1.3.6 Clipping Videos	204
5.1.3.7 Smart Search	206
5.1.4 Map Applications	208
5.1.5 Video Wall	211
5.1.5.1 Configuring Video Wall	211
5.1.5.1.1 Page Description	211
5.1.5.1.2 Preparations	213
5.1.5.1.3 Adding Video Wall	213

5.1.5.1.4 Configuring Video Wall Display Tasks.....	215
5.1.5.1.5 Configuring Video Wall Plans	215
5.1.5.2 Video Wall Applications	218
5.1.5.2.1 Instant Display.....	218
5.1.5.2.2 Video Wall Task Display.....	219
5.1.5.2.3 Video Wall Plan Display	220
5.2 Event Center.....	220
5.2.1 Real-time Alarms	221
5.2.2 History Alarms	223
5.2.3 Event Overview	223
5.2.4 Alarm Controller	225
5.3 DeepXplore	227
5.3.1 Searching for Records	227
5.3.2 Searching for People.....	229
5.3.3 Searching for Vehicles.....	231
5.3.4 Searching for POS Transaction.....	232
5.3.5 Adding Case Bank	234
5.3.6 Viewing Track of MPT Devices	237
5.4 Access Management	237
5.4.1 Access Control Application	237
5.4.1.1 Viewing Videos	237
5.4.1.2 Unlocking Door.....	239
5.4.1.3 Locking Door.....	240
5.4.1.4 Viewing Event Details	240
5.4.1.5 Viewing Access Control Records	241
5.4.1.5.1 Online Records.....	241
5.4.1.5.2 Offline Records	242
5.4.2 Lift Control Application	243
5.4.2.1 Viewing Videos	244
5.4.2.2 Global Control	244
5.4.2.3 Viewing Event Details	244
5.4.2.4 Viewing Lift Control Records	245
5.4.3 Video Intercom Application.....	246
5.4.3.1 Call Center	246
5.4.3.2 Releasing Messages	249
5.4.3.3 Video Intercom Records	250
5.4.4 Viewing Attendance Data.....	250

5.4.5 Visitor Application	251
5.4.5.1 Preparations	252
5.4.5.2 Visitor Appointment.....	252
5.4.5.3 Checking In.....	253
5.4.5.4 Checking Out	257
5.4.5.5 Searching for Visit Records.....	257
5.5 Parking Lot	257
5.5.1 Statistics Dashboard	257
5.5.2 Entrance and Exit Monitoring	259
5.5.3 Searching for Records	260
5.5.3.1 Searching for Entrance Records.....	260
5.5.3.2 Searching for Exit Records	261
5.5.3.3 Searching for Forced Exit Records	261
5.5.3.4 Searching for Parking Records	262
5.5.3.5 Searching for Capture Records	262
5.5.4 Visualized Parking Lot	263
5.5.5 Vehicle Location.....	264
5.6 Intelligent Analysis	265
5.6.1 People Counting	265
5.6.1.1 Real-time Count.....	265
5.6.1.2 Historical Count	266
5.6.2 Heat Maps.....	267
5.6.3 In-area People Counting	268
5.7 Maintenance Center	269
5.7.1 Viewing System Status.....	269
5.7.2 Updating Device Program	270
6 General Application	272
6.1 Target Detection	272
6.1.1 Typical Topology	272
6.1.2 Preparations	272
6.1.3 Live Target Detection	273
6.1.4 Searching for Metadata Snapshots	273
6.2 ANPR.....	274
6.2.1 Typical Topology	274
6.2.2 Preparations	274
6.2.3 Live ANPR.....	275
6.2.4 Searching for Vehicle Snapshot Records.....	275

6.3 Face Recognition	276
6.3.1 Typical Topology	276
6.3.2 Preparations	277
6.3.3 Arming Faces	277
6.3.4 Live Face Recognition	277
6.3.5 Searching for Face Snapshots	278
6.4 POS	278
6.4.1 Typical Topology	279
6.4.2 Preparations	279
6.4.3 Setting POS End Sign	279
6.4.4 POS Live View	280
6.4.5 Searching for POS Receipts	281
7 System Configurations	282
7.1 System Deployment	282
7.1.1 Distributed Deployment	282
7.1.2 Cascade Deployment	284
7.2 License Information	285
7.3 License	285
7.3.1 Activating License	286
7.3.2 Deactivating License	286
7.3.2.1 Online Deactivation	286
7.3.2.2 Offline Deactivation	287
7.4 System Parameters	287
7.4.1 Configuring Security Parameters	288
7.4.2 Configuring Retention Period of System Data	288
7.4.3 Time Synchronization	289
7.4.4 Configuring Email Server	290
7.4.5 Configure Device Access Parameters	291
7.4.6 Customizing POS End Sign	292
7.4.7 Remote Log	292
7.4.8 Configuring Active Directory	293
7.4.9 Configuring Independent Database	295
7.4.10 Configuring Push Notification and Certificate for App	296
7.5 Backup and Restore	297
7.5.1 System Backup	297
7.5.2 System Restore	298
8 Management	300

8.1 Managing Logs	300
8.1.1 Operation Log	300
8.1.2 Device Log	300
8.1.3 System Log	300
8.1.4 Service Log	300
8.2 Downloading Videos	301
8.3 Configuring Local Settings	302
8.3.1 Configuring General Settings	303
8.3.2 Configuring Video Settings	305
8.3.3 Configuring Video Wall Settings	307
8.3.4 Configuring Alarm Settings	308
8.3.5 Configure File Storage Settings	310
8.3.6 Viewing Shortcut Keys	311
8.4 Playing Local Videos	311
8.5 Quick Commands	313
Appendix 1 Service Module Introduction	315
Appendix 2 Cybersecurity Recommendations	317

1 Overview

1.1 Introduction

Dahua Security System (DSS) Professional is designed for centralized security management. It enhances hardware performance and provides centralized video monitoring, access control, video intercom, alarm controller, POS, radar and AI features, such as face recognition, automatic number plate recognition, and video metadata.

Whether you are a small business with a few cameras, or a global business spread across the globe with over 20,000 cameras, DSS Professional is the right solution for you. Even if your needs change in the future, you can easily scale, upgrade or add functionalities to DSS Professional so that your needs are met. Build your security management system on a solid foundation with DSS Professional.

1.2 Highlights

- **Scalable design, easy to grow**
With distributed deployment, you can easily expand the supported channels to 20,000 and central storage capacity to 4 PB. The multi-site function allows you to incorporate multiple DSS platforms into one, and conveniently show their information on one PC client. You can access live and recorded videos, real-time and historical events, and more.
- **AI-powered applications, proactive security**
DSS Professional integrates various AI capabilities that devices have, such as face recognition, automatic number plate recognition, and video metadata. You will be notified immediately when the target you are interested in appears, allowing you or security personnel to take necessary security measures.
- **Highly available technology, more stable**
With hot standby and N+M redundancy, DSS Professional ensures that your business will not be interrupted by failed servers.
- **Customized services, enhanced competitiveness**
We offer services for you to build DSS Professional into your own platform, allowing it to fully suit your needs and give you a competitive edge in the market.


2 Installation and Deployment

DSS platform supports standalone deployment, distributed deployment, hot standby, and N+M deployment, and LAN to WAN mapping.

Standalone Deployment

For projects with a small number of devices, only one DSS server is required.


Figure 2-1 Standalone deployment



Distributed Deployment

Suitable for medium to larger projects. Sub servers are used to share system load, so that more devices can be accessed. The sub servers register to the main server, and the main server centrally manages the sub servers.


Figure 2-2 Distributed deployment



Hot Standby

Used with systems that require high stability. The standby server takes over the system when the active server malfunctions (such as with power-off and network disconnection). You can switch back to the original active server after it recovers.


Figure 2-3 Hot standby



N+M

Each sub server has a standby server to maintain stability. When a sub server malfunctions, the system replaces it with an idle standby server. When the malfunctioning server normalizes, you can manually switch back to it. If you do not manually switch them, the system will automatically make the switch if the standby server malfunctions.

Figure 2-4 N+M



LAN to WAN Mapping

Perform port mapping when:

- The server of the platform and devices are on a local area network, and the DSS client is on the internet. To make sure that the DSS client can access the platform server, you need to map the platform IP to the Internet.
- The platform is on a local area network, and the devices are on the Internet. If you want to add devices to the platform through automatic registration, you need to map the IP address and ports of the platform to the Internet. For devices on the Internet, the platform can add them by their IP addresses and ports.



The DSS Server configuration system does not differentiate service LAN ports and WAN ports. Make sure that the WAN ports and LAN ports are the same.

2.1 Standalone Deployment

2.1.1 Server Requirements

Table 2-1 DSS Pro hardware requirements

Parameter	Hardware Requirement	Operating System
Recommended configuration	<ul style="list-style-type: none"> • CPU: Intel Xeon Silver 4214 2.2GHz • RAM: 16 GB • Network card: 4 × Ethernet port @ 1000 Mbps • Hard drive type: 7200 RPM Enterprise Class HDD 1 TB • DSS installation directory space: 500 GB 	<ul style="list-style-type: none"> • Win10-64 bit • Windows server 2008 • Windows server 2012 • Windows server 2016 • Windows server 2019
Minimum configuration	<ul style="list-style-type: none"> • CPU: Intel Xeon E-2224 3.4GHz/4core • RAM: 8 GB • Network card: 2 × Ethernet port @ 1000 Mbps • Hard drive type: 7200 RPM Enterprise Class HDD 1 TB • DSS installation directory space: 500 GB 	Win10-64 bit




- Face recognition images, videos, and files cannot be stored on the system disk and DSS installation disk. We recommend you store these files on network disks.
- For best performance, we recommend adding additional hard drives to store pictures.

2.1.2 Installing DSS

Prerequisites

- You have downloaded the DSS installer from the official website or received it from our sales or technical support.
- You have prepared a server that meets the hardware requirements mentioned in "2.1.1 Server Requirements", and the server IP address is configured.


Procedure

Step 1 Double-click the DSS installer .



The name of the installer includes version number and date, confirm before installation.

Figure 2-5 Install DSS server



Step 2 Click **Software License Agreement**, and then read the agreement,

Step 3 Select the check box to accept the agreement, and then click **Next**.

Figure 2-6 Select a server type



Step 4 Select **Main** from the server type, and then click **Next**.

Step 5 Click **Browse**, and then select the installation path.

If the **Install** button is gray, check whether your installation path and space required meet the requirements. The total space required is displayed on the page.



We do not recommend you install the DSS server on Disk C, because features such as face recognition require higher disk performance.

Step 6 Click **Install**.




The installation process takes about 4 to 8 minutes. Do not cut off the power or close the program.

Figure 2-7 Run the DSS server



Step 7 Click **Run** when the installation finishes.

Figure 2-8 Select the network mode and network card



Step 8 Select a network mode and the network card, and then click **Next Step**.



Dual NIC will be available if the server has two network cards. This is useful when you need to access devices on two different network segments.

Step 9 Enable or disable TLS1.0 as needed.



TLS 1.0 has known security vulnerabilities. We strongly recommend you disable it to avoid security risks. If it is disabled, the web page of DSS platform cannot be accessed through the browser. You need to enable TLS 1.1 and TLS 1.2 in the browser settings to gain access to the web page.

Step 10 Click **Finish**.



If the available RAM of the server is less than 4 GB, you can only use basic functions related to video. If it is less than 2.5 GB, you cannot use any function.

Related Operations

- To uninstall the platform, log in to the server, go to "..\DSS\DSS Server\Uninstall", double-click uninst.exe, and then follow the on-screen instructions to uninstall the program.
- To update the system, directly install the new program. The system supports in-place update. Follow the steps above to install the program.

2.1.3 Configuring Server IP Address

Change the server IP address as you planned. Make sure that the server IP can access the devices in your system. For details, see the manual of the server.



After changing the IP address of the server, you need to update it in the system services. See the following section.

2.1.4 Managing System Services

View service status, start or stop services, and change service ports.


On the server, double-click  .

Figure 2-9 Service management page










Table 2-2 Interface description

No.	Function	Description
1	Service Management	<ul style="list-style-type: none"> Click to restart all services. <p></p> <p>When starting the platform, if the available memory of the server does not reach 4 GB, only the basic video services can be enabled. If the server has less than 2.5 GB of available memory, no services are available.</p> <ul style="list-style-type: none"> Click to stop all services. Click to refresh services.
2	User's manual	User manual.
3	Language	Switch language.
4	Security Setting	<p>TLS 1.0 has known security vulnerabilities. We strongly recommend you disable it to avoid security risks. If it is disabled, the web page of DSS platform cannot be accessed through the browser. You need to enable TLS 1.1 and TLS 1.2 in the browser settings to gain access to the web page.</p> <ol style="list-style-type: none"> Open Internet Explorer. Click the Tools button at the upper-right corner, and then select Internet Options. Select the Advanced tab. Go to the Settings > Security, and then select Use TLS 1.1 and Use TLS 1.2. Click OK.

No.	Function	Description
5	Setting	Configure the IP address of the server and IP mapping. <ul style="list-style-type: none"> Set up an IP address for the server so that the platform can access the network and the devices in it. If the server has two network cards, you can select Dual NIC mode, configure two IP addresses, and then the platform will be able to connect to two networks and access the devices on each one. If the platform is in a local network and the devices are on the internet, or you need to access the platform that is in a local network from the Internet, you need to map the IP address of the platform to a WAN IP address or a domain name. For details, see "2.6.2 Mapping IP or Domain Name".
6	About	Software version information.
7	Minimize	Minimize the page.
8	Close	—
9	Service Status	<ul style="list-style-type: none">  Starting : Services are starting.  Unavailable : Service is running abnormally  Stopping : Services are stopping.  Running : Service is running normally  Stopped : Services have stopped.
10	Services	Displays each service and service status. Click  to modify service port number, and then the services will restart automatically after modification.
11	Download DSS Client	Go to client download page of the DSS client.

2.1.5 Installing and Logging into DSS Client

Install the DSS client before licensing it.

2.1.5.1 Installing DSS Client

You can visit the system through the DSS Client for remote monitoring.

2.1.5.1.1 DSS Client Requirements

To install DSS Client, prepare a computer in accordance with the following requirements.

Table 2-3 Hardware requirements


Parameters	Description
Recommended system requirements	<ul style="list-style-type: none"> • CPU: Intel Core i5, 64 bits 4 Core Processor • Memory: 8 GB and above • Graphics: NVIDIA® GeForce®GT 730 • Network Card: 1000 Mbps • HDD: Make sure that at least 200GB is reserved for the client.

2.1.5.1.2 Downloading and Installing DSS Client

Procedure

- Step 1 Go to <https://IP address of the platform> in the browser
- Step 2 Click **PC**, and then **Download**.
If you save the program, go to Step 3.
If you run the program, go to Step 4.

Figure 2-10 Download DSS Client



- Step 3 Double-click the DSS Client program.
- Step 4 Select the check box of **I have read and agree to the DSS agreement** and then click **Next**.
- Step 5 Select installation path.
- Step 6 Click **Install**.
System displays the installation progress. It takes about 5 minutes to complete.

2.1.5.2 Logging in to DSS Client

Procedure

- Step 1 Double-click  on the desktop.

Step 2 Select a language and user type.



If you want to log in using a domain user account, you must import domain users first. For details, see "3.2.3 Importing Domain User".


Step 3 Enter the IP address and port number of the platform.

On the drop-down list, platforms that are in the same network as your computer will be shown.



If you want to log in to the platform using its domain name, you must link its IP address to a domain name first. For details, see "2.6.2 Mapping IP or Domain Name".

Figure 2-11 Automatically discovered platform



Step 4 Click anywhere else on the page to start initializing the platform.

For first-time login, you will be automatically directed to the initialization process. If you are not logging in for the first time, enter the IP address, port number of the platform, username, and password, and then click **Login**.

1) The default user is system. Enter and confirm the password, and then click **Next**.

The password must consist of 8 to 32 non-blank characters and contain at least two types of characters: Uppercase, lowercase, number, and special character (excluding ' " ; : &).

2) Select your security questions and enter their answers, and then click **OK**.

The client will automatically log in to the platform by using the password you just set.

2.1.5.3 Homepage of DSS Client

Figure 2-12 Homepage












Table 2-4 Parameter description

No.	Name	Function
1	Tab	Displays the names of all tabs that are opened.

No.	Name	Function
2	System settings	<ul style="list-style-type: none"> ● : Enable or disable alarm audio. ● : Displays number of alarms. Click the icon to go to Event Center. ● Click  to view system messages, such as the information of a device was edited or deleted. The permissions of a user will determine what messages can be seen. For example, if user A does not have the permission of device A, then user A will not get the message when device A is deleted. ● Click  to connect to other platforms as sites to your current platform. You can view certain resources from the sites. For details, see "3.4 Connecting to Multiple Sites". ● : User information: Click the icon, and then you can log in to the web page by clicking system IP address, change password, lock client and log out. <ul style="list-style-type: none"> ◇ Click platform IP address to go to the Web page. ◇ Click Change Password to change user password. ◇ Click About to view version information. ◇ Click Sign Out to exit client. ● Click  to lock client.
3	Overview	<ul style="list-style-type: none"> ● The number of devices in total, offline and online. ● The number of total, processed and pending events. ● The client network, CPU and RAM usage.
4	Management	<ul style="list-style-type: none"> ● Download videos. ● Check local pictures and videos. ● Settings for video, snapshot, video wall, alarm, security and shortcut keys. ● View and manage logs. ● View user manual. ● Customize quick HTTP commands. For details, see "8.5 Quick Commands".
5	Applications	<ul style="list-style-type: none"> ● : Application options including monitoring center, access management, intelligent analysis and vehicle entrance control. ● : Configuration options.

2.1.6 Licensing

Activate the platform with a trial or paid license the first time you log in to it. Otherwise you cannot use it. You can upgrade your license for more features and increased capacity.

This section introduces license capacity, how to apply for a license, how to use the license to activate the platform, and how to renew your license.

2.1.6.1 Applying for a License

A license is used to confirm the features and number of channels you purchased. To get a formal license, contact our sales personnel. To apply for a trial license, visit our website and find DSS Professional, scroll to the bottom, click **Apply**, and then follow the instructions. You can only use a trial license on a server once.

2.1.6.2 Activating License



The following images of the page might slightly differ from the actual pages.

2.1.6.2.1 Online Activation

Prerequisites

- You have received your license. If not, see "2.1.6.1 Applying for a License".
A license is used to confirm the features and number of channels you purchased. To get a formal license, contact our sales personnel. To apply for a trial license, visit our website and find DSS Pro, and then follow the application instructions.
- The platform server can access the Internet.

Procedure




- Step 1** On the **Home** page, click , and then in **System Config**, select **License**.
- Step 2** Click **Online Activate License**.
- Step 3** Select an activation method. Select **Normal Active** to complete the process. If you upgraded the system from Express to DSS Pro, and DSS Express has a paid license, then select **Upgrade from Express** instead.

Figure 2-13 Select a method



- Step 4** Enter your new **Activation Code**.
- Enter the DSS Pro activation code that you received.

2. If you select **Upgrade from Express**, enter the original Express activation code or import the deactivation file.
 - Enter the original activation code: Select **Enter Activation Code**, and then enter the original activation code.
 - Import the deactivation file: Select **Import DSS Express Deactivation Code**, click , and then select the deactivation file.

Step 5 Click **Activate Now**.

Step 6 On the **License** page, view your license details.


2.1.6.2.2 Offline Activation

Prerequisites

You have received your license. If not, see "2.1.6.1 Applying for a License".

A license is used to confirm the features and number of channels you purchased. To get a formal license, contact our sales personnel. To apply for a trial license, visit our website and find DSS Pro, and then follow the application instructions.

Procedure


Step 1 On the **Home** page, click , and then in **System Config**, select **License**.

Step 2 Click **Offline Activate License**.

Step 3 Select an activation method. Select **Normal Active** to complete the process. If you upgraded the system from Express to DSS Pro, and Express has a paid license, then select **Upgrade from Express** instead.

Figure 2-14 Select a method

Step 4 Enter your new **Activation Code**.

1. Enter the DSS Pro activation code that you received.
2. If you select **Upgrade from Express**, enter the original Express activation code or import the deactivation file.
 - Enter the original activation code: Select **Enter Activation Code**, and then enter the original activation code.
 - Import the deactivation file: Select **Import DSS Express Deactivation Code**, click , and then select the deactivation file.


Step 5 Click **Export** to export the license request file.

Step 6 Generate license file.

- 1) Move the request file to a computer with Internet access.
- 2) On that computer, open the system email that contains your license, and then click the attached web page address or **Click to go to DSS License Management** to go to the license management page.
- 3) Click **Activate License**.
- 4) Click **Upload**, select the license request file, and then when you are prompted **uploaded successfully**, click **Activate**.

The success page is displayed, where a download prompt is displayed asking you to save the license activation file.

Figure 2-15 Upload license request file



- 5) On the success page, click **Save** to save the file, and then move the file back to the computer where you exported the license request file.
- 6) On the **Offline Activate License** page, click **Import**, and then follow the on-screen instructions to import the license activation file.

Step 7 On the **License** page, view your license details.

2.2 Distributed Deployment

2.2.1 Installing Main Server

For details about how to install the main server, see the previous chapter or section. After sub server are deployed, log in to the main server, and then you can view the status of the sub servers.

2.2.2 Installing Sub Server

This section introduces how to install sub servers and register them to the main server.

Prerequisites

- You have received the DSS installer from our sales or technical support.
- You have prepared a server that meets the requirements mentioned in "2.1.1 Server Requirements", and the server IP address is set.

Procedure

Step 1 Double-click the DSS installer .



The name of the installer includes version number and date. Please confirm before installation.

Step 2 Click **agreement**, read through the agreement, and then accept it.

Step 3 Select the agreement check box, and then click **Next**.

Step 4 Select **Sub** for server type, and then click **Next**.

Step 5 Click **Browse**, and then select the installation path.

If the **Install** button is gray, check whether your installation path and space meet the requirements. The total space required is displayed on the page.



We recommend you do not install the platform into drive C because features such as face recognition require higher disk performance.


Step 6 Click **Install**.



The installation process takes about 5 to 10 minutes. Do not cut off the power or close the program.

Step 7 Click **Run** when the installation finishes.

Figure 2-16 Select network mode and network card




Step 8 Select a network mode and the network card, and then click **Next Step**.



Dual NIC will be available if the server has two network cards. This is useful when you need to access devices on two different network segments.

Figure 2-17 Configure the information of the main server



Step 9 Configure the IP address and port of the main server.

Step 10 Click **Finish**.



After successfully installing a sub server, you need log in to the platform of main server to enable it so that it can work properly. For details, see "7.1.1 Distributed Deployment".

Related Operations

- To edit service ports, start or stop services, refresh services, view service status or more, see "2.1.4 Managing System Services".
- To uninstall the platform, go to **Control Panel > Programs and Features**, and then locate DSS Server. Double-click it, and then uninstall it according to the on-screen instructions.

2.3 Hot Standby

For detailed steps, see *DSSReplicatorPlus2.0 Configuration Guide V8.1.1.docx*. If you have any problems, contact technical support.

2.4 Cascade

Attach a DSS platform to another DSS platform, and then you can view videos of the child platform

from the parent platform. You can create up to 3 cascade levels.

Prerequisites


Make sure that all the platforms on the system were already installed.

Background Information

- You only need to configure the child DSS information on the parent DSS information.
- Express can only be a child platform.

Procedure

Step 1 Log in to the parent DSS client. On the **Home** page, click  > **System Deployment**.

Step 2 Click .

Step 3 Click **Add**, and then configure parameters.

- **Organization:** Select an organization for the added platform, so that the resources of the platform will be attached to the organization of the current platform.
- **IP Address, Port, Username and Password:** Enter corresponding information of the added platform.

Step 4 Click **OK**.

2.5 N+M

On the main server, enable the sub server, and then create the sub-standby relationship.


Prerequisites

See "2.1 Standalone Deployment" and "2.2 Distributed Deployment" to deploy the servers you need. The relevant servers have been well deployed.

Procedure

Step 1 Log in to the parent DSS client. On the **Home** page, click  > **System Deployment**.

Step 2 Click .

Step 3 Click  to enable the sub servers.

Step 4 Configure a standby server.

- 1) Click  of a sub server.
- 2) Select **Standby Server** for **Server Type**, and then click **OK**.

Step 5 Configure the sub-standby relationship in either of the following ways.





- Go to the **Server Configuration** page of the sub server to select a standby server.
 1. Click  of a sub server.
 2. On the **Select Standby Server(s)** section, select one or more standby servers.

Figure 2-18 Select a standby server



3. Click **OK**.
- Go to the **Server Configuration** page of the standby server to select a sub server.
 1. Click  of a standby server.
 2. On the **Select Sub Server(s)** section, select one or more sub servers. You can click  to adjust the priority.
 3. Click **OK**.

2.6 Configuring LAN or WAN

2.6.1 Configuring Router

For the list of the ports that need to be mapped, see "Appendix 1 Service Module Introduction".



Make sure that the WAN ports is consistent with LAN ports.

2.6.2 Mapping IP or Domain Name

If the platform is deployed in a local network, you can map the IP address of the server to a fixed WAN IP or a domain name, and then log in to the server using the WAN IP or domain name. The page might vary between the main server and the sub server. This section uses the main server page as an example.

Procedure




- Step 1** Log in to DSS server, and then double-click .
- Step 2** Click the  on the upper-right corner.

Figure 2-19 Setting



Step 3 Enter a fixed WAN IP address or a domain name in the **Mapping IP | Domain** box, and then click **OK**.



If you want to use a domain name, you need to make corresponding configurations on the domain name server.

Step 4 Click **OK**, and then the services will restart.

3 Basic Configurations

Configure basic settings of the system functions before using them, including system activation, organization and device management, user creation, storage and recording planning, and event rules configuration.

3.1 Managing Resources

Manage system resources such as devices, users, and storage space. You can add organizations and devices, configure recording plans and retrieval plans, bind resources, and more.

3.1.1 Adding Organization

Classify devices by logical organization for the ease of management. The default organization is **Root**. If the parent organization is not specified, newly added devices are attached to **Root**.

Procedure






- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Add an organization.
- 1) Select a parent organization.
 - 2) Click .

Figure 3-1 Add an organization




- 3) Enter the name of the organization, and then click **OK**.

Figure 3-2 Add an organization




You can also right-click the root organization, and then click **Create Organization** to add an organization.

Related Operations

- Change organization name
Right-click the organization, and then click **Rename**.
- Delete an organization
Organization with devices cannot be deleted.
Select the organization, click , or right-click an organization and select **Delete**.
- Change the organization of devices
Select one or more devices, and then click **Move To** to move them to another organization.





3.1.2 Managing Device

Add devices before you can use them for video monitoring. This section introduces how to add, initialize, and edit devices and how to change device IP address.

3.1.2.1 Searching for Online Devices

Search for devices on the same network with the platform before you can add them to the platform.


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Click .
- The icon changes to  when devices are searched.




- When using the platform for the first time, the platform automatically searches for devices on the same network segment.
- If not the first time, the platform automatically searches for the devices in the network segment you configured last time.

Figure 3-3 Search for devices



Step 4 Specify **IP Segment**, and then click **Search**.

Figure 3-4 IP segment search



3.1.2.2 Initializing Devices

You need to initialize the uninitialized devices before you can add them to the platform.

Procedure

Step 1 Search for devices. For details, see "3.1.2.1 Searching for Online Devices".

Step 2 Select an uninitialized device, and then click **Initialize**.



- You can select multiple devices to initialize them in batches. Make sure that the selected devices have the same username, password and email information. The information of these devices will be the same after initialization, such as password and email address.
- Click next to **Initialization Status** to quickly sort out devices in certain status.

Step 3 Enter the password, and then click **Password Security**.

Step 4 Enter the email address, and then click **Change IP**.



The email is used to receive security code for resetting password.

Step 5 Enter the IP address, and then click **OK**.

When setting IP addresses in batches, the IP addresses increase in an ascending order.

3.1.2.3 Changing Device IP Address

You can change IP addresses of the devices that have not been added to the platform.


Procedure

- Step 1** Search for devices. For details, see "3.1.2.1 Searching for Online Devices".
- Step 2** Select a device, and then click **Change IP**.



For devices that have the same username and password, you can select and modify their IP addresses in batches.

Figure 3-5 Change IP address



- Step 3** Enter **New IP**, **Subnet Mask** and **Gateway**, and then click **Save**.
When setting IP addresses in batches, the IP addresses increase in sequence.
- Step 4** Enter the username and password used to log in to the devices, and then click **OK**.

3.1.2.4 Adding Devices

You can add different types of devices, such as encoder, decoder, ANPR device, access control, emergency assistance device, alarm box, radar device, and video intercom. This section takes adding an encoder as an example. The configuration pages shown here might be different from the ones you see for other types of devices.



When you add devices by using automatic registration, IP segment, or importing, some devices will fail to be added if they exceed the number of devices or channels allowed to be added to the platform. These devices will be displayed in **Devices without License**.

3.1.2.4.1 Adding Devices One by One

There are multiple ways you can add devices to the platform, including using domain names, serial numbers, IP addresses, IP segments, and automatic registration.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Click **Add**.
- Step 4** Enter device login information, and then click **Add**.

In the **Add Mode** drop-down list,

- **IP Address:** Add a device. We recommend selecting this option when you know the IP address of the device.



Only **Encoder** devices support IPv6. If you want to add devices to the platform through IPv6 addresses, you must first configure an IPv6 address for the platform. Contact technical support for help.

- **IP segment:** Add multiple devices in the same segment. We recommend selecting this option when the login username and password of the multiple devices in the same segment are the same.
- **Domain Name:** We recommend selecting this option when the IP address of the device changes frequently and a domain name is configured for the device.
- **Auto Registration:** We recommend this method when the IP address of a device might change. The ID of auto register has to be in accordance with the registered ID configured on the device you want to add. The port number must be the same on the platform and on the device. The auto register port is 9500 on the platform by default. To change the auto register port number, open the configuration tool to change the port number of DSS_ARS service.



- ◇ After a device is added through auto registration, hover the mouse over its IP address on the device list, and then you can see its local IP address and the IP address it uses to connect to the platform.
 - ◇ Sleep function is supported for IPCs that use 4G mobile network to communicate and are solar-powered only when they are added to the platform through automatic registration.
- **P2P:** Add devices under a P2P account to the platform. The platform must be able to access the P2P server. There is no need to apply for the dynamic domain name of the device, perform port mapping or deploy a transit server when using it.



The parameters vary with the selected protocols.

Figure 3-6 Add an encoder

Step 5 Enter the information.

Step 6 Click **OK**.

- To add more devices, click **Continue to add**.
- To go to the web manager of a device, click

3.1.2.4.2 Adding Devices through Searching

Devices on the same network with the platform server can be added using the automatic search function.

Procedure

Step 1 Search for devices. For details, see "3.1.2.1 Searching for Online Devices".

Step 2 Select a device, and then click **Add to Device List** or



If devices have the same username and password, you can select and add them in batches.

Figure 3-7 Add in batches

Initialization status	IP Address	Device Model	Port	MAC Address	Operation
Initialized	192.168.1.101	DH-SD6CR2F-GN	3777	08:00:27:00:00:00	[Icon]
Initialized	192.168.1.102	DH-SD59230T-HN	3777	08:00:27:00:00:00	[Icon]
Initialized	192.168.1.103	FSU	3777	08:00:27:00:00:00	[Icon]

Step 3 Select the server and organization, enter username and password, and then click **OK**.


3.1.2.4.3 Importing Devices

Enter the device information in the template, and then you can add devices in batches.

Prerequisites

You have downloaded the template, and then enter device information in the template.


Figure 3-8 Download template



Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Click **Import**.

Figure 3-9 Import devices



Step 4 Click **Import File**, and then select the completed template.

Step 5 Click **OK**.


3.1.2.5 Editing Devices

Edit the information of devices.

3.1.2.5.1 Changing IP Address

For the devices that have been added to the platform, and their IP addresses have been changed, you can edit their IP addresses directly on the platform so that they can connect to the platform normally.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.


Step 2 Click **Device Config**.

Step 3 Click  of a device.

Step 4 Edit the IP address, and then click **OK**.

3.1.2.5.2 Modifying Device Information

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.

Step 2 Click .



Step 3 Click  of a device, and then edit device information. Click **Get Info** and the system will synchronize device information.

Figure 3-10 Basic information



Step 4 Click **Video Channel**, and then configure the channel information, such as the channel name and channel features.



- The features that you can set for channels vary with the types of devices.
- If the device is added through the ONVIF protocol, you can configure the stream type of its video channels.

Step 5 Click the **Alarm Input Channel** tab, and then configure number, names, and alarm types of the alarm input channels.



Skip the step when the device does not support alarm input.

- Alarm type includes external alarm, Infrared detect, zone disarm, PIR, gas sensor, smoke sensor, glass sensor, emergency button, stolen alarm, perimeter and preventer move.
- Alarm type supports custom. Select **Customize Alarm Type** in the **Alarm Type** drop-down list. Click **Add** to add new alarm type. It supports up to 30 custom alarm types.

Step 6 Click the **Alarm Output Channel** tab and then edit the number and names of alarm output channels.

Step 7 Click the **POS Channel**, and then edit the number and names of the POS channels.



This tab will only appear if the device has POS channels.

Step 8 Click the **Audio and Light Channel** tab, and then edit the number and names of the audio and light channels.



This tab will only appear if the device has audio and light channels.

Step 9 Click **OK**.

3.1.2.5.3 Configuring Channel Features in Batches

Configure the channel features in batches so that devices can work normally.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** On the top of the page, select **More > Capability Set Management**.
- Step 3** In the **Capability Set Type** drop-down list, select a type, and then the platform will only display devices and channels that are configured with that type of capability set.
- Step 4** Select the channels you want to configure.
- Step 5** Click the area below the **Features** column, and then select one or more features.

Figure 3-11 Select capability sets



- Step 6** Complete configuration.
 - If configuration is complete, click **Complete** to save the settings and exit the page.
 - If you want to configure more channels, click **Save** to save your current settings, and then continue your configuration. When it is complete, click **Complete** to save the settings and exit the page.

3.1.2.5.4 Modifying Device Organization

You can move a device from an organization node to another one.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Select a device to be moved, click **Move To**, select the target organization, and then click **OK**.

Figure 3-12 Move a device





3.1.2.5.5 Changing Device Password

Background Information

You can change device usernames and passwords in batches.


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Select a device, and then click **Change Password**.




You can select multiple devices and change their passwords at the same time.

Figure 3-13 Change device password



- Step 4** Enter the old and new passwords, and then click **OK**.


3.1.2.6 Logging in to Device Webpage

After a device is added to the platform, you can click  to go to the webpage of the device.


The platform supports accessing the webpage of a device through the HTTPS protocol. If you want

to use this function, you must complete the following steps. For details procedures on the device webpage, see the user's manual of the device.

1. Log in to the webpage of the device, and then download the trusted CA root certificate.
2. Double-click the certificate, and then click **Install Certificate**.
3. Select **Current User**, and then click **Next**.



4. Store the certificate to **Trusted Root Certification Authorities**, and then click **Next**.



5. Click **Finish**.
6. On the webpage of the device, create a device certificate, and then apply it.



If the IP address or domain name of the device is in the address bar, you must enter the IP address or domain name of the device in the certificate. If it is the IP address or domain name of the platform, you must enter the IP address or domain name of the platform in the certificate.

3.1.2.7 Exporting Devices

You can export the information (except username and password for login) of all the devices on the DSS client. When you need to switch or configure a new platform, you can quickly add them all by

importing them, but you need to enter the username and password for login again.



You can export up to 100,000 devices at a time.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** (Optional) Select only the devices that you need.

Figure 3-14 Select a device type



IP Address	Device Name	Device Type	Organization	Online Status	Offline Reason	Operation
		IVSS	face	Offline	Network Exception.	
		IPC	root	Offline		
		IVSS	root	Online		
		NVR	root	Online		
		DVR	root	Offline		
		DVR	root	Offline	Network Exception.	
		IPC	root	Online		
		IPC	pyf	Online		

- Step 4** Click **Export**.
- Step 5** Enter the password used to log in to the DSS client, encryption password, and range, and then click **OK**.



You can configure whether to verify the password. For details, see "7.4.1 Configuring Security Parameters".

- The encryption password is used to protect the export file. It consists of 6 uppercase or lower case letters, numbers, or their combination. You need to enter it when using the export file.
- You can select **All** to export all the devices, or **Selected** to export the devices you selected.

- Step 6** Select a path on your PC, and then click **Save**.

3.1.2.8 Modifying Device Time Zone

Background Information

Configure device time zone correctly. Otherwise you might fail to search for recorded video.



If a device is accessed through ONVIF and the ONVIF version is earlier than 18.12, the device DST cannot be edited on the platform. You can only edit manually.

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config**

section, select **Device**.

Step 2 Click .

Step 3 Select a device, and then click **Time Zone Settings**.

Figure 3-15 Modify device time zone



Step 4 Select a time zone.

Step 5 Click **OK**.

3.1.3 Binding Resources

The platform supports binding resources for linked actions. You can link a video channel with an alarm input channel, ANPR channel, POS channel, access control channel, lift control channel or another video channel, so that you can view the associated video for alarm, face and other businesses.


Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.

Step 2 Click .

Step 3 Select a channel, and then click **Modify**.

Figure 3-16 Bind channel




Step 4 Select a channel, and then click **OK**.



Multiple channels can be selected.

Figure 3-17 Select the channels you want to bind to the camera



Step 5 Click **OK**.

3.1.4 Adding Recording Plan

Background Information

Configure recording plans for video channels so that they can record videos accordingly. You can configure 2 types of recording plans for a channel. One is general recording plan, and a device will continuously record videos during the defined period. The other is motion detection recording plan, and a device will only continuously record videos when motion is detected.

3.1.4.1 Adding Recording Plan One by One

Add a center recording plan or device recording plan for a channel, so that it can make general or motion detection videos within the defined period.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Select a channel, and then configure a recording plan.
- Configure a center recording plan.
 - 1) Click **Add Recording Plan** next to **Center Recording Plan**.

Figure 3-18 Add a center recording plan (1)



- 2) Configure the parameters, and then click **OK**.

Table 3-1 Parameter description

Parameter	Description
Enable	Turn on or off the recording plan.
Position	Videos will be stored on the server by default. It cannot be changed.
Recording Type	<ul style="list-style-type: none"> • General recording: The device will continuously record videos within the defined periods. • Motion detection recording: The device will continuously record videos within the defined periods on motion detections.
Stream Type	Select Main Stream , Sub Stream 1 or Sub Stream 2 . Videos recorded on the main stream will have the best quality, but they require more storage.
Remarks	Customizable description for the recording plan.
Recording Time	Select a default time template or click Create Time Template to add a new time template. See "3.1.8 Adding Time Template".


- 3) Click **OK**.
 - Configure a device recording plan.



The platform can obtain and display the recording plan that has been configured on EVS of the latest versions. You can check if recording plan are obtained and displayed on the page to know if your EVS is of the latest version.

- 1) Click **Add Recording Plan** next to **Device Recording Plan**.

Figure 3-19 Add a device recording plan (1)



- 2) Configure the parameters, and then click **OK**.

Table 3-2 Parameter description

Parameter	Description
Enable	Turn on or off the recording plan.
Position	Videos will be stored on the device by default. It cannot be changed.
Stream Type	The device will make recordings using the main stream by default. It cannot be changed.
Remarks	Customizable description for the recording plan.
Recording Time	Select a default time template or click Create Time Template to add a new time template. See "3.1.8 Adding Time Template".

Related Operations

- Enable/disable a recording plan
 means that the plan has been enabled. Click the icon and it becomes , and it means that the plan has been disabled.
- Click : Copy the recording plan to other channels.
- Edit a recording plan
 Click of corresponding plan to edit the plan.
- Click to delete recording plans one by one.

3.1.4.2 Adding Center Recording Plans in Batches

Add a center recording plan of general or motion detection videos for multiple channels at the same

time.

3.1.4.2.1 General Recording Plan

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Storage Plan > Recording Plan**.

Figure 3-20 Center recording plan



- Step 2** Select **General Recording Plan > Add General Recording Plan**.

- Step 3** Configure the parameters, and then click **OK**.

Table 3-3 Parameter description

Parameter	Description
Enable	Turn on or off the recording plan.
Position	Videos will be stored on the server by default. It cannot be changed.
Stream Type	Select Main Stream , Sub Stream 1 or Sub Stream 2 . Videos recorded on the main stream will have the best quality, but they require more storage.
Remarks	Customizable description for the recording plan.
Recording Time	Select a default time template or click Create Time Template to add a new time template. See "3.1.8 Adding Time Template".
Recording Channel	Select the channels you want to add the recording plan for.

3.1.4.2.2 Motion Detection Recording Plan

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Storage Plan > Recording Plan**.

Figure 3-21 Center recording plan



Step 2 Select **Motion Detection Recording Plan** > **Add Motion Detection Recording Plan**.

Step 3 Configure the parameters, and then click **OK**.

Table 3-4 Parameter description

Parameter	Description
Enable	Turn on or off the recording plan.
Position	Videos will be stored on the server by default. It cannot be changed.
Recording Type	<ul style="list-style-type: none"> General recording: The device will continuously record videos within the defined periods. Motion detection recording: The device will continuously record videos within the defined periods on motion detections.
Stream Type	Select Main Stream , Sub Stream 1 or Sub Stream 2 . Videos recorded on the main stream will have the best quality, but they requires more storage.
Remarks	Customizable description for the recording plan.
Recording Time	Select a default time template or click Create Time Template to add a new time template. See "3.1.8 Adding Time Template".
Recording Channel	Select the channels you want to add the recording plan for.

Related Operations

- Enable/disable a recording plan
 means that the plan has been enabled. Click the icon and it becomes , and it means that the plan has been disabled.
- Edit a recording plan
 Click of corresponding plan to edit the plan.
- Edit a recording plan
 Click of corresponding plan to edit the plan.
- Delete**: Select multiple channels, and then delete them at the same time.
- Enable** and **Disable**: Select multiple channels, and then enable or disable them at the same time.

3.1.5 Adding Retrieval Plan One by One

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .

Figure 3-22 Add a retrieval plan for a channel



- Step 3** Select a device and then click **Add Retrieval Plan**.

Figure 3-23 Add a retrieval plan



- Step 4** Configure the parameters.

Table 3-5 Parameter description

Parameter	Description
Enable	Turn on or off the retrieval plan.
Backup Storage for Retrieval	Select a period, and then the videos within the defined period will be uploaded. The platform supports uploading videos from devices within the past 7 days at most. Videos from the current day will not be included.

Parameter	Description
Stream Type	Select the stream type of the videos that you want up upload. If the videos are recorded on sub stream 1 and Main Stream is configured in this retrieval plan, uploading will fail.
Schedule	Configure when to upload videos every day. Click to configure specific periods. You can configure up to 6 periods.

Step 5 Click **OK**.

Related Operations


- Enable/disable retrieval plan means that the plan has been enabled. Click the icon and it becomes , and it means that the plan has been disabled.
- Edit retrieval plan Click of corresponding plan to edit the plan.
- Click to delete recording plans one by one.

3.1.6 Adding Retrieval Plans in Batches

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Storage Plan > Recording Retrieval > Video Retrieval**.

Figure 3-24 Video retrieval



Step 2 Click **Add Video Retrieval Plan**.

Figure 3-25 Configure a video retrieval plan



Step 3 Configure the parameters, and then select channels in the **Retrieval Channel** section.

Table 3-6 Parameter description

Parameter	Description
Enable	Turn on or off the retrieval plan.
Backup Storage for Retrieval	Select a period, and then the videos within the defined period will be uploaded. The platform supports uploading videos from devices within the past 7 days at most. Videos from the current day will not be included.
Stream Type	Select the stream type of the videos that you want up upload. If the videos are recorded on sub stream 1 and Main Stream is configured in this retrieval plan, uploading will fail.
Schedule	Configure when to upload videos every day. Click to configure specific periods. You can configure up to 6 periods.


Step 4 Click **OK**.

3.1.7 Adding Retrieval Plan for MPT Devices

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Storage Plan > Recording Retrieval > File Retrieval**.

Figure 3-26 File retrieval



Step 2 Click **Add File Retrieval Plan**.

Figure 3-27 Configure a file retrieval plan



Step 3 Configure the parameters, and then select MPT devices in the **Retrieval Device** section.

Table 3-7 Parameter description

Parameter	Description
Enable	Turn on or off the retrieval plan.

Parameter	Description
Backup Storage for Retrieval	Select a period, and then the videos within the defined period will be uploaded. The platform supports uploading videos from devices within the past 7 days at most. Videos from the current day will also be uploaded.
Execute retrieval plan only when Wi-Fi is connected	When selected, videos on MPT devices will be uploaded only when they are connected to a Wi-Fi network. If it is not selected and MPT devices are connected to the mobile network, uploading videos might result in additional charges.
Time to Execute Plan	Configure when to upload videos every day. Click to configure specific periods. You can configure up to 6 periods.

Step 4 Click **OK**.

Related Operations

3.1.7.1 Adding One by One

Background Information


The procedures are the same as other devices. For details, see "3.1.5 Adding Retrieval Plan One by One".

3.1.7.2 Adding in Batches

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Storage Plan > Recording Retrieval > File Retrieval**.

Figure 3-28 File retrieval






Step 2 Click **Add File Retrieval Plan**.

Figure 3-29 Configure a file retrieval plan



Step 3 Configure the parameters, and then select MPT devices in the **Retrieval Device** section.

Table 3-8 Parameter description

Parameter	Description
Enable	Turn on or off the retrieval plan.
Backup Storage for Retrieval	Select a period, and then the videos within the defined period will be uploaded. The platform supports uploading videos from devices within the past 7 days at most.  Videos from the current day will also be uploaded.
Execute retrieval plan only when Wi-Fi is connected	When selected, videos on MPT devices will be uploaded only when they are connected to a Wi-Fi network.  If it is not selected and MPT devices are connected to the mobile network, uploading videos might result in additional charges.
Time to Execute Plan	Configure when to upload videos every day. Click  to configure specific periods. You can configure up to 6 periods.

Step 4 Click **OK**.

Related Operations

3.1.8 Adding Time Template

Procedure






- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Select a channel, and then add a recording plan.
- Step 4** In the **Recording Time** drop-down list, select **Create Time Template**.
Creating time template in other pages is the same. This chapter takes creating time template in **Record Plan** page as an example.

Figure 3-30 Create time template




- Step 5** Configure name and periods. You can set up to 6 periods in one day.
Select the **Copy From** check box, and then you can select a template to copy from.
- On the time bar, click and drag to draw the periods. You can also click , and then draw the periods for multiple days.
 - You can also click  to configure periods.
- Step 6** Click **OK**.

3.1.9 Configuring Video Retention Period


For videos stored on the platform, you can configure video retention period. When the storage space runs out, new recorded videos will cover the oldest videos automatically.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device** > **Device Config**.

Step 2 Select a camera, and then click **Modify**.

Figure 3-31 Go to recording storage configuration page



Step 3 Click to enable the storing of different type of video, and then configure the retention period.

Step 4 Click **OK**.

Related Operations

Enable/disable record plan

In the operation column, means that the recording storage configuration has been enabled. Click the icon and it becomes , meaning that the configuration has been disabled.

3.1.10 Configuring Events

You need to set up the event configuration on a device or its channels to receive alarms on the platform.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.

Step 2 Click .

Step 3 Select a channel or a device, and then click **Event Config**.

Events that can be configured are different for different types of devices. If you select **Device**, you can only configure general events. If you select **Channels**, various events supported by different types of channels will be displayed.

Figure 3-32 Go to the event configuration (device)





Figure 3-33 Go to the event configuration (channel)



Step 4 Configure events. For details, see "4.1 Configuring Events".

3.1.11 Configuring Device Parameters

Configure the camera properties, video stream, snapshot, video overlay, and audio configuration for the device channel on the platform. The platform only supports configuring the channels added via IP in Dahua protocols.



Device configuration might vary depending on the capacities of the devices. The pages in the section are for reference only, and might differ from the actual ones.

3.1.11.1 Configuring Camera Properties

Configure camera image parameters for the **Daytime**, **Night**, and **Regular** modes to ensure high image quality.

3.1.11.1.1 Configuring Property Files

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device** > **Device Config**.
- Step 2** Select a device, and then click **Parameter Setting**.

Figure 3-34 Device configuration







Step 3 Select **Camera > Camera > Camera Properties**.



- To go to the device web page, you can click **Link to Device Webpage**.
- A PTZ control panel will be displayed if the device has PTZ function.

Table 3-9 PTZ operation

Icon/Function	Description
Arrow keys	Click it and the camera will rotate to the corresponding direction.
	Adjust the speed. The higher the value, the faster the camera rotates.
	Zoom in and out.
	Adjust the focus level.
	Adjust the aperture.

Step 4 In the **Profile Management** drop-down list, select a mode.

The parameters you configured will be applied to the mode.

Step 5 Click **Image**, and then configure the parameters.

Table 3-10 Parameter description

Parameter	Description
Style	You can set the image style to be Standard , Soft , or Vivid .
Brightness	You can adjust the overall image brightness through linear tuning. The higher the value, the brighter the image and vice versa. If this value is set too high, images tend to look blurred.

Parameter	Description
Contrast	Adjusts the contrast of the images. The higher the value, the bigger the contrast between the bright and dark portions of an image and vice versa. If the contrast value is set too high, the dark portions of an image might become too dark, and the bright portions might be over-exposed. If the contrast value is set too low, images tend to look blurry.
Saturation	Adjusts color shade. The higher the value, the deeper the color and vice versa. The saturation value does not affect the overall brightness of the images.
Sharpness	Adjusts the edge sharpness of images. The higher the value, the sharper the image edges. Setting this value too high might result in noises in images.
Gamma	Changes image brightness by non-linear tuning to expand the dynamic display range of images. The higher the value, the brighter the image and vice versa.


Step 6 Click **Exposure**, and then configure the parameters.



If the device that supports real wide dynamic (WDR) has enabled WDR, long exposure is not available.

Table 3-11 Parameter description


Parameter	Description
Anti-flicker	<ul style="list-style-type: none"> • 50Hz and 60Hz: With the 50/60 Hz household power supply, exposure can be automatically adjusted based on the brightness of the scene to ensure that no horizontal stripe appears on the image. • Outdoor: In an outdoor scenario, you can switch the exposure modes to achieve your target effect.

Parameter	Description
Mode	<p>The following options are available for different exposure modes of the camera:</p> <ul style="list-style-type: none"> • Auto: Auto tuning of the image brightness based on the actual environment. • Gain Priority: Within the normal exposure range, the device adjusts itself automatically first in the preset range of gains as per the brightness of the scenes. If the image has not achieved the target brightness when the gains hit the upper limit or lower limit, the device adjusts the shutter automatically to achieve the best brightness. The gain priority mode also allows for adjusting the gains by setting up a gain range. • Shutter Priority: Within the normal exposure range, the device adjusts itself automatically first in the preset range of shutter values as per the brightness of the scenes. If the image has not achieved the target brightness when the shutter value hits the upper limit or lower limit, the device adjusts the gains automatically to achieve the best brightness. • Aperture Priority: The aperture is fixed at a preset value before the device adjusts the shutter value automatically. If the image has not achieved the target brightness when the shutter value hits the upper limit or lower limit, the device adjusts the gains automatically to achieve the best brightness. • Manual: You can set up the gains and shutter values manually to adjust image brightness. <p></p> <ul style="list-style-type: none"> • If the Anti-flicker is set to Outdoor, you can set the Mode to Gain Priority or Shutter Priority. • Different devices have different exposure modes. The actual pages might be different.
3D NR	Reduces the noises of multiple-frame (at least two frames) images by using inter-frame information between two adjacent frames in a video.
Grade	When 3D NR is On , you can set up this parameter. The higher the grade, the better the noise reduction effect.

Step 7 Click **Backlight**, and then configure the parameters.

- Turning on **Backlight Correction** avoids silhouettes of relatively dark portions in pictures taken in a backlight environment.
- Turning on **Wide Dynamic** inhibits too bright portions and makes too dark portions brighter, presenting a clear picture overall.
- Turning on **Glare Inhibition** partially weakens strong light. This feature is useful in a toll gate, and the exit and entrance of a parking lot. Under extreme lighting conditions such as deep darkness, this feature can help capture the details of the faces and license plates.

Table 3-12 Parameter description

Backlight Mode	Description
Backlight Correction	<ul style="list-style-type: none"> When selecting the Default mode, the system adjusts exposure automatically to adapt to the environment and make the images taken in the darkest regions clear. When selecting the Custom mode and setting up a custom region, the system exposes the selected custom region to give the images taken in this region proper brightness.
HLC	Glare inhibition. The system inhibits the brightness in bright regions and reduces the size of the halo, to make the entire image less bright.
Wide Dynamic	To adapt to the environmental lighting conditions, the system reduces the brightness in bright regions and increases the brightness in dark regions. This ensures clear display of objects in both bright and dark regions.  The camera might lose seconds of video recordings when switching from a non-wide dynamic mode to wide dynamic.
SSA	The system adjusts image brightness automatically based on the environmental lighting conditions to show image details clearly.

Step 8 Click **WB**, and then configure the parameters.

The WB feature can be used to display colors more accurately. For example, white objects will appear consistently white in various lighting conditions.




Table 3-13 Parameter description

WB Mode	Description
Auto	The system automatically corrects different color temperatures to ensure normal display of image colors.
Natural Light	The system automatically corrects the scenes without manmade lighting to ensure normal display of image colors.
Street Lamp	The system automatically corrects the outdoor scenes at night to ensure normal display of image colors.
Outdoor	The system automatically corrects most outdoor scenes with natural lighting and artificial lighting to ensure normal display of image colors.
Manual	You can set up the red gains and blue gains manually for the system to correct different color temperatures in the environment accordingly.
Regional Custom	You can set up custom regions and the system corrects different color temperatures to ensure normal display of image colors.

Step 9 Click **Day/Night**, and then configure the parameters.

You can set up the display mode of images. The system can switch between the **Colored** mode and the **Black&White** mode to adapt to the environment.

Table 3-14 Parameter description

Parameter	Description
Mode	 <p>The Day/Night settings are independent of the Config Files settings.</p> <ul style="list-style-type: none"> • Colored: The camera displays colored images. • Auto: The camera automatically selects to display colored or black&white images based on the environmental brightness. • Black&White: The camera displays black&white images.
Sensitivity	<p>Defines the sensitivity of the camera in switching between the Colored mode and the Black&White mode.</p>  <p>You can set up this parameter when the Day & Night mode is set to Auto.</p>
Delayed recording	<p>Defines the delay of the camera in switching between the Colored mode and the Black&White mode. The lower the delay, the faster the switch between the Colored mode and the Black&White mode.</p>  <p>You can set up this parameter when the Day & Night mode is set to Auto.</p>

Step 10 Click **Defog**, and then configure the parameters.

Image quality drops when the camera is placed in the foggy or hazy environment. You can turn on **Defog** to make the images clearer.

Table 3-15 Defog parameters

Defog Mode	Description
Manual	You can set up the defog intensity and the atmospheric light intensity manually. The system adjusts the image quality as per such settings. The atmospheric light intensity mode can be set to Auto or Manual for light intensity adjustment.
Auto	The system adjusts the image quality automatically to adapt to the surrounding conditions.
Off	Defog disabled.

Step 11 Click **IR Light**, and then configure the parameters.

Table 3-16 Parameter description

IR Light Mode	Description
Manual	You can set up the IR light brightness manually. The system provides light for images as per the preset IR light brightness.
SmartIR	The system adjusts the brightness of the light to adapt to the surrounding conditions.

IR Light Mode	Description
Zoom Priority	The system adjusts the illuminator according to the lighting condition. <ul style="list-style-type: none"> When the environment turns dark, the low beam will be used first. If the low beam is not enough, the high beam will be used. When the environment turns bright, the high beam will be adjusted or turned off first. If it is still too bright, the low beam will be adjusted or turned off. When the focal length is adjusted to a wide angle value, the high beam will not be used to avoid overexposure on the objects near the camera, but you can manually adjust the brightness of the low beam by reducing or increasing the light compensation value.
Off	IR light disabled.


Step 12 Click **Apply**.

Repeat the steps above if you want to set up the configuration files for other modes.

3.1.11.1.2 Applying Configuration Files

Apply the image parameters as configured in the pre-defined periods.


Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.

Step 2 Click .

Step 3 Select a device, and then click **Device Config**.


Figure 3-35 Device configuration



Step 4 Click **Profile Management**, and set configuration files.


- When the mode is set to **Regular**, the system monitors the objects as per regular configurations.

Figure 3-36 Set configuration files as regular




- When the mode is set to **Full Time**, you can set **Always Enable** to **Daytime** or **Night**. The system monitors the objects as per the **Always Enable** configurations.

Figure 3-37 Set configuration files as full time



- When the mode is set to **Shift by time**, you can drag the slider to set a period of time as daytime or night. For example, you can set 8:00–18:00 as daytime, 0:00–8:00 and 18:00–24:00 as night. The system monitors the objects in different time periods as per corresponding configurations.

Figure 3-38 Set configuration files as shift by time



Step 5 Click **OK** to save the configurations.

3.1.11.2 Video

Set video parameters such as video stream, snapshot stream, overlay, ROI and saving path.


3.1.11.2.1 Video Stream

Set the video stream parameters such as stream type, encoding mode, resolution, frame rate, stream control, stream, I frame interval, SVC, and watermark.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Select a device, and then click **Device Config**.


Figure 3-39 Device configuration



Step 4 Select **Camera > Video > Video Stream**.

Step 5 Set **Video Stream**.



Figure 3-40 Configure video stream settings



The default values of streams are for reference only, and the actual pages might be different.

Table 3-17 Video stream parameters

Parameter	Description
Video Settings	Enable or disable Sub Stream parameters.

Parameter	Description
Encoding Mode	<ul style="list-style-type: none"> • H.264: H.264B (Baseline Profile), H.264 (Main Profile), H.264H (High Profile). Bandwidth consumption level at the same image quality: H.264B > H.264 > H.264H. • H.265: Main Profile encoding, consuming less bandwidth than H.264 at the same image quality. • MJPEG: Frame-by-frame compression, requiring large bandwidth and high video stream to ensure clear image. To achieve better video image, it is recommended that you select the largest stream value from the given options. • SVAC (Surveillance Video and Audio Coding): It is a standard for security surveillance applications in China.
Smart Codec	Turning on Smart Codec will compress the images to save storage space.  When smart code is on, the device does not support sub stream 2, ROI, IVS event detection.
Resolution	The resolution of the videos. Different devices might have different max resolutions.
FPS	The number of frames per second in a video. The higher the FPS, the more distinct and smooth the images.
Bit Rate Control	The following video stream control modes are available: <ul style="list-style-type: none"> • BRC_CBR: The bit stream changes slightly around the preset value. • BRC_VBR: The bit stream changes according to the monitored scenes.  When the Encode Mode is set to MJPEG , BRC_CBR remains the only option for stream control.
Image Quality	This parameter can be set only when Stream Ctrl is set to BRC_VBR. Video image quality is divided into six grades: Best, Better, Good, Bad, Worse and Worst.
Stream	This parameter can be set only when Stream Ctrl is set to BRC_CBR . You can select the proper stream value from the drop-down box based on actual scenarios.
Reference Stream	The system will recommend an optimal range of stream values to users based on the resolution and FPS set up by them.
I Frame Interval	Refers to the number of P frames between two I frames. The range of I Interval changes with FPS. It is recommended to set the I Interval to be two times as the FPS value.
SVC	FPS is subject to layered encoding. SVC is a scalable video encoding method on time domain.

Parameter	Description
Watermark	Turn on Watermark to enable this feature. You can verify the watermark characters to check whether the video has been tempered or not. Characters for watermark verification. The default value is DigitalCCTV.

Step 6 Click **Apply**.

3.1.11.2.2 Snapshot Stream

Set snapshot parameters, including snapshot type, picture size, picture quality, and snapshot speed.


Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.

Step 2 Click .


Step 3 Select a device, and then click **Device Config**.

Figure 3-41 Device configuration



Step 4 On the **Device Config** page, select **Camera** > **Video** > **Snapshot Stream**.

Figure 3-42 Configure snapshot stream settings



Step 5 Set **Snapshot Stream**.

Table 3-18 Snapshot stream parameters

Parameter	Description
Snapshot Type	It includes General and Trigger . <ul style="list-style-type: none"> • Regular refers to capturing pictures within the time range set up in a time table. • Trigger refers to capturing pictures when video detection, audio detection, IVS events, or alarms are triggered, provided that video detection, audio detection, and corresponding snapshot functions are enabled.
Image Size	Same as the resolution in Main Stream .
Image Quality	Sets up image quality. It is divided into six grades: Best, better, good, bad, worse and worst.
Snapshot Interval	Sets up the frequency of snapshots. Select Custom to manually set up the frequency of snapshots.
Link to Device Webpage	Go to the web page of the device.

Step 6 Click **OK**.

3.1.11.2.3 Overlay

Set video overlay parameters, including tampering, privacy mask, channel title, period title,

geographic position, OSD, font, and picture overlay.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Select a device, and then click **Device Config**.

Figure 3-43 Device configuration



- Step 4** On the **Device Config** page, select **Camera** > **Video** > **Overlay**.
- Step 5** Set privacy mask.

Figure 3-44 Overlay







- 1) Click the **Privacy Mask** tab.
 - 2) Click  to enable the function.
 - 3) Click  to adjust the size and position of the area frame. You can add 4 area frames at most.
- Step 6** (Optional) Set the channel name to display on the video.
- 1) Click the **Channel Name** tab.

Figure 3-45 Set channel name





- 2) Click  to enable the function.
- 3) Adjust the size and position of the name frame.

Step 7 (Optional) Set the period title to display on the video.

- 1) Click the **Period Title** tab.

Figure 3-46 Set period title




- 2) Click  to enable the function.
- 3) (Optional) Select **Week Display** so that the week information displays in video images.
- 4) Adjust the size and position of the frame.

Step 8 OSD overlay.

- 1) Enable **Geographic Position**, and then enter the geographic information of the camera.
- 2) Select a text alignment method.

Figure 3-47 OSD overlay



Step 9 Click **OK**.


3.1.11.3 Audio

Set audio parameters such as encoding mode, sampling frequency, audio input type, and noise filtering.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click and then in the **Basic Config** section, select **Device**.
- Step 2 Click .
- Step 3 Select a device, and then click **Device Config**.

Figure 3-48 Device configuration



- Step 4 On the **Device Config** page, select **Camera > Audio**.
- Step 5 Set parameters.

Figure 3-49 Configure audio settings






Table 3-19 Audio parameters

Parameter	Description
Audio Settings	Audio settings can be enabled when video has been enabled. After disabling Audio Settings in Main Stream or Sub Stream sections, the network transmits a mixed flow of videos and audios. Otherwise, the transmitted flow only contains video images.
Encoding Mode	The encoding modes of audios include G.711A, G.711Mu, AAC, PCM, and G.726. The preset audio encode mode applies to audio talks.
Sampling Frequency	Available audio sampling frequencies include 8K, 16K, 32K, 48K, and 64K.
Audio Input Type	The following types of audios connected to devices are available: <ul style="list-style-type: none"> • LineIn: The device must connect to external audio devices. • Mic: The device does not need external audio devices.
Noise Filtering	After enabling noise filtering, the system automatically filters out the noises in the environment.
Microphone Volume	Adjusts the microphone volume.  Only some devices support adjusting microphone volume.
Speaker volume	Adjusts the speaker volume.  Only some devices support adjusting speaker volume.

Step 6 Click **Apply**.

3.1.12 Synchronizing People Counting Rules

If you create, edit or delete people counting rules on a device, you have to manually synchronize them to the platform.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Click .
- Step 3** Select a channel, and then click **Sync People Counting Rules**.

Figure 3-50 Synchronize people counting rules from the device



- Step 4** Click **Sync Rules**, and then the system prompts **Synchronization Complete**.

Figure 3-51 Synchronize people counting rules from the device



3.2 Adding Role and User

Users of different roles have different menus and permissions of device access and operation. When creating a user, assign a role to it to give the corresponding permissions.

3.2.1 Adding User Role

A role is a set of permission. Classify users of the platform into different roles so that they can have different permissions for operating the devices, functions and other system resources.

Background Information

- Super administrator: A default rule that has the highest priority and all the permissions. This role cannot be modified. A super administrator can create administrator roles and common roles. The system supports 3 super administrators at most.
- Administrator: A default rule that cannot be modified and has no permission of configuring cascade, authorization, backup and restoring. An administrator can create other administrators.
- Common role: A common role that has no permission of configuring cascade, authorization, backup and restoring, user management, and device management.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **User**.
- Step 2** Click .
- Step 3** Click **Add**, set role information, and then select device and control permissions and assign the rule to users.

Figure 3-52 Add a role



- If a device is not selected under **Device Permissions** or a menu not selected under **Menu Permissions**, all users assigned with this role will not be able to see the device or menu.
- Click  of a selected organization. All permissions of subsequently added devices under this organization will also be assigned to users of this role.

- Step 4** Click **OK**.

3.2.2 Adding User

Create a user account for logging in to the platform.

Procedure







- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **User**.
- Step 2** Click .
- Step 3** Click **Add**, and then configure the user information.

Table 3-20 Parameter description

Parameter	Description
Username	Used to log in to the client.
Multi-client Login	Allow the user to log in to multiple clients at the same time.
Password	Used to log in to the client.
Confirm Password	
MPT User	Enable and enter a name, and then this user will be set as an MPT user. This is used in the group talk function in the map. For details, see "5.1.4 Map Applications".  If you enable this function, you cannot enable Multi-client Login .
Enable Forced Password Change at First Login	The user is required to change the password at first-time login.
Enable Password Change Interval	Force the user to change the password regularly.
Enable Password Expiry Time	The password must be changed after it expires on the defined date.
PTZ Control Permissions	The PTZ control priority of the user. The larger the value, the higher the priority. For example, User A has a priority of 2 and User B has a priority of 3. When they operate on the same PTZ camera, which is locked, at the same time, the PTZ camera will only respond to the operations from User B.
Email Address	Used to reset password and receive alarm emails.
Bind MAC Address	Limit the user to log in from specific computers. One user can be bound to 5 MAC addresses at most.
Role	Select one or more roles to assign the user permissions, such as which devices are allowed to be operated.

- Step 4** Click **OK**.

Related Operations

- Click  to lock user. The locked user cannot log in to the DSS Client and App.
- Click  to modify information of a user except the username.
- Click  to delete a user.

3.2.3 Importing Domain User

You can import domain users from the domain system of your current organization to create platform users.

Procedure

Step 1 Configuring domain information





- 1) Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameters**.
- 2) Click **Active Directory** and configure domain information.
- 3) Enable active directory to set domain information.  indicates active directory is enabled.
 - Click  to enter the password.
 - After setting domain information, click **Get DN** and it will acquire basic DN information automatically.
 - After getting DN information, click **Test** to test if domain information is available.

Figure 3-53 Set active directory




The screenshot shows the 'Active Directory' configuration page. At the top, there is a toggle switch for 'Active Directory' which is turned on. Below this, there are several sections:

- SSL Private Key:** A toggle switch that is currently turned off.
- Domain Name:** A text input field containing 'xxxx.xxxx.com'.
- IP Address:** A text input field containing '127.0.0.1'.
- Port:** A text input field containing '389'.
- Username:** A text input field containing 'xxxx'.
- Password:** A password input field with a pencil icon for editing.
- Base DN:** A text input field containing 'DC=xxx,DC=xxx'.


At the bottom of the form, there are three buttons: 'Get DN', 'Test', and 'Save'.

- 4) Click **Save**.

Step 2 Import domain users.

- 1) Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config**

section, select **User**.

2) Click  tab, and then click **Import Domain Users**.

3) Select the users to be imported, and then click **Next**.

You can also search for a user by entering keywords in the search box.

4) Select the roles, and then click **OK**.

Related Operations

To log in using a domain user account, start the DSS Client, and then select **Domain User** for user type.

3.2.4 Syncing Domain User

Background Information

When there are users that have expired, you can use sync domain user to delete the expired users.

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **User**.

Step 2 Click .

Step 3 Click **Sync Domain Users**.

Step 4 Select the users to be deleted, and then click **Delete**.

Figure 3-54 Sync domain user



3.2.5 Password Maintenance

The platform supports modifying user password, and resetting system user password when it is forgotten. Only the system user can reset password. Other users, when their passwords are forgotten, can ask the system user to modify the passwords.

3.2.5.1 Changing Password for the Current User

We recommend changing your password regularly for account safety.

Procedure



- Step 1** Log in to the DSS Client, click  at the upper-right corner, and then select **Change Password**.

Figure 3-55 Change password



Step 2 Enter the old password, new password, and then confirm the new password. Click **OK**.

3.2.5.2 Changing Password for Other Users

Background Information

The system user can change the password for other users without the need to verify the old password.

Procedure




- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **User**.
- Step 2 Click .
- Step 3 Select a user, and then click .
- Step 4 Enable **Change Password**, enter the new password and confirm password, and then click **OK**.

Figure 3-56 Change user info

3.2.5.3 Resetting User Password

You can reset the password of a user by security questions or email address, but only the system account supports resetting the password by security questions.

Procedure

- Step 1 On the login page, click **Forgot password?**.

- Step 2** Enter the account that you want to reset the password for, and then click **Next Step**.
- Step 3** Select how you want to reset the password.
- By security questions. This is only applicable to the system account.
 1. Click **Reset Password through Security Questions**.
 2. Answer the questions, and then click **Next Step**.
 - By email address. This is applicable to all accounts, but an email address must be configured first. For details, see "3.2.2 Adding User".
 1. Click **Reset Password through Email Verification**.
 2. Click **Send Verification Code**.
 3. Enter the verification code that you received from the email address, and then click **Next Step**.
- Step 4** Set a new password and confirm it, and then click **Next Step**.
The password has been reset.

3.3 Configuring Storage

Manage the storage of the platform, including adding network disks, setting storage types to store different types of files, creating disk groups to store files from specified channels, and setting the storage location and retention period of the images and recorded videos from devices.

3.3.1 Configuring Network Disk

Background Information

- The storage server is required to be deployed.
- One user volume of the current network disk can only be used by one server at the same time.
- User volume must be formatted when adding network disk. Check if you have backed up the data.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Storage**.
- Step 2** Select .
- Step 3** Click **Add**.
- Step 4** Select server name and mode, enter the IP address of network disk, and click **OK**.
- Normal mode: All volumes of the network disk will be added. Those used by any user will be in red.
 - User mode: Enter the username and password of a user. Only volumes of the network disk assigned to this user will be added.

Figure 3-57 Add network disk (normal mode)

Figure 3-58 Add network disk (user mode)

- Step 5** Select disk, and then click to format the corresponding disk.
1. Select user volume, and then click .
 2. Select format disk type, and then click **OK**.
- **Video:** Stores videos.
 - **Image and File:** Stores video files from MPT devices, and all types of images.

Figure 3-59 Format disk

Related Operations

- To configure disk type, click .
- To format a disk, click .



Formatting will clear all data on the disk. Please be advised.


3.3.2 Configuring Server Disk


Configure local disk to store different types of files, including videos, ANPR snapshots, incident files, and face or alarm snapshots. In addition to the local disks, you can also connect an external disk to the platform server, but you have to format the external disk before using it.



- To set up local storage, you need a physical disk with only one volume or any volume of one physical disk. Back up the data of the disk or volume before setting its disk type, which will format and erase all data from it.
- One physical disk with only one volume or any volume of one physical disk can only store one type of files. If you need to store more than one type of files, you need more than one physical disks or volumes, but it cannot be the one where you installed the operating system of the server or the DSS server. See "2.1.2 Installing DSS".

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Storage**.

Step 2 Select .

Step 3 Format a disk to set a storage type



This operation will clear all data on the disk. Please be advised.

1) Select user volume, and then click .

1) Select storage type, and then click **OK**.

- **Video:** Stores videos.
- **Images and Files:** Stores video files from MPT devices, and all types of images.
- **Incident File:** Stores videos and images in the case bank. This disk cannot be overwritten.



If you do not set up one or more disk types, you will not be able to properly use corresponding functions. For example, if you do not set up an **Image and File** disk, you will not see images in all alarms.

Step 4 Manage local disks.

- Initialize disk
Click .
- To configure disk type: Click .
- To format a disk: Select a disk or user volume, click .

3.3.3 Configuring Disk Group

Allocate disk groups for video storage.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Storage**.
- Step 2** Click .
- Step 3** Click **Add Disk Group**, enter disk group name, and then select a server and disks.

Figure 3-60 Configure disk group



1. Set disk group

When configuring a disk group, the disk capacity of the disks in the same group must be close to each other to allow storage data to be written in load balancing mode.

Disk Group Name:

Server:

Select Disks		Selected (0)	
Disk Name	Capacity (GB)	Disk Name	Operation
<input type="checkbox"/> lzl-vedio	39.22/44.00		

- Step 4** Click **Next Step**.
- Step 5** Select devices or channels on the left.
- Step 6** Click **OK**.

3.3.4 Configuring Device Storage

When there are a large number of devices on the platform, it will put too much pressure on the network disks or local disks because they might produce a lot of images and videos that need to be stored. The platform supports setting the storage location and retention period of the images and videos for storage devices, such as an IVSS, to reduce the pressure on the server.

Background Information

The types of images include face captures, video metadata, and events.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Storage > Device Storage Config**.
Only organizations with storage devices are displayed.
- Step 2** Select an organization, click  of a device on the right.
- Step 3** Configure the parameters, and then click **OK**.

Table 3-21 Parameter description

Parameter	Description
Event Image Storage Location	<ul style="list-style-type: none"> • Save to Central Storage: All images produced by the channels connected to this device will be stored on the network disks or local disks of the platform. • Link to Images on Device: All images produced by the channels connected to this device will be stored on the device itself. The platform will obtain images from the device.
Event Video Storage Location	<ul style="list-style-type: none"> • Save to Central Storage: All alarm videos produced by the channels connected to this device will be stored on the network disks or local disks of the platform. • Link to Videos on Device: All alarm videos produced by the channels connected to this device will be stored on the device itself. The platform will obtain videos from the device.  <p>To make sure that alarms videos are complete, we recommend you set a 24-hour recording plan for the device. Otherwise, the platform might not be able to obtain videos. For example, a recording plan of 00:00–14:00 has been configured on the device so that the channels connected to it will record videos during that period. If an alarm is triggered on 14:01, the platform will not be able to obtain videos for this alarm.</p>
Retention Time of Images and Videos on Device	<p>This function is applicable to the images and videos stored on the device.</p> <p>After enabled, the platform will obtain the value from the device, and you can change it to 1–180. The images and videos that have been stored longer than this value will be automatically deleted.</p>  <p>Deleted files cannot be recovered. Please be advised.</p>

3.4 Connecting to Multiple Sites

If you have multiple platforms, you can connect one or more platforms to your current one, so that you can view the resources from them directly on your main platform, including viewing real-time videos from video channels, searching for viewing real-time and historical events, and downloading recorded videos. The information of the platforms is linked to the user logged in to the main platform. When the user log in to the main platform again, the main platform will automatically connect to the other platforms. This function is only available to users assigned with the administrator role.

Prerequisites

The versions of different platforms must be the same.

Procedure

Step 1 Log in the DSS Client.

Step 2 Click on the upper-right corner, and then click **Add Site**.

Step 3 Enter a name for the site, and the login information, and then click **OK**.

You can now view real-time videos of the devices, and real-time and historical events from the site.

Figure 3-61 Resources from the site shown in the monitoring center




Figure 3-62 Search for historical events from the site in Event Center

No.	Alarm Time	Site Name	Alarm Catego...	Alarm Type	Alarm Source	Priority	Remarks	Processed by	Alarm Status	Operation
1	2022-04-22 20:...	Site 2	Device	Device Disconn...	10.35.88.187	High			Pending	
2	2022-04-22 19:...	Site 2	Soft Trigger		IPC	High			Pending	
3	2022-04-22 19:...	Site 2	Soft Trigger		IPC	High			Pending	
4	2022-04-22 19:...	Site 2	Soft Trigger	Soft Trigger_1	IPC	High			Pending	

4 Businesses Configuration

This chapter introduces the basic businesses, such as storage plan, video monitoring, access control, alarm controller, video intercom, target detection, face recognition, ANPR, and intelligent analysis.


4.1 Configuring Events

To receive alarms triggered by devices, you need to configure them on the platform.

4.1.1 Configuring Event Linkage


Configure the event source, and the linked actions. When the event is triggered, the platform will perform the actions you defined, such as taking a snapshot recording a video.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Event > Event Config**.


Step 2 Click **Add**.

Figure 4-1 Configure the event source



Step 3 Configure the event source.

Table 4-1 Parameter description of event source types

Parameter	Description
Device, video channel, alarm input channel, EAS alarm channel, access control channel, radar, parking lot, lift control channel, and POS alarm	<p>Select the type according to the type of the device or channel.</p> <p></p> <ul style="list-style-type: none"> Before configuring the event, check whether the channel features match the event type; otherwise the event type cannot be selected as the alarm source. To configure channel features, see "3.1.2.5.2 Modifying Device Information". If Alarm Input Channel is selected, check whether the Triggered Event that you select matches the channel feature of the alarm input channel you select. Otherwise, the event will not be triggered.

Parameter	Description
Soft Trigger	This is a type of event that is manually triggered. Click Add Soft Trigger Event Type to customize its name and icon. When viewing the live video image of the configured channel in the Monitoring Center , you can click the icon to trigger an alarm manually.
Combined Event	When a combined event is triggered, the platform performs the defined linked actions. For how to configure combined events, see "4.1.2 Configuring Combined Events".
Custom Alarm	This is used for events that devices support, but the platform currently does not. Click Add Extended Standard Event , and then configure the alarm source, name, and alarm code.

Step 4 Configure the priority, when the event can be triggered, and other information.

Table 4-2 Parameter description



Parameter	Description
Priority	The priority level is used to quickly know the urgency of the event when it is triggered.
Time Template	Select a time template for when the event can be triggered. If you want to create a new template, see "3.1.8 Adding Time Template".
Holiday Template	Select a holiday template for when the event will not be triggered. To create a new template, follow the steps below. <ol style="list-style-type: none"> 1. In the drop-down box, click Create Custom Holiday Template. 2. Enter a name for the holiday. 3. Click Add, and then add a period and adjust the time. You can add up to 50 periods. 4. (Optional) If there are other holiday templates, you can select Copy From, and then select a template to copy its periods. 5. Click OK.
Tag	Enter some content that is used for filtering among a large amount of events.

Step 5 Configure alarm linkage actions.

- To link video, enable **Linked Action > Link Video**, and then configure the parameters.

Table 4-3 Parameter description

Parameter	Description
Camera	<ul style="list-style-type: none"> • Event source: The camera of the alarm itself is linked when the alarm occurs. • Bound camera: If the alarm channel is bound to a video channel, you can view the video of the bound channel. To bind a channel, see "3.1.3 Binding Resources". • Select camera: Select a camera so that you can view the camera video when the associated alarm is triggered.

Parameter	Description
When an alarm is triggered, display camera live view on client	<p>Enable this parameter, and then the platform will open the real-time video of the channel where an alarm is triggered, and play it in the defined stream type.</p>  <p>After the event is configured, select Local Settings > Alarm, enable Open Alarm Linkage Video and set how the video will be opened, As Pop-up or Open in Live View. For details, see "8.3.4 Configuring Alarm Settings".</p>
Event Recording	Start recording when an alarm is triggered. The video will be saved to ..\DSS\DSS Client\Record by default.
Stream Type	Define the stream type of the recorded video. If you select main stream, the recorded video will be in higher quality than sub stream, but it requires more storage.
Recording Time	The duration of the recorded video.
Prerecording Time	<p>When there is recorded video that is stored on the device or platform before the alarm is triggered, the platform will take the defined duration of that video, and then add it to the alarm video. For example, when the prerecording time is set to 10 s, then the platform will add 10 s of video before the alarm is triggered to the alarm video.</p>  <ul style="list-style-type: none"> • If the alarm video is stored on the device, we recommend you configure a 24-hour recording plan to make sure that there is prerecorded content to add to the alarm video. • If the alarm video is stored on the platform, the platform will record videos and use certain input bandwidth continuously. • This parameter is not applicable to alarms in parking lots.

- To trigger a snapshot, enable **Trigger Snapshot**. The platform takes 2 snapshots, and save them to ..\DSS\DSS Client\Picture by default.
Select a video channel, and then it will take a snapshot when an alarm is triggered.
- To link a PTZ action, click **Link PTZ**, and then select the PTZ channels and presets to be linked.
- Click **Alarm Output**, select an alarm output channel, and then set the duration. The channel will send out alarm signal when an alarm is triggered.
- To link audio and light, click **Link Audio and Light**, select the audio and light channels, and then select the action duration.
- Click **Link Access Control Device**, select door channels, and then select a linked action. When an alarm is triggered, the door channels you selected will be locked, unlocked, normally open or normally closed.
- To play alarm video on the video wall, click **Link Video Wall**, select a camera on the left of the page, and then select a video wall window on the right of the page.



Make sure that you have added decoders to the platform, configured video wall and set alarm window.

- To execute an HTTP URL; command, click **Link HTTP URL Command**. Click **Add**, and then configure its request method, HTTP URL, and remarks. You can click to test if the command is valid.
- To link emails, enable **Email**, and click to add the email address, and then an email will be sent to the selected email address when an alarm is triggered. You can also manually enter an email address, but you must press Enter to make it valid. To configure the email template, select **Add Email Template** from the **Email Template** drop-down list.
- Apply an alarm protocol to help users process alarms when they are triggered. Click **Alarm Protocol**, and then select a protocol from the **Protocol Template** drop-down list. Click **Add protocol template** to create a new protocol.

Step 6 Select one or more users who will receive the notification when an alarm is triggered. The users will only receive notifications when they are logged in. If you need to add more users, see "3.2 Adding Role and User".



If the page becomes too long because you need to configure many parameters, you can use the pane on the right to quickly go to different positions.

Step 7 Click **OK**.

4.1.2 Configuring Combined Events

Configure the relation between the time of trigger of 2 events, and then you can configure what actions to performed when the event is triggered.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Event > Combined Event Rule Config**.

Step 2 Click to add a rule for combined events.

Step 3 Enter a name for the rule, and then configure the details.

For example, select **event B occurs** and configure the **X** and **Y** to be 10 and 50 seconds respectively. If event B occurs during the 10 seconds to 50 seconds after event A occurs, a combined event is triggered, and then the platform will perform defined linked actions.

Step 4 Click **OK**.

The previous page displays.

Step 5 Click **Add**, and then configure the parameters of the combined event.

Table 4-4 Parameter description

Parameter	Description
Name	Enter a name for the combined event.
Rule	Select a rule.

Parameter	Description
Source of Combined Event	Select the event and event source for event A and B.

Step 6 Click **OK**.


Related Operations

Configure the linked actions for the combined event. For details, see the previous section.

4.1.3 Filtering Repetitive Alarms

If certain alarms are frequently triggered, you can configure an interval during which they can only be triggered once. For example, a tripwire alarm can only be triggered once in 10 seconds.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Event > Alarm Config**.

Step 2 Click **Add**.

Step 3 Select an event, and then configure the interval.

Step 4 Click **OK**.

4.2 Configuring Map


4.2.1 Preparations

- Devices are deployed. For details, see device user's manuals.
- Basic configurations of the platform have been finished. For details, see "3 Basic Configurations".
- If you need to use a raster map, prepare an image of the map.
- To show device alarms on the map, make sure that **Map flashes when alarm occurs** is enabled in **Home > Management > Local Settings > Alarm**.

4.2.2 Adding Map

4.2.2.1 Adding Vector Map

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Map**.




Step 2 In the map list, select the vector map, and then click .

Figure 4-2 Map



Step 3 Configure the parameters.

Figure 4-3 Map information



- Online map
 1. Select **Online**.
 2. Configure the information of the map, and then click **OK**.
- Offline map
 1. Select **Offline**.
 2. Click **Import** and import offline map.
 3. Configure map information, and then click **OK**.

Step 4 Add a sub map.

If there is a specific area on the map that you want to view its detailed information, you can add an image of it on the map as a sub map. For example, you can add a plane image of a parking lot on the map.

- 1) On the map resource tree on the left, click the name of the map that you have just added, or open the GIS map and click **Add Sub Map**.
 - 2) Name the sub map, upload a map picture, and then click **OK**.
 - 3) Drag the map to adjust its position, and then click **OK**.
- The sub map is added.


Related Operations

- **Hide Device Name**
Only display the icons of devices.
- **Satellite Map**
View the satellite map.
- **Delete Devices**
To delete a device from the map, click it and then click **Delete Resource**.
- **Show Device**
Select which type of resources you want to display on the map.
- **Move**
To move a device, click **Move** and then drag the device on the map.
- **Select**
To select one or more devices, click **Select**, and then click on the devices on the map one by one.
- **Pane**
To select devices in batches, you can click **Pane**, and then draw a frame on the devices to select the device.
- **Clear**
To clear all markings on the map, click **Clear**.
- **Add Sub-map**
To add a sub map on the current map, click **Add Sub Map**, click on the map to locate it, enter a name, upload a map picture and then click **OK**.
- **Length**
Select **Box > Length**, connect two points with a line on the map (double-click to finish drawing), and then the distance between the points is shown.
- **Area**
Select **Box > Area**, select a region on the map (double-click to finish drawing), and then the area is measured.
- **Add Mark**
Select **Box > Add Mark**, and then mark information on the map.
- **Reset**
Select **Box > Reset** to restore the map to its initial position and zoom level.

4.2.2.2 Adding Raster Map

A raster map is suitable for places where you want to view their detailed information, such as a parking lot. You can add multiple ones.

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section,

select **Map**.

Step 2 Select **Main Map**, and then click **Add Map**.

Step 3 Enter the map name, select the picture and then click **OK**.

Figure 4-4 Add main map



Step 4 Add a child map.

- 1) Click the added raster map, and then click **Add Sub Map**.
- 2) Enter the map name, upload the picture, and then click **Next Step**.
- 3) Drag the picture to the desired position and click **OK**.

Related Operations

- Hide Device Name
Only display the icons of devices.
- Delete Devices
To delete a device from the map, click it and then click **Delete Resource**.
- Show Device
Select which type of resources you want to display on the map.
- Move
To move a device, click **Move** and then drag the device on the map.
- Select
To select one or more devices, click **Select**, and then click on the devices on the map one by one.
- Pane
To select devices in batches, you can click **Pane**, and then draw a frame on the devices to select the device.
- Clear
To clear all markings on the map, click **Clear**.
- Add Sub-map
To add a sub map on the current map, click **Add Sub Map**, click on the map to locate it, enter a name, upload a map picture and then click **OK**.
- Map scale
Select **Map Scale** > **Configure the map scale**, draw a line on the map, and then enter its actual distance.

- Length
Select **Box > Length**, connect two points with a line on the map (double-click to finish drawing), and then the distance between the points is shown.
- Area
Select **Box > Area**, select a region on the map (double-click to finish drawing), and then the area is measured.
- Add Mark
Select **Box > Add Mark**, and then mark information on the map.
- Reset
Select **Box > Reset** to restore the map to its initial position and zoom level.

4.2.3 Marking Devices

Link a device to the map by dragging it to the corresponding location on the map according to its geographical location.

Procedure



- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Map**.
- Step 2 Click the map.

Figure 4-5 Map



- Step 3 Drag the device channel from the left device tree to the corresponding location of the map.



If you mark a radar on the map, you can configure the Radar-PTZ linkage function. For details, see "4.2.4 Configuring Radar-PTZ Linkage".

4.2.4 Configuring Radar-PTZ Linkage

A radar can meet most security needs because it can penetrate fog, smoke, and dust. After a target is detected by the radar, you can view real-time videos of PTZ cameras to understand the situation better and faster.

Before configuring the function, you must complete the following configurations first:

- The radar and PTZ cameras are directly added to the platform through their IP addresses. Also, they must be on the same network, or different networks that can connect to each other. One radar can link up to 8 PTZ cameras.

- Configure a vector or raster map. If you use a raster map, you must configure the map scale so that the alarm area and detection area of the radar can be displayed normally.
- If you also need to monitor the area around the radar, you can bind it with video channels. For details, see "3.1.3 Binding Resources".

4.2.4.1 Configuring Linkage

Configure the linkage between the radar and PTZ cameras. When an alarm is triggered, PTZ cameras will track the target. Operations on a vector map or raster maps are similar, and this section uses vector map as an example.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Map**.
- Step 2** Click the vector map to open it.
- Step 3** In the device tree on the left, drag the radar channel on the map.

Figure 4-6 Mark a radar



- Step 4** Click , and then configure the parameter.
- 1) In the device tree, select one or more PTZ cameras to be linked to the radar.



If you already configured related parameters on the webpage of the radar, the platform will automatically obtain the information of the PTZ cameras. Click **Bind** to save the linkage relationship and skip the following steps.


- 2) Click **Bind and Configure** to save the linkage relationship, and then go to the webpage of the radar.
- 3) On the webpage of the radar, configure the parameters related to radar-PTZ linkage, such as upload an image of the map, set the position and heading angle of the radar,

and, calibrate the PTZ cameras. For details, see the user's manual of the radar.

4.2.4.2 Configure a Radar Event

Configure an event so that an alarm will be triggered after a target enters the warning area and alarm area of the radar, and then the platform will perform the defined linkage actions, such as taking a snapshot.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Event > Event Config**. Click **Add**, and then configure the parameters. For details, see "4.1.1 Configuring Event Linkage".

4.3 Personnel and Vehicle Management


Configure personnel and vehicle information for the applications of access control, vehicle control, attendance management, and video intercom.

- Personnel information contains card number, password, face picture, and more. People bound with vehicle information will be displayed in the vehicle list.
- Vehicle information helps to confirm the entry of the vehicle into a certain area. Vehicle bound with personnel information will be displayed in the personnel list.

4.3.1 Adding Person and Vehicle Groups

Add person and vehicle groups to easily manage people and vehicles. People and vehicles use the same groups. Only administrators can add, edit, and delete person and vehicle groups.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Personal and Vehicle Info**.

Step 2 Click **Person List** or **Vehicle List**.




Step 3 Click , and then configure the parameters.

Table 4-5 Parameter description

Parameter	Description
Parent Group	This is for permission control. For example, if a user cannot access Group A, then the user cannot access all the groups under Group A.
Group Name	Enter a name for the group.
Roles Allowed Access	Only the roles and their users can view this group.  Click  to see the users assigned with the roles.

Step 4 Complete configuration.

- Click **Add** to add the group and exit the page.

- Click **Save and Add Person** to add people to the group. For details, see "4.3.2 Configuring Personnel Information".

4.3.2 Configuring Personnel Information



Add people to the platform and grant them access to different access control devices, entrance and exits permissions, and more.



- The information of a person must be the same on the platform and access control devices, such as the person ID and card number. Otherwise the attendance data of this person cannot be synchronized between the platform and access control devices.
- To collect fingerprints or card number, connect a fingerprint collector or card reader to the computer where the PC client is installed.

4.3.2.1 Adding a Person

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Personal and Vehicle Info**.
- Step 2** Click .
- Step 3** Click **Add**.
- Step 4** Click the **Basic Info** tab to configure person information.
- 1) Hover over the profile, and then click **Upload** to select a picture or click **Snapshot** to take a photo.






- You can upload 2 pictures or take 2 snapshots.
 - Click  on the **Snapshot** page, and then you can select camera, pixel format, resolution, and image quality. These settings are only effective with the current client.
- 2) Enter personnel information as necessary. ID is required and must be unique. It can be up to 30 characters, and letter-number combination is also supported.

Figure 4-7 Personnel information



Only certain devices support the second picture or snapshot. The second picture or snapshot can be the person's face being blocked, such as wearing a mask or a hat.

Step 5 Click , and then set person details as required, including nickname, ID, address, birthday, region, company, job title, and more.


Step 6 If the person is resident, Click  next to **Resident Info**, and then bind room number.




- **Room No.:** The number of the apartment in which this person lives. The room number is displayed in the access records and video intercom operation records. Access permission of the corresponding VTO is also included when authorizing access control permission to this person.
- **Homeowner:** When several people live in one apartment, you can set one of them as the homeowner.

Step 7 Click the **Authentication Info** tab, and then set validity period and access control information.

Figure 4-8 Authentication Info



- 1) Configure effective periods, within which the face, card, password, and fingerprint are effective.
- 2) When access controllers are added and passwords are required to unlock the door, configure the password first.
 - A multi-factor authentication password must be used with a card, person ID, or fingerprint to unlock the door. It is only applicable to second-generation access control devices.
 - Click  and you can set up an unlock password that can be used to directly unlock the door. It is only applicable to first-generation access control devices.

Step 8 Issue cards to personnel.

One person can have up to 5 cards. There are two ways to issue cards: by entering card No. or by a card reader. A card number is 8-16 numbers. Only second-generation access control devices support 16-digit card numbers. When a card number is less than 8 numbers, the system will automatically add zeros prior to the number to make it 8 digits. For example, if the provided number is 8004, it will become 00008004. If there are 9-16 numbers, the system will not add zero to it.



- Issue a card through a card issuer or a device with a card reader.
 1. Click  next to **Card**, select a card issuer or a reader of a device, and then click **OK**.

Figure 4-9 Card reader manager







2. Click , swipe a card on the device you select, the card number will be recognized and displayed.
 3. Click .
- Manually enter the card number.
Click , enter card number, and then click .

Figure 4-10 Reader manager













Table 4-6 Card operations

Icon	Description
	If a person has more than one card, only the main card can be issued to the first-generation access control device. The first card of a person is the main card by default. Click  on an added card, the icon turns into  , which indicates that the card is a main card.
	Set a card as duress card. When opening door with a duress card, there will be a duress alarm. Click this icon, it turns into  , and  is displayed at upper right, which indicates that the card is set as a duress card. To cancel the duress setting, click  .
	Change card for the person when the current card does not work.
	Remove the card, and then it has no access permissions.

Step 9 Collect fingerprint.

To open door with fingerprint, you need to collect personnel fingerprints. A person can have up to 3 fingerprints.

- 1) Click next to **Fingerprint**.
- 2) Click **Add**.
- 3) Select a fingerprint collector from the **Fingerprint Collector** drop-down list, and then click **OK**.
- 4) Click **Add**

Figure 4-11 A collected fingerprint




Table 4-7 Fingerprint operations

Icon	Description
	One can have 3 fingerprints, but only these fingerprints can be issued to devices. Click this icon, and then it turns into , which indicates that this fingerprint has been set as a main one. To cancel the main fingerprint setting, click .
	Set a fingerprint as duress fingerprint. When opening door with a duress fingerprint, there will be a duress alarm. Click this icon, it turns into , which indicates that the fingerprint has been set as a duress fingerprint. To cancel the duress setting, click .
	Modify fingerprint name.
	Remove the fingerprint, and then it has no access permission.

Step 10 If the person has one or more vehicles, click next to **Vehicle Information** to add vehicle information, so that you can grant access permissions to this person's vehicles later.


- If vehicles have been added to the platform, click **Select from Vehicle List**, and then select the vehicles for this person.
- If vehicles have not been added to the platform, click , and then enter the plate number, and select a color and brand.

Step 11 If the person needs access control permission, enable the permission first.

- 1) Click next to **Access Control Permission**.

- 2) Select **Access Type**, and select **Allow Device Login** check box as needed.
 - **Allow Device Login**: People have permission to go into web page from the device.
 - Select **General** if you want to set the person to be a first-card user.
- 3) Click **Add**, and then select access control permission group. For details, see "4.4.1.1 Creating Face Comparison Group".


Figure 4-12 Add to access control permission group



Step 12 Enable **Lift Control Permissions** so that the person can use certain lifts.

- 1) Click next to **Lift Control Permissions**.
- 2) Select one or more lift control devices, and then select the floors this person can go to.

Figure 4-13 Lift control devices and floors




You need to create a face comparison group first.

Step 13 Enable **Face Comparison** to recognize the person by images.

- 1) Click next to **Face Comparison**.
- 2) Select a face comparison group.

Figure 4-14 Face comparison



You need to create a face comparison group first.

Step 14 If the vehicle needs access to the parking lot, enable and configure **Vehicle Group** first.




- 1) Click  next to **Parking Lot Vehicle Group**.
- 2) Enable **Parking Space Available** and configure the number of the parking space for the vehicle owner.
- 3) Click **Add** to select a vehicle of the person, and then select which vehicle group it belongs to, and for how long it has permission to park in the parking lot.

Figure 4-15 Parking lot vehicle group






Step 15 Click **OK**.



To delete a person, you can select the person, and then click ; to delete all people on this page, select the **Select All** check box, and then click **Delete**.

Related Operations

- To edit basic information of a person, select the person, and then click .
- To delete a person:
 - ◇ Click  to delete a person and associated permissions.
 - ◇ Select multiple people, and then click **Delete** to delete them and their permissions.
 - ◇ Click **Delete All** to delete all the people and their permissions in the group.
- To view authorization exception, click .
- To search for a person, enter key words in the .

4.3.2.2 Importing Multiple Persons

To quickly add a number of personnel, you can download a personnel template, fill in it and then

import it to the platform. You can also import an existing personnel file.

Prerequisites

Prepare an .xlsx file that includes the information of the people you want to import, their face images (optional), and then compress them into a zip file. The .xlsx file can include information of up to 10,000 people. The zip file cannot be larger than 1 GB.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Personal and Vehicle Info**.
- Step 2** Click .
- Step 3** Select **Import** > **Import from File**.

Figure 4-16 Import personnel information



- Step 4** Import the personnel information file.



If there is no personnel information file, click **Template Download** and follow the instructions on the page to create personnel information.

- Step 5** Click **OK**.

The following cases might occur during an import:

- If there are failures, you can download the failures list to view details.
- Read carefully the instructions in the template to make sure all the information is correct.
- Cannot read the contents with a parsing error reported directly.

Related Operations

- Export personnel information.
Select an organization, click **Export**, and then follow the instructions on the page to save the exported information to a local disk.
- Download template.
To add personnel information in batches, you can download the template, fill in the information, and then import it.

4.3.2.3 Extracting Personnel Information

When personnel information has been configured on access control devices or door stations, you can directly synchronize the information to the platform.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Personal and Vehicle Info**.
- Step 2** Click .
- Step 3** Click **Import**, and then select **Import from Device**.

Figure 4-17 Import from device



- Step 4** Click , select a channel from an access control device or door station, and then click **OK**.


Figure 4-18 Extract task list



Step 5 Double-click a result to view the detailed information.

Step 6 Synchronize personnel information to the platform, or export information.

Figure 4-19 Personnel extraction results



- To add all the personnel information to the platform, click **Import All**.

- To add part of the information, select the people of interest, and then click **Import selected**.
- To export information, select the people you want, and then click **Export**.

4.3.2.4 Issuing Cards in Batches

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Personal and Vehicle Info**.
- Step 2** Click .
- Step 3** Select the people to issue card to, and then click **Batch Issue Card**.

Figure 4-20 Issue card in batches



- Step 4** Set term of validity.
- Step 5** Issue cards to personnel.
- Step 6** Support issuing cards by entering card number or by using a card reader.
 - By entering card number

Figure 4-21 Enter card number

↶
Batch Issue Card

Effective Period:

2021/04/13 00:00:00-2031/04/13 23:59:59
📅


Issue Card ⚙️

ID	Name	Card No.	Operation
942	233		🗑️
2890	1		🗑️
19010	andy		🗑️
20711	test		🗑️
26227	test1		🗑️
26607	2		🗑️
1340121	112		🗑️
6754227	z1		🗑️
10020001	ZhangSan1	10020001	🗑️
10020002	ZhangSan2	10020002	🗑️
10020003	ZhangSan3	10020003	🗑️
10020004	ZhangSan4	10020004	🗑️
10020005	ZhangSan5	10020005	🗑️
10020006	ZhangSan6	10020006	🗑️
10020007	ZhangSan7	10020007	🗑️
10020008	ZhangSan8	10020008	🗑️

Save
Cancel

- 1) Double-click the **Card No.** input boxes to enter card numbers one by one.
- 2) Click **OK**.
 - By using a card reader
 - 1) Click ⚙️.
 - 2) Select a card reader or device, and then click **OK**.

Figure 4-22 Reader manager






- 3) Select people one by one and swipe cards respectively until everyone has a card number.
- 4) Click **OK**.

4.3.2.5 Editing Person Information

Modify personnel information including basic information, authentication details, and authorization. Person ID cannot be modified.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Personal and Vehicle Info**.
- Step 2 Click .
- Step 3 Click  to edit information. For details, see "4.3.2.1 Adding a Person".

4.3.3 Vehicle Management

Manage vehicle information including vehicle type, owner, entry and exit permissions and arming groups.

Procedure





- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Personal and Vehicle Info**.
- Step 2 Click .
- Step 3 Click **Add** to add vehicle information.
 - Add vehicles one by one
 1. In the **Owner Info** section, click **Select from Person List** to select the owner of the vehicle.
 2. Configure the information of the vehicle in the **Vehicle Info** section, such as the vehicle group, plate number (required and unique), vehicle color, brand and more. If you have selected an owner, you can add multiple vehicles.
 3. Click  to enable **Parking Lot Vehicle Group**, and then you can set the available parking spots for the selected person, and grant access permissions by adding vehicles into entrance and exit vehicle groups.


Figure 4-23 Parking lot vehicle group



If the owner has more vehicles than the set parking spots, once no parking spots available, owner cannot access the parking lot.

- Click to enable **Vehicle Arming Group**, and then click **Add** to arm the vehicles you have just added.

Figure 4-24 Vehicle arming group



For arming group details, see "4.4.2.1 Creating Vehicle Arming Group".

- Add vehicles in batches
 - Click **Import** at the top, and then click **Template Download**.
 - Fill in the template, and then select **Import** > **Import File**. Click to select the file and import.




The platform supports downloading files that failed to import for you to check and fix.

Step 4 Click **OK**.



Step 5 (Optional) You can export vehicle information to local storage as needed.

Figure 4-25 Export vehicle information



- Click **Export** and then enter required information, such as passwords for login and encryption, to export all the items.
- Select vehicles, and then click **Export** to export only the selected information.

Related Operations

- You can search vehicles by entering keywords in search box at the upper-right corner.
- Click  or double-click the column to edit the vehicle information.
- Click  to delete vehicles one by one. You can also select multiple vehicles and then click **Delete** at the top to delete in batches.

4.4 Watch List Configuration

Configure face and vehicle watch list for future investigation.

- For face watch list, you can create and arm face comparison groups to recognize faces.
- For vehicle watch list, you can create vehicle comparison groups, add vehicles and then link devices for plate recognition.

4.4.1 Face Watch List

Configure face watch list and issue the list to devices for recognition and alarm.


4.4.1.1 Creating Face Comparison Group

Only administrators can add, edit, and delete person and face comparison groups.

Prerequisites

- Make sure that the devices for face recognition have been successfully configured onto the Platform.
- Make sure that the basic configuration of the Platform has completed. For details, see "3 Basic Configurations". During the configuration, you need to pay attention to following parts.
 - ◇ When adding devices on the **Device** page, set the **Device Category** to **Encoder**.


Figure 4-26 Device category



The screenshot shows the 'Add Device' configuration interface. The 'Device Category' dropdown menu is highlighted with an orange border and shows 'Encoder' selected. Other fields include 'Add Mode' (IP Address), 'Access Protocol' (Dahua), 'IP Address' (empty), 'Device Port' (3777), 'Username' (admin), 'Password' (masked), 'Organization' (Root), and 'Server' (empty).

- ◇ When adding devices like NVR or IVSS which support face recognition, set the device feature to **Face Recognition**. For details, see "3.1.2.5 Editing Devices".

Figure 4-27 Feature configuration



- ◇ Make sure that you have configured at least one disk with the type of **Images and Files** to store face images. Otherwise, the snapshots cannot be displayed.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Watch List > Face Watch List**.
- Step 2** Click **Add**, and then configure the parameters.

Table 4-8 Parameter description



Parameter	Description
Face Comparison Group Name	Enter a name for the group.
Color	You can use colors to quickly differentiate each group. For example, red indicates key targets.
Roles Allowed Access	Only the roles and their users can view this group.  Click  to see the users assigned with the roles.

- Step 3** Click **Add**.

4.4.1.2 Adding Faces

Add people to face comparison groups. Their faces will be used for face comparison.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Watch List > Face Watch List**.
- Step 2** Click  of a group you want to add people to it.
- Add people by person groups. This is the most efficient way, provided that you have created person groups based on the access permissions. For details, see "4.3.2 Configuring Personnel Information".
 Click **Add by Person Group**, select one or more groups, and then click **OK**. You can also select **Include Sub Groups** to include the people in the sub groups of the groups you select.
 - Select the people you want to add. This is applicable to people in different person groups have the same access permissions.
 Click **Add by Person**, select the people you want to add, and then click **OK**.

4.4.1.3 Arming Faces

The faces of the people in comparison groups will be sent to devices for real-time face recognition. If the similarity reaches the defined threshold, alarms will be triggered.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Watch List > Face Watch List**.
- Step 2** Click  of the face comparison group you want to arm.
- Step 3** Click **Add**, select one or more devices or channels, and then click **OK**.
The platform will send the information of the face watch list to the devices and channels you selected, and display the progress. If exceptions occur, you can click  to see the reason.

Figure 4-28 Send face comparison group




- Step 4** After the face watch list is successfully sent, click **Next Step**.
- Step 5** Click **Add**, select the channels you want to arm, and then configure the similarity for each channel.



When the similarity between the face captured by the channel and a face in the face watch list reaches or is greater than the defined value, it is considered a match.

Figure 4-29 Arm face comparison group



Step 6 Click **OK**.

Step 7 (Optional) View exceptions and arm the face comparison group again.

- 1) Click to view why arming failed and address the issue.
- 2) Click **Send Again** to arm the face comparison group again.

4.4.2 Vehicle Watch List

Create a vehicle comparison group and add vehicles to it. After a vehicle comparison group is sent to ANPR cameras for recognition, alarms will be triggered if the vehicles in the group are captured and recognized.



4.4.2.1 Creating Vehicle Arming Group

A vehicle arming group contains the information of multiple vehicles. When arming the group, you can arm all the vehicles inside the group at the same time. Only administrators can add, edit, and delete person and face comparison groups.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then click **Watch List > Vehicle Watch List**.
- Step 2** Click **Add**, and then configure the parameters.

Table 4-9 Parameter description

Parameter	Description
Vehicle Arming Group Name	Enter a name for the group.
Color	You can use colors to quickly differentiate each group. For example, red indicates key targets.
Roles Allowed Access	Only the roles and their users can view this group.  Click  to see the users assigned with the roles.


Step 3 Click **Add**.

4.4.2.2 Adding Vehicles

Add vehicles to vehicle arming groups. After armed, devices will recognize their plate numbers and trigger alarms.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then click **Watch List > Vehicle Watch List**.

Step 2 Click  of a group, or double-click a group, and then click **Select from Vehicle List**.

- Add vehicles by vehicle groups. This is the most efficient way, provided that you have created vehicle groups. For details, see "4.3.2 Configuring Personnel Information". Click **Add by Vehicle Group**, select one or more groups, and then click **OK**. You can also select **Include Sub Groups** to include the vehicles in the sub groups of the groups you select.
- Select the vehicles you want to add. This is applicable to vehicles that you want to add are in different vehicle groups. Click **Add by Vehicle**, select the vehicles you want to add, and then click **OK**.

4.4.2.3 Arming Vehicles

The plate numbers of the vehicles in comparison groups will be sent to devices for real-time recognition and trigger alarms.



Log in to the DSS Client. On the **Home** page, click , and then arm the vehicle on the **Event** page. Click **Add** to add an event to arm a vehicle watch list. For how to configure events, see "4.1 Configuring Events".

Figure 4-30 Arm vehicle event



4.5 Access Control

- Access control
Issue cards, collect fingerprints and face data, and apply permissions, so that the authorized people can open door by using card, face or fingerprint.
- Advanced functions
Configure advanced access control rules such as First-card Unlock, Multi-card Unlock, Anti-pass Back and Interlock to enhance security.

4.5.1 Preparations

Make sure that the following preparations have been made:


- Access control devices are correctly deployed. For details, see the corresponding user's manual of the device.
- Basic configurations of the platform have been finished. See "3 Basic Configurations" for details.
 - ◇ When adding access control devices, select **Access Control** for device category.
 - ◇ (Optional) On the **Bind Resource** page, bind video channels for access control channels.
 - ◇ Personnel information is added correctly. For details, see "4.3 Personnel and Vehicle Management".

4.5.2 Configuring Door Groups

Door groups allow you to easily manage access permissions by granting them to people in batches. A normal user can only access a door group if it can access all the channels in the group.

Administrators can access all door groups by default.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.
- Step 2** Click **add**, and then enter the group name, select a time template and a holiday schedule, select device channels, and then click **OK**.
- After the time template and channels are configured, people assigned with the permission can only unlock the doors during the defined periods.
- In the **Time Template** drop-down list, select **Create Time Template**. For details, see "3.1.8 Adding Time Template".
 - If you have added holiday plans, select one in the **Holiday Plan** drop-down list. You can also create new holiday plans. For details, see "4.5.8 Configuring Holidays".

4.5.3 Configuring Access Permission Groups

By adding multiple door groups to an access permission group, you can quickly assign people permissions to access all the channels in the door groups. Only administrators can edit the door groups in access permission groups.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Access Permission Group**.
- Step 2** Click **Add**, and then configure the parameters.

Table 4-10 Parameter description

Parameter	Description
Access Permission Group Name	Enter a name for the group.
Door Groups	Select one or more door groups.
Roles Allowed Access	Only the roles and their users can access this group.  Click  to see the users assigned with the roles.

- Step 3** Click **OK**.
- Step 4** Click  and select people to grant them access to the access control channels in batches.
- Add people by person groups. This is the most efficient way, provided that you have created person groups based on the access permissions. For details, see "4.3.2 Configuring Personnel Information".
Click **Add by Person Group**, select one or more groups, and then click **OK**. You can also select **Include Sub Groups** to include the people in the sub groups of the groups you select.
 - Select the people you want to add. This is applicable to people in different person groups have the same access permissions.
Click **Add by Person**, select the people you want to add, and then click **OK**.

4.5.4 Configuring Public Passwords

Anyone with a public password can unlock associated doors. You can add up to 1,500 passwords.



Only second-generation access control devices and video intercom devices support this function.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control** > **Door Groups**.
- Step 2** Click .
- Step 3** Click **Add**, enter a name and a password, and then select the access control channels and video intercom devices as needed.

Figure 4-31 Add a public password

- Step 4** Click **Save**.

4.5.5 Configuring Advanced Functions

4.5.5.1 First Card Unlock

Only after the specified first-card user swipes the card on each day can other users unlock the door

with their cards. You can set up multiple first-card users.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.
- Step 2** On the **Access Control** page, click .
- Step 3** Click the **First Card Unlock** tab.
- Step 4** Click **Add**.
- Step 5** Configure the parameters, and then click **OK**.

Figure 4-32 First card unlock configuration

Table 4-11 Parameters

Parameter	Description
Door	You can select which access control channel to use the first-card unlock function.
Time Template	First-card unlock is valid in the time period of the selected time template.

Parameter	Description
Status	After first-card unlock is enabled, the door is in either the Normal mode or Always Open mode.
User	You can select one or more users to be first-card unlock users. Any one of them swipes the card, and then other users can unlock the door.

Step 6 Click , and then it changes to . The function is enabled.

4.5.5.2 Multi-Card Unlock

You can configure a door to be opened by a number of people in a defined order.


Background Information

- You can add up to 50 people in a group. Each person can only be added to one group at the same time.
- If you enable the multi-card unlock function for a door channel, you can select up to 4 multi-card unlock groups of people to the door, but the number of people who need to verify their identifications cannot exceed 5.



- If the first-card unlock and multi-card unlock functions are enabled on a door channel at the same time, the platform will execute first-card unlock first.
- We do not recommend adding the people related to the first-card unlock function to a multi-card unlock group. If a person related to the first-card unlock function and also in a multi-card unlock function swipes a card, the platform will consider that the first-card unlock function is used.
- The access type of the people in a multi-card unlock group cannot be **VIP** or **Patrol**. This parameter is configured when adding people to the platform. See "4.3.2.1 Adding a Person".

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.


Step 2 On the **Access Control** page, click .

Step 3 Click the **Multi-card Unlock** tab.

Step 4 Add a user group.

- 1) Click **Add Multi-card Unlock Group**.
- 2) Click **Add**.
- 3) Enter the group name, select users from **User List** and then click **OK**.
You can select up to 50 users.


Figure 4-33 Multi-card unlock group configuration



Step 5 Configure the multi-card unlock function.

- 1) Go back to the **Multi-card Unlock** page, and click **Add**.
- 2) Select the door to use the multi-card unlock function.
- 3) Select the user group. You can select up to four groups.

Figure 4-34 User group information



- 4) Fill in the **Valid Quantity** for each group to be on site and the **Open Door Mode**. Click or to adjust the group order.
- 5) The valid quantity refers to the number of users in each group that must be on site to swipe their cards, user their passwords, or press their fingerprints.



Up to five valid users are allowed.

6) Click **OK**.

Step 6 Click , and then it changes to . The function is enabled.

4.5.5.3 Anti-passback

The anti-passback feature requires a person to enter and exit from the specific doors. For the same person, an entry record must pair with an exit record. If someone has entered by tailing someone else, which means there is no entry record, this person cannot unlock the door to exit.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.

Step 2 On the **Access Control** page, click .

Step 3 Click the **Anti-passback** tab.

Step 4 Click **Add**.

Step 5 Configure the parameters, and then click **OK**.

Figure 4-35 Anti-passback parameters







Table 4-12 User selection information description

Parameter	Description
Device	You can select the device to configure the anti-passback rules.
Anti-passback name	You can customize the name of an anti-passback rule.
Reset Time(min)	The access card becomes invalid if an anti-passback rule is violated. The reset time is the invalidity duration.
Time Template	You can select the time periods to implement the anti-passback rules.
Remark	Description information.
Group X (X is a number)	The group sequence here is the sequence for swiping cards. You can add up to 16 readers for each group. Each group can swipe cards on any of the readers.



When the selected device is a multi-door controller, you must set up these parameters.

Step 6 Click , and then it changes to . The function is enabled.

4.5.5.4 Multi-door Interlock

A regular access controller employs interlock within a group. To open one of the access control channels (under normal access control), other access control channels must be closed; otherwise the door cannot be unlocked. The A&C Central Controller employs interlock across groups, where the access control channels within the same group are not interlocked, and can all be opened. However, whenever an access control channel in a group is opened, no channels of other groups can be opened. The configuration steps in this chapter are for an A&C Central Controller.

Procedure



- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.
- Step 2 On the **Access Control** page, click .
- Step 3 Click the **Multi-door Interlock Config** tab.
- Step 4 Click **Add**.
- Step 5 Configure the parameters, and then click **OK**.

Figure 4-36 Multi-door interlock




Table 4-13 Parameters

Parameter	Description	
Device	You can select the device to set up inter-lock.	
Multi-door Interlock Name	You can customize the name of the inter-lock rule.	
Remark	Description information.	When the selected device is a multi-door controller, you must set up these parameters.
Multi-door Interlock List	You can set up inter-lock across different door groups. If a door in Group 1 is opened, no doors can be opened in Group 2 until all doors in Group 1 are closed. Supports up to 16 door groups, with up to 16 doors in each group.	

Step 6 Click , and then it changes to . The function is enabled.

4.5.5.5 Remote Verification

For devices with remote verification, when users unlock the doors with card, fingerprint, or password in the specified time period, it must be confirmed on the platform client before the access controller can be opened.

Procedure






- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.
- Step 2 On the **Access Control** page, click .
- Step 3 Click the **Remote Verification** tab.
- Step 4 Click **Add**.

Figure 4-37 Add remote verification




- Step 5 Select **Time Template** and access control channel, and click **OK**.
- Step 6 Click , and then it changes to . The function is enabled.
After the setup, door unlocking by card, fingerprint, or password that takes place in the corresponding access control channel triggers a pop-up on the client.
You can choose to unlock the door or ignore it by clicking the corresponding button, and the pop-up automatically disappears.


4.5.6 Synchronizing Records

If access control devices go offline and then online again, the platform can automatically synchronize records from them during that period to make sure that access control and attendance

records are complete and up-to-date.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Auto Sync Records**.

Step 2 Click  to enable the function.

Step 3 Set up a time, and then click **Save**.

The platform will synchronize records on a regular basis.



Click **Extract Now** to immediately synchronize records from devices to the platform.


How records are synchronized:

- If records on a device was automatically synchronized to the platform, then the platform will synchronize all records from the time of the latest record from the last automatic synchronization to the time you set. For example, the latest record from the last automatic synchronization was on 2022-10-18 16:00, time of automatic synchronization is set to 04:00 every day. The device was offline on 2022-10-18 18:00, and then reconnected on 2022-10-20 16:00, then the platform, on 2022-10-21 04:00, will synchronize the records generated on the device from 2022-10-18 16:00 to 2022-10-21 04:00.
- If records on a device has not been automatically synchronized to the platform, and the device went offline and online multiple times, the platform will synchronize all the records from the time of the latest record uploaded before the first offline, to the time you set. For example, time of synchronization is set to 04:00 every day. The device first goes offline on 2022-10-18 16:00 with the latest record uploaded on 2022-10-18 15:00. Before the time of synchronization, the device goes offline and online multiple times. Then on 2022-10-19 04:00, the platform will synchronize the records generated on the device from 2022-10-18 15:00 to 2022-10-19 04:00.
- If records on a device has not been automatically synchronized to the platform, and records were not generated on the device and uploaded to the platform when the device is online, then on the time of synchronization, the platform will synchronize the records on the device within the past 24 hours.

4.5.7 Configuring Time Templates

Configure time templates for different access control strategies. For example, employees can only gain access to their offices during work time.


Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.

Step 2 Click .


Step 3 Click **Create Time Template** from the **Time Template** drop-down list when adding or editing a door group.

Figure 4-38 Time template



Step 4 Enter the template name, set time periods, and then click **OK**.

There are two ways to set time periods:

- Drag your mouse cursor on the time bars to select time sections. To remove a selected time section, click on the time bar and drag.
- Click , and then set time periods in the **Period Setup** dialog box.



- You can add up to 6 periods for each day.
- To use an existing template, select the **Copy From** check box and then select a template in the drop-down list.

4.5.8 Configuring Holidays

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Access Control > Door Groups**.
- Step 2** Click **Add Holiday Schedule** from the **Holiday Schedule** drop-down list when adding or editing a door group.

Figure 4-39 Add a holiday schedule

Holiday Plan

Holiday Plan Name:

Schedule:

00:00 02:00 04:00 06:00 08:00 10:00 12:00 14:00 16:00 18:00 20:00 22:00 24:00

Holiday: Up to 16 holidays can be selected.

Holiday Name	Date	Operation
aaa	2021-07-15 - 2021-07-16	

Selected (0)

Add Cancel

Step 3 Configure the parameters.

1. Enter a holiday schedule name.
2. Configure the periods in the **Schedule** section.
3. Click to add a holiday: Enter the holiday name, set a start date, and how many days this holiday lasts, and then this holiday will be effective within the periods you set from the previous step.

Step 4 Click **Add**.

4.5.9 Configuring Access Control Devices

After an access control device is added, and if it is online, you can restart it, and synchronize its time with the platform.


Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.


Step 2 Click .

Step 3 Select an access control device from the device tree.

Figure 4-40 Select an access control device



Step 4 Configure the access control device.

- Click **Restart Device** to restart the device.
- Click  at the upper-right corner to go to the web page of the device.

4.5.10 Configuring Door Information

You can configure door status, Always-Open or Always-Close period, alarm and more.

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **Device**.
- Step 2** Select a door channel in the device tree, and then click **Door Config** on the right.
- Step 3** Configure door information, and then click **OK**.

Figure 4-41 Door configuration

The screenshot shows the 'Door Config' interface with the following settings:

- Reader Direction:** In Reader 1 ⇌ Out Reader 2
- Mode:** Normal
- NO Period:** Disabled (toggle), All-Period Template
- NC Period:** Disabled (toggle), All-Period Template
- Enable Door Sensor:** Disabled (toggle)
- Enable Alarm:** Enabled (toggle)
 - Duress
 - Unsuccessful Attempts Exceeding ...
- Public Password:** Disabled (toggle)
- Unlock Duration:** 5 sec
- Unlock Timeout:** 5 sec
- Unlock Method:** OR
 - Card
 - Fingerprints
 - Password
 - Face



The page is only for reference, and might vary with different access control devices.

Table 4-14 Parameters description

Parameter	Description
Reader Direction	Indicates the in/out reader based on the wiring of ACS.
Door Status	Set access control status to Normal, Always Open, or Always Close.
NO Period	If enabled, you can set up a period during which the door is always open.
NC Period	If enabled, you can set up a period during which the door is always closed.
Door Sensor Enable	You can only enable intrusion and timeout alarms when the door sensor is enabled.
Enable Alarm	<ul style="list-style-type: none"> • Intrusion: If the door is unlocked by methods you have not configured, the door contact is split and triggers an intrusion alarm. • Unsuccessful Attempts Exceeding Limit: If failed to unlock the door for certain times, an alarm will be triggered. • Duress: Entry with the duress card, duress password, or duress fingerprint triggers a duress alarm. • Timeout: Unlock duration timeout triggers a timeout alarm.
Public Password	Enable this function, and then you can use a public password to unlock the door. For how to configure a public password, see "4.5.4 Configuring Public Passwords".

Parameter	Description
Unlock Duration	Sets up for how long the door will unlock. The door locks automatically after the duration.
Unlock Timeout	Unlock duration exceeding the Unlock timeout triggers a timeout alarm.
Multi-door Interlock	Select whether to enable your multi-door interlock configuration. See "4.5.5.4 Multi-door Interlock".
Unlock Method	<p>You can use any one of the methods, card, fingerprint, face, and password, or their combinations to unlock the door.</p> <ul style="list-style-type: none"> • Select And, and select unlock methods. You can only open the door using all the selected unlock methods. • Select Or and select unlock methods. You can open the door in one of the ways that you configured. • Select Unlock by period and select unlock mode for each time period. The door can only be opened by the selected method(s) within the defined period.

4.6 Video Intercom

4.6.1 Preparations

Make sure that the following preparations have been made:

- Access control devices are correctly deployed. For details, see the corresponding user's manuals.
- Basic configurations of the platform have been finished. To configure, see "3 Basic Configurations".
 - ◇ When adding video intercom devices on the **Device** page, select **Video Intercom** as the device category.
 - ◇ When adding access control devices that support intercom, select **Device Category** to **Access Control** in **Login Information**, and then select **Door Station access Controller** or **Fence Station Access Controller** according to the type of your device.




- The platform automatically creates a room after you add a VTH. For details, see "4.6.4 Configuring Room".
- Any configuration modification on the device will not be reported to the platform. You need to go to the device modification page of Web Manager to manually synchronize the modification.

4.6.2 Call Management


Create call group, management group and relation group respectively and define restricted call relations. This function is only available for administrators.



Click  on the page of call group, management group or relation group, the system will restore management group and relation group to their original status.

4.6.2.1 Configuring Call Group



Only devices in the same call group can call each other.

- A call group will be automatically generated after you add to the platform a VTO or access control device that supports intercom. All VTHs in the same unit will also be automatically added to the group, then the devices in the group can call each other.
- A call group will be automatically generated after you add a second confirmation station to the platform. Add the VTHs in the same house to the group, then the second confirmation station and the VTHs can call each other.
- A call group will be automatically generated after you add a fence station to the platform. All the VTHs on the platform will be automatically added to the group by default, then the fence station and the VTHs can call each other. You can also click  to edit the VTHs in the group, so that the fence station can only call certain VTHs.
- After added to the platform, VTHs will be automatically added to corresponding groups if they are associated with VTOs, second confirmation stations, or fence stations, so that they can call each other.

4.6.2.2 Adding Manager Group

Divide administrators into different groups and link them to call groups in different combinations. This is useful when certain administrators can only answer calls from certain devices. Administrators include VTS and users with permissions to use the video intercom function and operate the devices. VTS will be automatically added to the default manager group after added.


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Video Intercom**.
- Step 2** Click .
- Step 3** Click **Manager Group Config**.
- Step 4** Click **Add Group**.
- Step 5** Enter group name, select administrator account or VTS, and click **OK**.
The added management group is displayed in the list.



- To transfer members, click and move the member to other groups.
- To manage group members, click to add or delete group members.

Figure 4-42 Edit manager group



4.6.2.3 Configuring Relation Group

Background Information

Link call groups and manager groups, and VTOs or VTHs in a call group can only call administrators or VTSs of a linked manager group. There are 2 types of relations:

- A call group links to 1 manager group.
All online administrators in the manager group will receive the call when any device is calling. If an administrator answers, it will stop ringing for other administrators. The call will only be rejected if all administrators reject it.
- A call group links to multiple manager groups.
Priorities vary for different manager groups. When any device is calling, all online administrators in the manager group with the highest priority will receive the call first. If no one answers for 30 seconds, then the call will be forwarded to the manager group with the second highest priority. If still no one answers, the device will prompt that there is no response for the call.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Video Intercom**.
- Step 2** Click .
- Step 3** Click **Relation Group Config**.

- Step 4** Click **Add**.
- Step 5** Enter the group name, and then select one or more call groups and manager groups.

Figure 4-43 Add a group relation



Because only up to 2 manager groups will receive a call, we recommend you select no more than 2 manager groups.

- Step 6** Click or to adjust priorities of the manager groups, and then click **OK**. The upper manager group has higher priority.

4.6.3 Configuring Building/Unit and Call Mode

Background Information

Make sure the status of building and unit of the DSS client is the same as the VTO. If building and unit are enabled on the platform, they must also be enabled on the device, and vice versa; otherwise, the VTO will be offline after being added. That also affects the dialing rule. Take room 1001 unit 2 building 1 as an example, the dialing rule is as follows:

- If building is enabled while unit is not, the room number is "1#1001".
- If building is enabled, and unit is enabled as well, the room number is "1#2#1001".
- If building is not enabled, and unit is not enabled either, the room number is "1001".

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click and then in the **App Config** section, select **Video Intercom**.
- Step 2** Click .
- Step 3** Enable or disable building and unit as required, and then click **OK**.



This configuration must be the same as the device configurations. Otherwise, information of the devices might be incorrect. For example, if only **Building** is enabled on a VTO, you must only enable **Building** on the platform.

Step 4 Configure the call mode.

- **Simultaneous Call:** When a room is being called, all the VTHs and App users in it will receive the call. If there are only App users in the room, then all App users will receive the call.
- **Group Call:** When calling a room, only the VTHs in it will receive the call. If call forwarding is enabled on the VTHs, then all App users will receive the call.

Step 5 Click **Save**.


4.6.4 Configuring Room

Add a room to include the VTHs and App users in it.

Background Information

When you add a VTH to the platform, the platform will automatically create a room. You can also create a room and add the VTH later. The VTH will automatically join the corresponding room. The rooms that are automatically created cannot be deleted. You can only delete those that are manually created.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Video Intercom > Room Config**.





Step 2 Click **Add**.

Step 3 Select an organization, enter a name for the room and the room number, and then click **Add**.

If the VTH with the same room number has been added to the platform, or the homeowner with the same room number has registered, the VTH or the App user will join the room automatically.

Related Operations

Operations on the App users:



- : Set an App user to be the homeowner after it is linked with a person.
- : Reset the password of an App user. The App user will need to log in to the App with the new password.
- : Link an App user to a person.
- : Delete an App user.

4.6.5 Synchronizing Contacts

Synchronize contacts information to VTO and then you can view contacts on the VTO or its web

page.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Video Intercom**.
- Step 2 Click .
- Step 3 Select an organization node (VTO), and then click **Send Contacts**.
- Step 4 Select one or more VTHs as needed, and then click **OK**.
Now you can view contacts on the VTO or web page.




4.6.6 Setting Private Password

Set room door passwords so that the room door can be opened by entering password on the VTO (outdoor station).



Make sure that contacts are sent to the VTO; otherwise you cannot set private password.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Video Intercom**.
- Step 2 Click .
- Step 3 Select a VTO, and then you can see all the VTHs linked to this VTO.
- Step 4 Select a VTH and click , or select several VTHs and click **Change Password**.
- Step 5 Enter password, and then click **OK**.
You can use the new password to unlock on the VTO.




The format should be **room number + private password**, and the room number consists of 6 digits. For example, a person who lives in 1001 with the private password of the VTO in the building being 123456, can enter **001001123456** to unlock the door.

4.6.7 QR Codes

Configure the information of the QR codes that are used by homeowners to download the App and register an account.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Video Intercom > QR Codes**.
- Step 2 Enter a name and some notes for your community, and then click **Save**.
Homeowners can scan the **QR Code for App Download** to download and install the App on the phone, and then scan the **QR Code for App Registration** to register. For how to register, see the user manual of the App.


4.6.8 App User

You can view information of App users, freeze user, modify login password and delete user.

Prerequisites






App users have registered by scanning the QR code on the platform or the VTH. For details, see the user manual of the App.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Video Intercom**.

Step 2 Click .


Table 4-15 Parameter description

Operation	Description
Freeze APP user	The App user cannot log in for 600 s after being frozen. The account will be frozen when invalid password attempts exceeds 5 by an App user.
Change APP user login password	Click  and enter a new password on the Reset Password page, and then click OK .  <ul style="list-style-type: none"> The password must be 8 to 16 characters and include numbers and letters. Click  to display password, or  to mask password.
Refresh the list of App users	Click Refresh to display the App users that recently registered.
Delete APP user	Click  to delete App users one by one, or select multiple App users, click Delete , and then follow the instructions to delete the users.

4.7 Granting Lift Control Permissions in Batches

We recommend you use this method if you need to configure lift control permissions for a large number of people.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Lift Control**.

Step 2 Click **Add**, and then configure the information of the lift control permission group.

Table 4-16 Parameter description

Parameter	Description
Name of Lift Control Permission Group	We recommend you set a name that clearly displays its permissions, such as Building 1.






Parameter	Description
Lift Control Device	Select the lift controllers and floors that this group can access.  Only administrators can edit the device information.
Roles Allowed Access	Only the roles and their users can access and edit this group.  Click  to see the users assigned with the roles.

Figure 4-44 Group information



Step3 Click **OK**.

Step4 Click  and select people to grant them access to the lift controllers in batches.

- Add people by person groups. This is the most efficient way, provided that you have created person groups based on the access permissions. For details, see "4.3.2 Configuring Personnel Information".
Click **Add by Person Group**, select one or more groups, and then click **OK**. You can also select **Include Sub Groups** to include the people in the sub groups of the groups you select.
- Select the people you want to add. This is applicable to people in different person groups have the same access permissions.
Click **Add by Person**, select the people you want to add, and then click **OK**.

4.8 Attendance Management

Configure attendance devices, attendance shifts and periods, so as to manage attendance records and reports.

4.8.1 Preparations

Make sure that the following preparations have been made:

- Attendance devices are correctly deployed. For details, see the corresponding user’s manuals.
- Basic configurations of the platform have been finished. To configure, see "3 Basic Configurations".
 - ◊ When adding attendance devices on the **Device** page, select **Access Control** as the device category.
 - ◊ Personnel information is added correctly. For details, see "4.3.2 Configuring Personnel Information".

4.8.2 Configuring Attendance Terminal

Make sure that access controller is used as the attendance device for check-in and check-out, recording attendance information, and uploading attendance data.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Attendance**.
- Step 2** Select **Attendance Config > Attendance Terminals**.

Figure 4-45 Attendance terminal



- Step 3** Select access control channels, and then click **Save**.



You can enter keyword and search for devices.

4.8.3 Configuring Statistics Rule

The smallest timing unit of swiping card is minute. Seconds will be rounded up or down. For example, if you swipe your card at 09:00:01 and the rule is set to round down, then the time of you swiping the card is 09:00; if the rule is set to round up, then the time of you swiping the card it is 09:01.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Attendance**.
- Step 2** Click , on the left, and then select **Statistics Rule**.

Figure 4-46 Statistical rule



- Step 3** Select a rule, and then click **Save**.

4.8.4 Configuring Attendance Period

Set attendance period, which can be used as time evidence to judge if a person is late, on time, or leaves early.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Attendance**.
- Step 2** Click .
- Step 3** Click **Add** on upper-left corner of the page.
- Step 4** Set parameters of attendance period.
- Fixed attendance requires you to sign in and sign out during the fixed hours. Click  to add another working period. You can set up two working periods at most.

Table 4-17 Fixed attendance parameters


Parameter	Description
Period Name	Custom period name, used to recognize period, such as early shift and night shift.
Color	Set corresponding color of period, and corresponding color will be directly displayed on calendar when making shift for personnel, and quickly identify shift information.
Attendance Mode	Set as Fixed Attendance .

Parameter	Description
Work Time	Set corresponding working hour of period. Attendance time supports cross-day, but not exceeds 24 hours. One attendance period supports max two types of attendance time.
Work Hours	Fill in according to actual situation.
Valid Check-in Time	<p>If working time is set from 09:00 to 18:00, then valid sign-in time can be set as 08:00-10:00, valid sign-out time can be set as 16:00-18:00.</p> <p>Configuration rules are as follows:</p> <ul style="list-style-type: none"> The start time of valid sign-in time is earlier than or equal to start working time (09:00), the end time of valid sign-in time should be later than start working time (09:00), earlier than start time of valid sign-out time. If there are several sign-in records within valid sign-in time, then the earliest record is considered as sign-in time. The start time of valid sign-out time is later than the end time of valid sign-in time, earlier than end working time (18:00), the end sing-in time of valid sign-out time is later than or equal to end working time (18:00). If there are several sign-out records within valid sign-out time, then the earliest record is considered as sign-out time.
Valid Check-out Time	<p>If working time is set from 09:00-18:00, then valid sign-in time can be set as 08:00-10:00, valid sign-out time can be set as 16:00-18:00.</p> <p>Configuration rules are as follows:</p> <ul style="list-style-type: none"> The start time of valid sign-in time is earlier than or equal to start working time (09:00), the end time of valid sign-in time should be later than start working time (09:00), earlier than start time of valid sign-out time. If there are several sign-in records within valid sign-in time, then the earliest record is considered as sign-in time. The start time of valid sign-out time is later than the end time of valid sign-in time, earlier than end working time (18:00), the end sing-in time of valid sign-out time is later than or equal to end working time (18:00). If there are several sign-out records within valid sign-out time, then the earliest record is considered as sign-out time.
Must Check In	If you set two working time, then the second working time can cancel sign in, you don't have to sign in when you work at the second working time, and the start time of working time can be used as sign-in time.
Must Check Out	If you set two working time, then the first working time can cancel sign in, you don't have to sign out when you finish work at the second working time, and the end time of working time can be used as sign-out time.
Allowed Late Check-in Time (min)	Define the rules for being late, absence and early leave. Take the values in the snapshot as an example.
Allow Early Check-out Time (min)	<ul style="list-style-type: none"> Check in on time: Check in no later than 5 minutes. Later: Check in 5 minutes later, but no later than 30 minutes.
Absence Time On Duty _ min later.	<ul style="list-style-type: none"> Absence: Check in 30 minutes later or check out 120 minutes earlier.

Parameter	Description
Absence Time On Duty _ min earlier.	<ul style="list-style-type: none"> • Leave on time: Check out no earlier than 5 minutes. • Leave earlier: Check out 5 minutes earlier, but no earlier than 120 minutes. • Overtime: Check out 60 minutes later.
Overtime Off Duty _ min later.	Define overtime rule. If it is set to 120 minutes, off duty check-out time is later than end time of working time, and period >120 minutes, then it is recorded as overtime, overtime period is Period- 120 minutes .

- Flexible attendance just calculates whether the daily working hours of a person meets the rule according to the sign-in/out time.

Table 4-18 Free attendance parameters

Parameter	Description
Period name	Custom period name, used to recognize period, such as flexible attendance.
Attendance mode	Set as Flexible Attendance .
Color	Set corresponding color of period, corresponding color will be directly displayed on calendar when making shift for personnel, and quickly recognize shift information.
Work Time	Set the period you must work in a day.
Working Hours	Set how many hours you have to work a day. For example, if you set 8, then it means you are required to work 8 hours.
Valid Check-in Time	Sign in after restricted time is recorded as late.
Valid Check-out Time	You are required to sign out before the designated time, otherwise no sign out is recorded.
Must Check In/Out	You must check in or check out within the defined period.  If you have configured 2 or more attendance periods, you can select which within period people must check in or out.
Minimum OverTime Work (Hours)	For example, working hour is 8 hours a day, and if you work overtime for 2.5 hours, then it is recorded as overtime, then you can set 10.5 here.
Cumulate Time For Every Two Punches. Minimum Time Interval Between Every Two Punches (Minutes)	Swipe card at odd number is recorded as check-in. For example, the first card-swiping is check-in. Swipe card at even number is recorded as check-out. For example, the second card-swiping is check-out. It is recorded swiping the card twice when the interval of two continuous card swiping is larger than the defined value.

Step 5 Click **Save**.



If attendance period is already applied to attendance shift, then before deleting attendance period, go to **Attendance Shift**, disable the attendance period in the attendance shift, and then delete the attendance period you want.

4.8.5 Configuring Holiday Plans

Set holiday time to determine overtime type.

Procedure



- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Attendance**.
- Step 2 Click .
- Step 3 Click **Add** on the upper-left corner.
- Step 4 Configure the information.

Figure 4-47 Add a holiday

Table 4-19 Holiday parameters

Holiday mode	Description
Fixed Date	Set some specific date as holiday. For example, set May 1, 2019 (Labor's day) as holiday, and lasts for 1 day, then set Start Date as May 1, 2019 and Holiday Days as 1.


Holiday mode	Description
Date Cycle	If the holiday is the fixed weekday of some week in some specific month, and it cycles according to year, which can be configured as date cycle. For example, if you want to set Mother's Day as holiday, and it lasts for 1 day, then you can set Start Date as the second Sunday in May, and Holiday Days as 1.
Year Cycle	If the holiday is fixed date and it cycles according to year, which can be configured as year cycle. For example, set New Year's Day as holiday, and it lasts for 1 day, then you can set Start Date as January 1 and Holiday Days as 1.


Step 5 Click **Save**.

4.8.6 Configuring Attendance Shift

Set attendance shift according to attendance period, used for department and personnel shift.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Attendance**.

Step 2 Click .

Step 3 Click **Add** on the upper-left corner of the page.

Step 4 Set shift details, select a day, and then click **Apply** to arrange attendance period for the day.

Figure 4-48 Configure attendance shifts

Shift Name: Cyclic Mode:

Cyclic Period (Days):

Daily cycle. Start from day 1.

Day 1	Day 2	Day 3	Day 4	Day 5	Day 6	Day 7
▼	▼	▼	▼	▼	▼	▼
Day 8	Day 9	Day 10	Day 11	Day 12	Day 13	Day 14
▼	▼	▼	▼	▼	▼	▼
Day 15	Day 16	Day 17	Day 18	Day 19	Day 20	Day 21
▼	▼	▼	▼	▼	▼	▼
Day 22	Day 23	Day 24	Day 25	Day 26	Day 27	Day 28
▼	▼	▼	▼	▼	▼	▼
Day 29	Day 30	Day 31				
▼	▼	▼				

Period Name	Time Interval	Opera...
Rest	00:00-23:59	Apply
■ [blacked out]	09:00-18:00	Apply

Table 4-20 Attendance shift parameters

Parameter	Description
Shift Name	Custom period name, used to recognize shift.
Cyclic Mode	Day: Start cycle from the first day, cycle period can be set as any number from 1 to 31 according to day. For example, if you set 2, then the cycle period is 2 days.
Cyclic Period (Days)	Week: There are 7 days in a week by default, it starts cycle from Sunday, and so Sunday is required to be set as the first day. Cycle period can be set as any number from 1 to 4. For example, if you set 2, then 2 weeks can be a cycle period. Month: There are 31 days in a month by default, it starts cycle from the current day (If the date does not exist, then it will be deleted during shift arrangement), cycle period can be set as any number from 1 to 3 according to month. For example, if you set 2, then 2 months can be a cycle period.

Step 5 Click **Save**.



Delete in-use attendance shift: Go to **Shift Management** > **Person Shift**, check if there are shifts to be deleted; if yes, remove the relation, and then delete.

4.8.7 Shift Management

Arrange shifts for personnel or department. You can also arrange temporary shift for personnel. The shift priority is temporary shift > holiday > personnel shift > department shift.


4.8.7.1 Personnel/Department Shift Arrangement


The operations for personnel shift and department shift are similar. This section takes personnel shift as an example.

Background Information


- If you configure department shift, then all the personnel of the department need to conform to the shift.
- If both personnel and department are configured with shift, then the latest personnel shift shall prevail. For example, after configuring the personnel shift, and the corresponding department is configured as well, then personnel shift is based on the latest department shift.
- If the department where new personnel belong to is configured with shift, then the shift of new personnel should conform to department shift.


Procedure

Step 1 Click  on the **Attendance** page.

Step 2 Click  on the upper-left corner of the page.



- If you need to configure shift for department, click  on the upper-left corner and enter the page of department shift arrangement. The following operation is the same as personnel shift arrangement.

- Click  next to the personnel and you can view the shift details.


Step 3 Select shift personnel, click  to add shift information.

Figure 4-49 Select shifts




Table 4-21 Parameter description

Parameter	Description
Start Time	Set start date and end date of personnel shift. Click the column of Start Time and display calendar, select date and time, and then click OK to complete date setting
End Time	
Shift	Select the one you need. See "4.8.7.1 Personnel/Department Shift Arrangement".

Step 4 Click **Save**.


4.8.7.2 Temporary Shift

Arrange a temporary shift when needed.

Procedure

- Step 1 Click on the **Attendance** page.
- Step 2 Select personnel and date.
- Step 3 Click , and then click **Reset** to select an attendance shift as needed. You can add max. 2 attendance periods and 1 free attendance period.

Figure 4-50 Temporary shift



Step 4 Click **OK** and save shift information.



Temporary shift can be deleted, right-click the date which is configured with temporary shift, and delete temporary shift according to system prompt.

4.9 Visitor Management


After appointment is made on platform, and visitor information is registered, the visitor can have access permission. Access permission is disabled after the visitor leaves.

4.9.1 Preparations

- Access control devices have been added into the platform.
- Basic configurations of the platform have been finished. To configure, see "3 Basic Configurations".

4.9.2 Configuring Visit Settings

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Visitor**.

Step 2 Configure the parameters.

- Automatic visit
Enable the function, and then select the channels as needed. Visitors with appointment can verify their identities on the selected channels without registering.
- Automatic leave
 - ◇ Enable the function, and then select the channels as needed. Visitors who are visiting can verify their identities on the selected channels to end their visits automatically.
 - ◇ Sign out regularly: Expired visits will be automatically ended at the defined time point.
 - ◇ Daily sign-out time: For visitors who do not arrive for their appointment before the daily sign-out time, their appointment will be canceled.
 - ◇ Sign out now: For visitors who missed their appointment when you click this button, their appointment will be canceled.
- Default visitor permissions: Set default access permissions for visitors.
- Email template: You can set up an email template and automatically send emails when visitors make an appointment, arrive for their appointment, and end their visit. You can customize the email subject and content with the visitor information, such as visitor's name and ID number.
- Visitor pass remarks: Customize the content of remarks on a visitor pass.

Figure 4-51 Customize visitor pass remarks





Figure 4-52 Visitor pass remarks



Step3 Click **Save**.

4.10 Parking Lot

Control vehicle entrance and exit control with the functions such as ANPR, number of parking space, alarm, and search. In case the vehicle is not recognized by the ANPR camera, visitors can use VTO to call the management center, and then the management center can remotely open the barriers after verifying the identity of the visitor.

4.10.1 Preparations

Make sure that the following preparations have been made:

- Devices, such as ANPR cameras, parking space detectors, VTOs, barriers, and displays for available parking spaces, are added to the platform.
- Basic configurations of the platform have been finished. To configure, see "3 Basic Configurations".
 - ◇ When adding an ANPR camera, select **Access ANPR Device** as the device category. After you have added ANPR cameras, you can bind video channels to their channels. This is

useful when you have installed other cameras at the entrance to view and record videos of the entire scene, not just the vehicle. You can view video from the bound camera when checking the alarm details. For how to bind channels, see "3.1.3 Binding Resources".

- ◇ When adding an NVR, select **Encoder** as the device category.
- ◇ Select **Entrance ANPR** from **Features** for the corresponding NVR channels.
- ◇ When adding VTO, select **Video Intercom** as the device category.

Also, you need to add the information of people and assign them permissions so that they can use the VTO normally. For details, see "4.3 Personnel and Vehicle Management".



Make sure that the configuration of building and unit on the DSS client is the same as the device. If building and unit are enabled on the platform, they must also be enabled on the device, and vice versa. Otherwise, the VTO will be offline after being added. For details, see "4.6.3 Configuring Building/Unit and Call Mode".

- ◇ Add a screen.
Add a display for available parking space. Select **Display Device** as the device category. Dahua screen and Jiuzhou screen are supported as the display for available parking space.
- ◇ Snapshots taken by ANPR cameras are stored in the **Images and Files** disks. You must configure at least one **Images and Files** disk so that snapshots of vehicles can be normally displayed. For details, see "3.3 Configuring Storage".

4.10.2 Configuring Parking Lot

A parking lot includes parking spaces, entrances and exits, barrier control rules and other information. Link an ANPR camera for recognizing license plates, and a VTO for verifying identities.

4.10.2.1 Basic Information

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Parking Lot > Parking Lot Configuration > Parking Lot Basic Config**.
- Step 2** Click the root node named **Current Site**, and then click **Add**.
- Step 3** Configure the basic information of the parking lot, and then click **Next Step**.

Table 4-22 Parameter description


Parameter	Description
Parking Lot Name	To differentiate from other parking lots.
Enable Parking Space Counting	<ul style="list-style-type: none"> ● Count parking spaces by entering and exiting vehicles: Set up the total and available parking spaces in the parking lot, and then the parking spaces will be automatically counted based on each vehicle that enters or exits the parking lot. ● Count parking spaces using parking space detectors: After parking space detectors are added to the platform and configured, parking spaces will be automatically counted.

Parameter	Description
Fuzzy Match of Entrance & Exit Plate No. Snapshot	<ul style="list-style-type: none"> • First Character Rule <ul style="list-style-type: none"> ◇ 1 character added to the front of the plate number: It will still be considered as a match when an additional character is added to the plate number. For example, AB12345 is recognized as AAB12345. ◇ Missing the first character of the plate number: It will still be considered as a match when the first character is missing from the plate number. For example, AB12345 is recognized as B12345. • Last Character Rule <ul style="list-style-type: none"> ◇ 1 character added to the end of the plate number: It will still be considered as a match when an additional character is added to the end of the plate number. For example, AB12345 is recognized as AB123455. ◇ Missing the last character of the plate number: It will still be considered as a match when the last character is missing from the plate number. For example, AB12345 is recognized as AB1234. • Misread Character Rule: It will still be considered as a match if a character is recognized incorrectly, but the number of characters are correct. For example, AB12345 is recognized as AB12B45. <p> When you enable multiple rules, the platform will check if each rule is satisfied. Only when one or more rules are satisfied will platform consider it to be a match. For example, 1 character added to the front of the plate number, and missing the first character of the plate number are both enabled. When the plate number AB12345 is recognized as AAB12345, it satisfied 1 character added to the front of the plate number, but not missing the first character of the plate number. This will be considered as a match. If the plate number AB12345 is recognized as AB112345, it does not satisfy both rules. This will not be considered as a match.</p>
Auto overwrite when captured vehicle has not existed	If a vehicle entered the parking lot but has not exited, a new entry record will be generated when the vehicle is recognized to have entered again.

Step 4 Configure the entrance and exit points, and then click **Next Step**.



The platform supports up to 60 entrances and exits.


- 1) Click  or **Add Entrance and Exit Point**.
- 2) Enter a name, and then click **OK**.

- 3) If there is an entrance point, click **+** next to **Entrance**.
- 4) Enter a name for the point, select a capture mode, and then add a camera, video intercom device (optional), or information display (optional).

If limited by the surroundings, you can install two cameras for this point, and then set **Capture Mode** to **Dual Camera** to improve the successful rate of recognition number plates.

In **Dual Camera** mode, the vehicles captured by the two cameras within the defined **Dual Camera Coordination Time** will be considered as the same one. You must configure the time properly according to the installation positions of the cameras and the distance between them.

Figure 4-53 Entrance point configuration






- 5) If there is an exit point, click **+** next to **Exit**, and then configure the parameters. The parameters are similar to the ones in **Entrance**. For details, see the steps above.

Step 5 Configure the passing rules, and then click **Next Step**.

- 1) Select a vehicle entrance rule, and then configure the parameters.

Table 4-23 Parameter description

Parameter	Description
Registered Vehicles	<ul style="list-style-type: none"> • Registered Vehicles Access Rule Click Add, and then select By Parking Lot or By Point. By parking lot: The vehicle groups will be added to all entrance and exit points of the parking lot, and the vehicles in these group can enter and exit through any entrance or exit. By point: You can add different vehicle groups to different entrance or exit points. For example, vehicle group is added to East entrance but not South entrance, then the vehicles in the group can only enter the parking lot through East entrance. • Allow Passage When Available Space is 0: After enabled, vehicles are allowed to enter the parking lot even if there are no available parking space. Click  to enable this function for an entrance point.
All Vehicles	<p>All vehicles can enter the parking lot.</p> <ul style="list-style-type: none"> • Vehicles on the Blocklist to Enter: After enabled, vehicles on the blocklist are also allowed to enter the parking lot. • Registered Vehicles Access Rule Click Add, and then select By Parking Lot or By Point. By parking lot: The vehicle groups will be added to all entrance and exit points of the parking lot, and the vehicles in these group can enter and exit through any entrance or exit. By point: You can add different vehicle groups to different entrance or exit points. For example, vehicle group is added to East entrance but not South entrance, then the vehicles in the group can only enter the parking lot through East entrance.

Parameter	Description
Custom	<p>You can customize the passing rule for the entrance.</p> <ul style="list-style-type: none"> For how to configure Registered Vehicles Access Rule and Allow Passage When Available Space is 0, see the content above. All Vehicles: Select a default time template or create a new one, and then any vehicle can enter the parking lot within the specified duration. For how to create a new time template, see "3.1.8 Adding Time Template". Open Barrier by Verification: After enabled, the access permission of a vehicle must be verified, and then an administrator can manually open the barrier for it. If Open Barrier by Card Swiping After Verification is also enabled, the driver can swipe a card, and then the barrier will automatically open if the can verify the driver to be the owner of the vehicle. Open Barrier by Card Swiping Without Verification: The barrier will automatically open if the card has access permission. <p> You can enable Open Barrier by Verification or Open Barrier by Card Swiping Without Verification at the same time.</p> <ul style="list-style-type: none"> Available Parking Space Counting: <p> You must enable parking space counting and select Count parking spaces by entering and exiting vehicles.</p> <ul style="list-style-type: none"> ◇ Count each vehicle as an occupied parking space: The number of parking spaces decreases after a vehicle enters. ◇ Count each unregistered vehicle as an occupied parking space: The number of parking spaces decreases only after a vehicle that is not registered to the platform enters. ◇ Custom: Configure which vehicles in the vehicle groups will be used to calculate parking spaces.



For how to configure vehicle groups, see "4.10.3 Managing Vehicle Group".

- 2) Select a vehicle exit rule, and then configure the parameters.
The parameters are similar to the ones in the entrance. See the previous step.
- 3) Enable **Send Plate No. to Devices**, and then add vehicle groups to the allowlist and blacklist.
Devices can use this information to determine which vehicles to let in when the platform is offline.

Step 6 (Optional) Configure parking space detectors, and then click **Next Step**.



If you do not need to calculate parking spaces by using parking space detectors, you can skip this step and click **Next Step**.

1) Click **Add** or **Add Parking Space Detector**.





You need to add parking space detectors to the platform first. For how to add parking space detectors, see "3.1.2 Managing Device".

2) Select the parking space detectors that belong to this parking lot, and then click **OK**.

Step 7 (Optional) Configure indoor and outdoor parking space available displays, and then click **Save and Exit**.


1) Click **Add**, and then select the displays that belong to this parking lot, and then click **OK**.


2) Click  of an outdoor parking space available display, select the color and what to display when available parking space is 0, and then click **OK**.


3) Click  of an outdoor parking space available display, select a parking space counting mode, and then click **OK**.

If you select **Count parking spaces using parking space detectors**, two options are available:

- **Selected Parking Spaces:** Only count the parking spaces of the parking space detectors you select.
- **Count parking spaces by parking space detectors:** Count the parking spaces from all parking space detectors in this parking lot.

4) Click  of an indoor parking space available display, select the arrow position and the color, and then click **OK**.





5) Click  of an indoor parking space available display, select a parking space counting mode, and then click **OK**.

6) Click  of an indoor parking space available display, configure a parking space counting mode for each direction, and then click **OK**.

If you select **Count parking spaces using parking space detectors**, two options are available:

- **Selected Parking Spaces:** Only count the parking spaces of the parking space detectors you select.
- **Count parking spaces by parking space detectors:** Count the parking spaces from all parking space detectors in this parking lot.

Related Operations

- : Edit the passing rules of the parking lot.
- : Edit the available parking space of the parking lot.
- : Edit the information of the parking lot.
- : Delete the parking lot.

4.10.2.2 Reserved Parking Space

Link a parking space to one or more plate numbers. Alarms will be triggered if vehicles with other plate numbers park in this parking space.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Parking Lot > Parking Lot Configuration > Reserved Parking Space Config**.
- Step 2** Select a parking lot, and then click **Add**.

Figure 4-54 Link a parking space to plate numbers



The screenshot shows a window titled "Add Reserved Parking Space". At the top, there is a dropdown menu for "Select Parking Space ID" with the value "1". Below this is a "Vehicle Group" dropdown set to "VIP" and a search field for "ID/Name/Plate No.". The main area is a table with the following columns: "Plate No.", "Owner Name", and "ID". The table contains 7 rows of data, with the first three rows having their checkboxes selected. The bottom of the window shows "Total 7 Record(s)", a page number "1" in a box, a "20" dropdown for "per Page", and "OK" and "Cancel" buttons.

Plate No.	Owner Name	ID
<input checked="" type="checkbox"/> A88900		
<input checked="" type="checkbox"/> A88898		
<input checked="" type="checkbox"/> A88896		
<input type="checkbox"/> A88894		
<input type="checkbox"/> A88892		
<input type="checkbox"/> A88890		
<input type="checkbox"/> A88888		

- Step 3** Select a parking space you want to link plate numbers to, a vehicle group, and one or more plate numbers, and then click **OK**.

4.10.2.3 Parking Lot Layer

Add a plan view image to the parking lot, and then mark the entrance and exit points, parking spaces, parking space available displays, and monitoring devices on it, so that you can manage the parking lot in an intuitive way. If the parking lot has multiple floor, you can add an image for each floor.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Parking Lot > Parking Lot Configuration > Parking Lot Layer Config**.
- Step 2** Select a parking lot, and then click **Add**.
- Step 3** Enter a name for the layer, upload an image, and then click **Save and Configure Layer**.
- Step 4** Drag an entrance or exit point to the image, and then click **Next Step**.
- Step 5** Drag a parking space to the image, adjust its size and direction, and then click **Next Step**.

Figure 4-55 Mark a parking space



Step 6 Drag a parking space available display to the image, and then click **Next Step**.

Step 7 Drag a channel of a monitoring device to the image, and then click **Next Step**.

Related Operations

- : Edit the marked information on the layer.
- : Edit the name and image of the layer.
- : Delete the layer.

4.10.2.4 Event Parameter

Configure events for a parking lot so that you can receive notifications when alarms are triggered.

Procedure

Step 1 Configure an event, and you need to select **Parking Lot** as the type of event source. For how to configure an event, see "4.1 Configuring Events".

Step 2 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Parking Lot > Parking Lot Configuration > Event Parameter Config**.

Step 3 Select a parking lot, the events that were configured will be displayed on the right. The following events will not be displayed because there are no additional parameters to be configured.

- Blocklist alarm: An alarm will be triggered when a vehicle on the blocklist enters the parking lot.
- Reserved parking space alarm: An alarm will be triggered when a vehicle parks in a parking space, but its plate number is not linked to the parking space.
- Parking overline: An alarm will be triggered when a vehicle crosses a line after it is parked.

Step 4 Click to configure an event.

Table 4-24 Parameter description

Parameter	Description
Parking Overtime	<ul style="list-style-type: none"> • Overtime Parking Threshold: The unit is minute. Alarm will be triggered if a vehicle has parked for longer than the defined value. • Detection Interval: How long the platform will check which vehicles have parked overtime. For example, select 5 minutes, then the platform will check whether there are vehicles that have parked overtime in the parking lot. If yes, then an alarm will be triggered. • Vehicles to Trigger Alarms: <ul style="list-style-type: none"> ◇ All Vehicles: All vehicles will trigger alarms if they park overtime, but VIP vehicles are not included. If you enable Include VIP Vehicles, VIP vehicles will also trigger alarms when they park overtime. ◇ Non-registered Vehicle and Vehicle in the Blocklist: The vehicles whose information is not registered to the platform will trigger alarms when they park overtime. ◇ Custom: Enable Non-registered Vehicle, and then the vehicles whose information is not registered to the platform will trigger alarms when they park overtime; enable Registered Vehicle and add vehicle groups, and then the vehicles in these groups will trigger alarms when they park overtime. <p style="text-align: center;">🔑</p> <p style="text-align: center;">You can enable Non-registered Vehicle and Registered Vehicle at the same time.</p>
No Entry and Exit Record	<ul style="list-style-type: none"> • No Entrance/Exit Record Duration: The unit is day. If a vehicle has not entered or exited the parking lot for longer than the defined duration, then an alarm will be triggered. • Statistical Time Point: The platform will start calculating the duration of a vehicle that has not entered or exited the parking lot on the defined time. • Entrance and Exit Vehicle Group of Interest: Only calculate the duration for the vehicles in the vehicle groups that are added.

4.10.2.5 Vehicle Finder


Enable vehicle search for parking lots, so that vehicle owners can find where their vehicles are parked through the vehicle search system.

Prerequisites

Parking space detectors have been configured for the parking lot. They are used to provide exact

locations of vehicles.

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Parking Lot > Vehicle Search Config**.

Step 2 Click **Add**, and then configure the parameters.



Table 4-25 Parameter description

Parameter	Description
Rule Name	Enter a name for the rule.
Enable Status	If enabled, the rule will be effective immediately after added.
Parking Lots Allowed to be Searched for	Select the parking lots you want to enable vehicel search for.
Upload Vehicle Search Interface Logo	You can customize the logo on the page of the vehicle search system. The logo must not exceed 256 KB.

Step 3 Click **Add**.

If the platform is working on 2 network cards, the rule will generate multiple links and QR codes that match with each other. They are used to access the vehicle search system in different networks. Hover the mouse on  to view the details of each link.

Related Operations

- Click  to copy the link, and then you can use it visit the vehicle search system in a browser.
- Click  to view QR codes. Vehicle owners can scan them with their phones to visit the vehicle search system. You can download the QR codes to your computer, or send them to a defined email address.


4.10.3 Managing Vehicle Group

Add vehicles to different groups, so that you can quickly apply different parking lot functions to multiple vehicles at the same time.

Background Information


General, VIP, and blacklist are the default groups. If you need to use them, you can directly add vehicles to them.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Parking Lot > Vehicle Groups**.

Step 2 Click **Add**.

Step 3 Enter a name and select a color for the group, and then click **Add**.

Step 4 Click  of a group, or double-click a group and click **Select from Vehicle List**, select the vehicles that you want to add to the group, and then click **OK**.

4.11 Intelligent Analysis

Before using the people counting and scheduled report functions, you must configure them first.

- **People counting:** Create a people counting group and add multiple people counting rules from one or more devices to it. Then, you can view the real-time and historical number of people of the group.
- **Scheduled report:** Configure the when to send a report with historical people counting data, the email address to send the report to, and the content of the email.

4.11.1 People Counting Group

Create a people counting group, and then add multiple people counting rules from one or more devices. In Intelligent Analysis, you can view the real-time and historical number of people of the group.

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Intelligent Analysis > People Counting Group Config**.
- Step 2** Click **Add** at the upper-left corner.

Figure 4-56 Add a people counting group

- Step 3** Configure the parameters, and then click **Add**.


Table 4-26 Parameter description

Parameter	Description
People Counting Group Name	Name of the people counting group.
Pass No.	The calibration time can only be configured on the hour. It is the start of a counting cycle. <ul style="list-style-type: none"> The number of people staying everyday will be set to the defined value every day on the calibration time. After Pass No. is enabled, the number of people pass by will be displayed. The value will be set to 0 every day on the calibration time by default.
Calibrate Number of People Staying Everyday	
Calibration Time	
Calibrated Number of People	
Calibrate Number of People Staying Now	The number of people staying will be set to the defined value after this group is added. The value will not be calibrated everyday.
Calibrated Number of People	
Limit Number of People	When enabled, you can configure the red and yellow light threshold of the people in the group. <ul style="list-style-type: none"> When the number of people in the group reaches the defined value, the light will turn red. When the number of people in the group reaches the defined value but smaller than the red light value, the light will turn yellow.
Red Light Threshold	
Yellow Light Threshold	
Rule	Select the devices whose people counting rules you want to include in the group, and then their data will be combined together.

4.11.2 Scheduled Report

Historical data will be sent on a regular basis to one or more email address that you set on the scheduled time.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Intelligent Analysis > People Counting Group Config**.

Step 2 Configure one or more types of report.

- Daily report: Data from yesterday will be sent to your email at a defined time. If set to 03:00:00, the data from the day before (00:00:00–23:59:59) will be sent to your email at 03:00:00 every day.
- Weekly report: Data from last week will be sent to your email at a defined time. If set to 03:00:00 on Wednesday, the data from Wednesday to Tuesday of each week will be sent to your email at 03:00:00 every Wednesday.
- Monthly report: Data from last month will be sent to your email at a defined time. If set to 03:00:00 on 3rd, the data from 3rd of last month to 2nd of the current month will be sent to your email at 03:00:00 on 3rd of each month.

Step 3 Configure one or more email addresses to send the report to, and the content of the email.


- 1) Click  to select the users that have been configured email addresses, or enter an email address, and then press Enter.

Figure 4-57 Invalid email address, you must press Enter





Figure 4-58 Valid email address



2) Configure the content of the email.

Step 4 Send the report.


- Click **Send Now** to immediately send the report that you configured.
- Click **Save**, and then the report will be sent at the defined time.

4.12 Synthesis

Use a bridge to import events to the platform from third-party systems, and then use these events to create alarms schemes and perform certain linkage actions. You can also share access control and attendance data with third-party databases, which can be used by third-party personnel to formulate their own reports.

4.12.1 Synchronizing Events

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **Synthesis > Event Sync**.
- Step 2 Click **Add**.



- A bridge serves as a connector between the platform and third-party systems, and is responsible for importing events from a third-party system to the platform. It must comply with the connection protocol between the third-party system and the platform. For different systems, the protocol might vary and you might need to develop a new bridge. Before using this function, make sure the bridge has been deployed and is running.
- You can add up to 5 bridges.

Figure 4-59 Add a bridge

The screenshot shows a dark-themed 'Add Bridge' form. At the top, there is a title 'Add Bridge' and a subtitle 'Bridge serves as a connector integrating this platform with third party systems.' Below this are several input fields: 'Bridge Name', 'Bridge IP/Domain Name', 'Bridge Port', 'Access Key' (with a copy icon), and 'Secret Key' (with a key icon and a copy icon). There is also a 'Remarks' text area. At the bottom, there are three buttons: 'Add' (blue), 'Add and Modify Event Sync' (blue), and 'Cancel' (grey).


Step 3 Configure the parameters.

Table 4-27 Parameter description

Parameter	Description
Bridge Name	Name of the bridge.
Bridge IP/Domain Name	IP address or domain name, and port number of the bridge.
Bridge Port	
Access Key	Automatically generated. Click to copy it.
Secret Key	Automatically generated. <ul style="list-style-type: none"> • Click to verify your password, and then generate a new secret key. • Click to verify your password, and then you can click to copy it.

Step 4 Click **Add** or **Add and Modify Event Sync**.


Figure 4-60 Synchronize events



Step 5 Synchronize incoming trigger events.


- One by one
 - 1) Click **Add**.
 - 2) Enter the code and name of the incoming trigger event.
 - 3) Click **OK**.

Figure 4-61 Enter the code and name of the incoming trigger event




- In batches
 - 1) Click **Import**.

Figure 4-62 Download template



- 2) Click **Download Template**, save the template to your PC, and then enter the information in it.
- 3) Click **Import File**, select the file, and then click **Open**.


Figure 4-63 Synchronize events in batches



Step 6 Synchronize incoming event sources.


- One by one
- 1) Click **Add**.
 - 2) Enter the number and name of the incoming event source.
 - 3) Click **OK**.

Figure 4-64 Enter the code and name of the incoming event source




- In batches
- 1) Click **Import**.

Figure 4-65 Download template



- 2) Click **Download Template**, save the template to your PC, and then enter the information in it.
- 3) Click **Import File**, select the file, and then click **Open**.

Figure 4-66 Synchronize incoming event sources in batches




Step 7 Click **Close** at the lower-left corner.

Related Operations

- : Edit the information of the bridge.
- : Edit the incoming trigger events and event sources.
- : Delete the bridge.
- Add event
 1. Go to **Home** page, click , and then in the **Applications Configuration** section, select **Event**.
 2. Click **Add**.
 3. In the **Event Source section**, select the one you import from the third-party system.

Figure 4-67 Add an third-party event



4. For other parameters, see "4.1 Configuring Events".

4.12.2 Synchronizing Data

You can manually or regularly synchronize data in the platform to third-party databases.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **Synthesis > Data Sync**.
- Step 2** Click **Add**.



You can only add one database.

Figure 4-68 Add a database


Step 3 Select the type of the database, and then enter its name, IP address, port, username and password.



Click **Test**. If the connection is through, the system will prompt that it connects to the database successfully.


Step 4 Click **Next Step**.

Figure 4-69 Synchronize data



Step 5 Click **Add**.

Figure 4-70 Configure parameters



Step 6 Set **Business Module** to **Access Control** or **Attendance**, and then enter the name of the data table in the third-party system.




Each business module can only be added once.

Step 7 Click to select what data to be synchronized. You must disable the data you do not

want to synchronize.

Step 8 Double-click the area under **Third-party System Data Table Field**, enter the corresponding name in the table in the third-party system.


Step 9 Click , and then configure the time to automatically synchronize the data everyday.







You can only configure 4:00–23:00.

Step 10 Click **OK**.

Figure 4-71 Database information



Related Operations

- : Turn on or off automatic synchronization.
 All the data will be synchronized on the first attempt, including after you delete and then add the database again. Only new data will be updated on subsequent synchronizations.
- : Edit the information of the database or the data that is being synchronized. You can view each synchronization result in the log. See "8.1.3 System Log".
- : Synchronize the data immediately.
- : Delete the database.

4.13 Maintenance Center

After configuring video storage detection, you will be prompted if the duration or integrity of recording is abnormal. Also, a scheduled report can be sent at the defined time to one or more email addresses to keep the persons updated of the status of the platform. The information in the report can include channel status, device status, server status, hard disk status, fault status, and abnormal videos.

4.13.1 Configuring Video Storage Detection


The platform will continue to check the duration and integrity of the videos. You will be prompted if the one of them is abnormal. For example, 30 days of duration and video integrity have been configured for channel A. If there are only 24 days of video, or the video does not last for 24 hours on

any day, the platform will give corresponding prompts.

Prerequisites

Recording plans have been configured for channels and videos have been recorded.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Maintenance Center > Video Storage Detection Config..**
- Step 2** In the **Video Storage Detection Config** section, select channels, and then configure the number of days of video.
You can also enter a number in the **Days to Record Videos in Batches Config** input box, and then click **Apply**. The number of days will be applied to all selected channels.
- Step 3** In the **Detection of Video Completion Status**, select channels.
- Step 4** Click **OK**.

Related Operations

You can view the detection results when viewing the detailed information of a device in **Maintenance Center**. If the duration of video is not enough, the number of days will be displayed in red. If the duration of video for a day is less than 24 hours, the integrity status will be abnormal.


Figure 4-72 Video duration and integrity status

Channel Name	Channel Type	Channel Online/...	Chanel ...	Recording ...	Video Integ...	Storage ...	Latest Status Change
48-onvif_1	Video Channel	Online	Normal	5	⊙	Centre Storage	2022-11-15 14:59:19
48-onvif_2	Video Channel	Online	Normal	2	⊙	-	2022-11-15 14:59:19
48-onvif_3	Video Channel	Online	Normal	-	⊙	Centre Storage	2022-11-15 14:59:19

4.13.2 Configuring Scheduled Report

Configure a period so that the platform will regularly send data on how the system is running to the defined email addresses, including server status, device status, and faults.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **App Config** section, select **Maintenance Center > Scheduled Report Config**.
- Step 2** Configure one or more types of report.
- Daily report: Data from yesterday will be sent to your email at a defined time. If set to 03:00:00, the data from the day before (00:00:00–23:59:59) will be sent to your email at 03:00:00 every day.
 - Weekly report: Data from last week will be sent to your email at a defined time. If set to 03:00:00 on Wednesday, the data from Wednesday to Tuesday of each week will be sent to your email at 03:00:00 every Wednesday.
 - Monthly report: Data from last month will be sent to your email at a defined time. If set to 03:00:00 on 3rd, the data from 3rd of last month to 2nd of the current month will be sent to your email at 03:00:00 on 3rd of each month.
- Step 3** Select a format of the report, including Excel or PDF.
- Step 4** Select the type of information to be included in the report.
It includes server status, device status, and faults.

- Step 5** Configure one or more email addresses to send the report to, and the content of the email.
- 1) Click **+** to select the users that have been configured email addresses, or enter an email address, and then press Enter.

Figure 4-73 Invalid email address





Figure 4-74 Valid email address



- 2) Configure the content of the email.

Step 6 Send the report.

- Click **Send Now** to immediately send the report that you configured.
- Click **Save**, and then the report will be sent at the defined time.

5 Businesses Operation

5.1 Monitoring Center

The monitoring center provides integrated real-time monitoring applications for scenarios such as CCTV center. The platform supports live video, license plate recognition, target detection, access control, emap, snapshots, events, video playback, video wall, and more.

5.1.1 Main Page

Provides frequently used functions such as video and event and alarm.


Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.

Figure 5-1 Monitoring center




Table 5-1 Interface description

No.	Parameter	Description
1	Favorites and device tree	<ul style="list-style-type: none"> List of resources including devices, POS channels, browser, and maps. You can search for a device or channel in the search field. Fuzzy search is supported so that you can simply enter part of the name and then select the exact one from the provided name list. Add, delete or rename the favorites. You can also tour the channels in favorites.

No.	Parameter	Description
2	View	<ul style="list-style-type: none"> Save the current view of window split and video channels in the live view section, and name the view. You can directly select the view from the View tab to display it quickly next time. Channels under a view or view group can be displayed by tour (in turn). You can set the tour interval to be 10 s, 30 s, 1 min, 2 min, 5 min or 10 min. Maximum 100 views can be created.
3	PTZ	PTZ control panel.
4	Save view	Click to save current video window as a view.
5	Close all windows	Close all windows in live view.
6	Channel control	Control the door channels in live view.
7	Real-time videos	Drag a channel to the windows and view its real-time video.
8	Window split mode and full screen	<ul style="list-style-type: none"> Set window split mode. Supports 1, 4, 6, 8, 9, 13, 16, 20, 25, 36 or 64 splits, or click to set a customized split mode. If the live-view channel number is more than the number of current windows, then you can turn page(s) by clicking at the bottom of the page. Switch the video window to Full Screen mode. To exit Full Screen, you can press the Esc key or right-click on the video and select Exit Full Screen.
9	Event panel button	Display or hide the event panel.
10	Event and alarms	Events and alarms.
11	Live view and playback	<ul style="list-style-type: none"> Live view: View real-time videos. Playback: View recordings. See "5.1.3 Playback".

5.1.2 Video Monitoring

View live videos. For ANPR and face cameras, you can view information of ANPR, face detection and face recognition. For video metadata cameras, you can view metadata information.



5.1.2.1 Viewing Live Video

View the live video of connected devices.



This section only introduces viewing live video. For POS live view, see "6.4 POS". For map live view, see "4.2 Configuring Map".


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then click **Monitoring Center**.
- Step 2** Click .
- Step 3** View real-time video.

You can view live video in the following ways:

- Double-click a channel or drag the channel from the device list on the left to one window on the right.
- Double-click a device to view all channels under the device.
 - Right-click a node, select **Tour**, and then set tour interval. The channels under this node will play in turn according to the defined interval.
 - ◇ If the number of splits in the window is more than the number of online channels, video of all channels will be displayed in the window. Otherwise, click 1/6 on the top of the page to turn pages.
 - ◇ Close the on-going tour before starting live view.

Figure 5-2 Live view



Step 4 You can perform the following operations during live view.

- Display intelligent snapshots.

When viewing live video of face detection cameras, face recognition cameras, ANPR cameras, or target detection cameras, right-click the monitoring image, and then select **Start Picture Overlay**. The snapshot will be displayed on the upper-right corner of the live window. If no more images are captured, a snapshot will be displayed up to 5 s by default, and it will disappear after 5 s.

Point to the live window, and then select type of images to be displayed.
- Point to the video window, and then you can see the shortcut menu on the upper-right corner.

Figure 5-3 Live window





Table 5-2 Parameter description

Icon	Name	Description
	Instant playback	Open/close instant playback.
	Audio	Open/close audio.
	Audio communication	Open/close two-way audio.
	Local record	Click it, and then the system begins to record local file and you can view the record time on the upper left. Click again, and then system stops recording and saves the file to your PC. The recorded video is saved to ..\DSS\DSS Client\Record by default. To change the storage path, see "8.3.5 Configure File Storage Settings".
	Snapshot	Take a snapshot. The snapshots are saved to ..\DSS\DSS Client\Picture by default. To change the snapshot storage path, see "8.3.5 Configure File Storage Settings".
	Close	Close the video.


- Sleep function is supported for IPCs that use 4G mobile network to communicate and are solar-powered.
 - ◇ When the device is asleep, you can click to wake it up.

Figure 5-4 Wake up the device



- ◇ The device will regularly request to sleep to save battery. When you are viewing its live video, the device will request to sleep every 2 minutes. When you are not viewing its live video, the device will request to sleep every 1 minute. You can accept or reject so that you can continue to watch live video. When rejecting the request, you can choose whether to delay the next request from the device.

Figure 5-5 Request to sleep from the device



- Right-click the live video, and then the shortcut menu is displayed.



The menu varies depending on device functions.

Figure 5-6 Live video operation menu






Table 5-3 Description


Parameters	Description
Audio Input Selection	If the camera has more than one audio input channels, you can select one or select the mixed audio. This configuration is effective with both live view and playback.
Start Remote Recording	Record the audio and video in the current window. If a channel already has a center recording plan, you cannot start remote recording. If a video storage disk is configured on the platform, the videos will be saved to the platform server.
Continuous Snapshot	Take snapshots of the current image (three snapshots each time by default). The snapshots are saved to <code>..\DSS\DSS Client\Picture</code> by default. To change the snapshot storage path, see "8.3.5 Configure File Storage Settings".
Stream Type	Select stream type as required. Generally, main stream requires the most bandwidth, and sub stream 2 the least. The smaller the bandwidth is required by the stream, the smoother the video image.

Parameters	Description
Play Mode	<ul style="list-style-type: none"> • Real-Time Priority: The video is in real-time, but video quality might be reduced. • Fluency Priority: The video is fluent, but video lagging might occur. • Balance Priority: Real-time priority or fluency priority, depending on actual conditions. • Custom: Configure the video buffer time from Local Settings > Video. The larger the value, the more stable the video quality.
Video Adjustment	Adjust the brightness, contrast, saturation, and chroma of the video for video enhancement.
Digital Zoom	Click it, and then click and hold the video image to zoom in on the image. Right-click the image, and then select Digital Zoom again to exit zooming in.
Window Mode	<p>Divide one window into 2 (1+1 mode), 4 (1+3 mode), and 6 (1+5 mode). One window will play the real-time video, and the others play different defined areas of the real-time video.</p> <p>If a device supports target tracking, you can enable this function in any window mode, the windows that play defined areas of the real-time video will follow the target when detected, until it disappears.</p>
AI Overlay	<p>Displays rule lines, bounding box on targets, and detection area for intelligent rules, except for motion detection. After enabled, the configuration will be saved, and only works on the current channel in the live view and playback.</p>  <p>AI overlay information is not displayed by default.</p>
SMD Overlay	Displays the bounding box on targets. After enabled, the configuration will be saved, and only works on the current channel in the live view and playback.
Disable Privacy Masking	For a camera that supports privacy masking of human face, you can disable the masking here to view the face image.
Alarm Output Control	Turn on or turn off alarm output channels.
Audio and Light Control	You can turn on or off the audio and light channels one by one or at the same time.
Add to Favorite	You can add the active channel or all channels into Favorite.
Set as Alarm Window	When selecting open alarm linkage video In Preview (in live window) from Local Settings > Alarm , then the video will be displayed on the window which is set to alarm window. If multiple alarms are triggered, the video linked to the latest alarm will be opened. If the number of alarm windows is fewer than the number of linkage videos, the video linked to the earliest-triggered alarm will be opened. After enabling Set as Alarm Window , the window frame is displayed in red.

Parameters	Description
Fisheye View	 <p>This function is available on fisheye cameras only. When changing the video stream, the fisheye view mode will maintain the current configuration.</p> <p>According to different installation methods, the fisheye view can be varied.</p> <ul style="list-style-type: none"> • In-ceiling mount: 1P+1, 2P, 1+2, 1+3, 1+4, 1P+6, 1+8. • Wall mount: 1P, 1P+3, 1P+4, 1P+8. • Ground mount: 1P+1, 2P, 1+3, 1+4, 1P+6, 1+8.

- To view real-time temperature of a point on the thermal camera view, hover over that point.

Figure 5-7 View temperature



- If a channel supports electronic focus, you can enable electronic focus for it on the platform to adjust video definition and size.



The page might vary according to the lens types of cameras. Lens types include embedded zoom lens and external CS electronic lens. The following figure is for reference only.

Figure 5-8 Live view








Table 5-4 Description

Parameters	Description
Zoom +/- (for embedded zoom lens)	Zoom in/out. Click or click and hold or , or drag the slider to the left or right to zoom in/out.
Focus +/-	Adjust camera focus to achieve the best video definition. Click or click and hold or , or drag the slider to the left or right to adjust focus.
Auto Focusing (for embedded zoom lens)	Adjust image definition automatically.
ABF (auto back focusing, for external CS electronic lens)	Other focusing operations are unavailable during auto focusing.
Reset	When image definition is imperfect, or after many times of zooming or focusing operations, you can click Reset to reset the lens, so as to eliminate lens deviation.

- **Tour**
On the live view page, right-click a device or node, select **Tour**, and then select an interval. The channels under this device or node will be played in turn at the pre-defined interval. You can also customize the interval.

Figure 5-9 Start tour



- ◇ To view remaining time of a channel during tour, check  00:02.
- ◇ To pause, click .
- ◇ To exit tour play, click .
- Region of interest (RoI)

A window can be divided into 4 or 6 regions during live view. One area is used to play live video and other regions are used to zoom in regional image.

On the live view page, right-click the window, select **Window Mode**, and then select a mode. For example, select a 1+3 mode.



To exit the **Window Mode**, right-click the window and then select 

Figure 5-10 Split mode













Figure 5-11 1+3 mode




- View real-time events.
 - Click  to open the event panel, which displays the real-time alarm events of the channel.
 - ◇ Click the event type on the top of the event panel to view the corresponding event.
 - ◇ Click event record to view the snapshot. Video playback is also supported. Operations related to different events might be different.
 - ◇ : Refreshes events in real time. : Stops refreshing.
 - ◇ Click  to clear the events in the event panel.

- ◇ Click  to quickly view the latest events.
- Remotely unlock the door.

When viewing the access control channel, you can remotely control the status of the door on the upper-right corner: Normally open () , normally closed () , or normal status () . You need to enter the login password of the current user before operation. Restore the door to normal status first, and then the door can be opened and closed according to defined period or through face recognition.

In the video window of the access control channel, you can remotely lock or unlock the door.


Figure 5-12 Lock/unlock the door



- Video intercom.

When viewing the video intercom channel, you can answer or hang up the call.

Figure 5-13 Video intercom



5.1.2.2 View

The current layout and resources can be saved as a view for quick play next time. Views are categorized into different groups, which include three levels: First-level root node, second-level grouping and third-level view. Tour is supported for first-level root node and second-level grouping. The tour time can be 10 s, 30 s, 1 min, 2 min, 5 min, 10 min, or customized (5 s–120 min). Up to 100 views can be created.

5.1.2.2.1 Creating View

Views are categorized into different groups, convenient for management and quick use. Group includes three levels, first-level root node, second-level grouping and third-level view.

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2** Click .
- Step 3** Create a view group.
 - 1) Click the **View** tab.
 - 2) Right-click **View**, select **New Folder**.

Figure 5-14 Create a new folder



- 3) Enter a folder name, click **OK**.

Step4 Create view.

- 1) Customize the window split mode, view real-time videos of channels in the windows, and then click  on the upper-right corner.
- 2) Enter a name for the view, select a view group it belongs to, and then click **OK**.

5.1.2.2 Viewing View

- Live view
On the **Monitoring Center** page, select a view, double-click or drag it to the window to start viewing.
- Tour
On the **Monitoring Center** page, right-click view group or root node, select **Tour** and tour period.

Figure 5-15 Go to video tour page





Figure 5-16 View tour



- ◇ To view remaining time of a channel during tour, check 00:02.
- ◇ To pause, click .
- ◇ To exit tour play, click .

5.1.2.3 Favorites


Add frequently used channels to favorites to realize quick search and call.


5.1.2.3.1 Creating Favorites

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2** Click .
- Step 3** Create favorites.
 - 1) Click .

Figure 5-17 Favorites








- 2) Right-click root node or created favorites, and then select **New Folder**.
 - 3) Enter a folder name, click **OK**.
Lower-level favorites are generated under the selected root node or favorites.
 - 4) Click .
- The system goes back to the device list.

Step 4 Add channels to favorites.

- In the device list, right-click a channel, and then select **Add to Favorite**.
- Right-click the window with live video, and then select **Add to Favorite**.

5.1.2.3.2 Viewing Favorites

- Live view
On **Monitoring Center** page, click , open favorites list, select favorites or channels, double-click or drag to video window and the system starts to play live video.
- Tour
On **Monitoring Center** page, click , open favorites list, select the root node or favorites, select **Tour** and then set duration. The system starts to play the channels in tour.
 - ◇ To view remaining time of a channel during tour, click  00:02.
 - ◇ To pause, click .
 - ◇ To exit tour play, click .

5.1.2.4 PTZ

Operate PTZ cameras during live view on the DSS Client.

5.1.2.4.1 Configuring Preset


A preset is a set of parameters involving PTZ direction and focus. By calling a preset, you can quickly rotate the camera to the pre-defined position.

Procedure

Step 1 On the **Monitoring Center** page, open the video of a PTZ camera.



Step 2 Click .

Figure 5-18 Go to PTZ control panel




Step 3 Click .

Step 4 Add a preset.

- 1) Rotate the PTZ camera to a specific point.
- 2) Click , enter the preset name, and then click .

Related Operations

Call a preset: Click  of a specific preset, and then camera will rotate to the related position.

5.1.2.4.2 Configuring Tour

Set Tour to enable an camera to go back and forth among different presets. Set tour to enable camera to automatically go back and forth between different presets.

Prerequisites


You have added at least 2 presets.

Procedure

Step 1 On the **Monitoring Center** page, open the video of a PTZ camera.

Step 2 Click .

Figure 5-19 Go to PTZ control panel



Step 3 Click

Step 4 Click

Step 5 Add tours.

- 1) Enter tour name, and click .
- 2) Select a preset from the drop-down list on the left.
- 3) Repeat the previous 2 steps to add more presets.
- 4) Click **OK**.

Related Operations

To start tour, click , then camera goes back and forth among the presets.

5.1.2.4.3 Configuring Pattern


A pattern is a record of a consecutive series of PTZ operations. You can select a pattern to repeat the corresponding operations quickly. See pattern configuration instructions as follows.

Procedure


Step 1 On the **Monitoring Center** page, open the video of a PTZ camera.

Step 2 Click

Figure 5-20 Go to PTZ control panel




Step 3 Click .

Step 4 Click , and then operate the 8 PTZ buttons of PTZ to set pattern.

Step 5 Click .

Related Operations

Call pattern: Click , and then the camera will automatically repeat the pattern that you have configured.

5.1.2.4.4 Configuring Scan


The camera automatically scans horizontally at a certain speed.

Procedure

Step 1 On the **Monitoring Center** page, open the video of a PTZ camera.

Step 2 Click .

Figure 5-21 Go to PTZ control panel



- Step 3** Click
- Step 4** Click PTZ button, and rotate PTZ to the left to a position, and then click to set the left boundary.
- Step 5** Continue to rotate PTZ to the right to a position, and then click to set the right boundary.
- Step 6** Click to start scanning, then PTZ will rotate back and forth automatically within the two boundaries.

5.1.2.4.5 Enabling/Disabling Pan

On the **Monitoring Center** page, open the video of a PTZ camera. Click , and then click . PTZ rotates 360° at a specified speed. Click to stop camera rotation.

5.1.2.4.6 Enabling/Disabling Wiper

Enable/disable the PTZ camera wiper. Make sure that the camera supports wiper function. On the **Monitoring Center** page, open the video of a PTZ camera. Click , and then click to turn on wiper. Click to turn off wiper.

5.1.2.4.7 Enabling/Disabling Light

Turn on/off camera light. Make sure that the camera supports light. On the **Monitoring Center** page, open the video of a PTZ camera. Click , and then click to turn on light. After enabling light, click to turn off light.

5.1.2.4.8 Configuring Custom Command


Background Information

Procedure

Step 1 On the **Monitoring Center** page, open the video of a PTZ camera.


Step 2 Click .

Figure 5-22 Go to PTZ control panel



Step 3 Enter your command in the **Command** box.

Figure 5-23 Custom command



Step 4 Click  to show the command functions.


5.1.2.4.9 PTZ Menu

Procedure

Step 1 On the **Monitoring Center** page, open the video of a PTZ camera.

Step 2 Click .

Figure 5-24 Go to PTZ control panel



Step 3 Click .

Step 4 Click .

Step 5 Use the panel to go to the menu configuration page.

Figure 5-25 Go to PTZ menu configuration page




Table 5-5 PTZ menu description

Parameters	Description
	Up/down.
	Left/right. Point to set parameters.
	Click to enable PTZ menu function. System displays main menu on the monitor window.
	Click to close PTZ menu function.
OK	It is the confirm button. It has the following functions. <ul style="list-style-type: none"> • If the main menu has the sub-menu, click OK to enter the sub-menu. • Point to Back and then click OK to go back to the previous menu. • Point to Exit and then click OK to exit the menu.
Camera	Point to Camera and then click OK to enter camera settings sub-menu page. Set camera parameters. It includes picture, exposure, backlight, day/night mode, focus and zoom, defog, and default.
PTZ	Point to PTZ and then click OK to go to PTZ sub-menu page. Set PTZ functions. It includes preset, tour, scan, pattern, rotation, PTZ restart, and more.
System	Point to System and then click OK to go to system sub-menu page. Set PTZ simulator, restore camera default settings, video camera software version and PTZ version.
Return	Point to the Return and then click OK to go back to the previous menu.
Exit	Point to the Exit and then click OK to exit PTZ menu.

5.1.2.5 Fisheye-PTZ Smart Track


Link a PTZ camera to a fisheye camera so that when the fisheye camera detects a target, the PTZ camera automatically rotates to it and track.

5.1.2.5.1 Preparations

Make sure the following preparations have been completed:

- Fisheye camera and PTZ camera are well deployed. For details, see corresponding user's manuals.
- Basic configurations of the platform have been finished. For details, see "3 Basic Configurations".
 - ◇ When adding cameras, select **Encoder** from **Device Category**.
 - ◇ **Features** of fisheye camera is set to **Fisheye**. For details, see "3.1.2.5.2 Modifying Device Information".

Figure 5-26 Set fisheye camera features



5.1.2.5.2 Configuring Fisheye-PTZ Smart Track

Procedure





- Step 1** Log in to the DSS Client. On the **Home** page, click , and then click **Monitoring Center**.
- Step 2** Click .
- Step 3** In the device tree on the left, right-click a fisheye camera, and then select **Modify Smart Track**.
- Step 4** Click  next to **Please select a PTZ camera to link**, and then select a PTZ camera.

Figure 5-27 Set smart track rules (1)







- Step 5** Click  and then move the  of the fisheye on the left to select a position. Click  of the PTZ camera to find the position. Adjust the PTZ camera to find the position and move the PTZ to the center position (The green cross on the image).

Figure 5-28 Set smart track rules (2)



- Select 3-8 mark points on fisheye camera.
- When you find mark point on the right side of the PTZ camera, click to zoom out PTZ.
- Click to 3D position, and when you click a certain point on the left side of PTZ camera, it will automatically move to the center.

Step 6 Click to save the calibration point.

See above steps to add at least three calibration points. These three points shall not be on the same straight line.


Step 7 Click **Save**.

5.1.2.5.3 Applying Fisheye-PTZ Smart Track

Procedure

Step 1 Log in to the DSS Client. On the **Monitoring Center** page, select the fisheye camera on the device tree and then right-click to select **Smart Track**.

Figure 5-29 Select a smart track channel



Step 2 Click any point on the left of fisheye, PTZ camera on the right will automatically rotate to corresponding position.

5.1.3 Playback

Play back recorded videos.

5.1.3.1 Page Description

Log in to the DSS Client. On the **Home** page, click , and then click **Monitoring Center**. Click the **Playback** tab.

Figure 5-30 Playback page




















Table 5-6 Description

Icon	Description
	Lock the video stored to the server within some period of designated channel. Locked video will not be overwritten when disk is full.
	Cut video
	Download video
	Filter video according to record type.
	Make dynamic detection analysis over some area of the record image, and it only plays back the video with dynamic image in the detection area.
	Play multiple recorded videos from the same time. For example, you are playing recorded videos from 3 channels at the same time. Select channels, configure when you want to play the recorded video from, and then click this icon. All 3 channels will play recorded videos from the same time.
	Stop/pause playback
	Frame by frame playback/frame by frame backward.
	Fast/slow playback. Max. supports 64X or 1/64X.
	During playback, you can drag time progress bar to play back record at the specific time.
	Select the storage location of the video to be searched. Supports searching for the video on the platform server or storage device.
	Tag records.
	Lock records.

5.1.3.2 Playing Back Recordings


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2** Click the **Playback** tab.
- Step 3** Select a channel from the device tree, and then double-click it, or drag it to the window.
- Step 4** Select the storage path of recorded video from , and then click  to select the date.



Dates with blue dot means there are recordings.

Figure 5-31 Playback page






Step 5 Click  to play the video.

Step 6 Hover over the video, and then the icons appear. You can perform the following actions.

Figure 5-32 Video playback



Table 5-7 Description

Icon	Name	Description
	Take a recording on the device	Click this icon to start recording. The recorded video is stored locally. The saving path is C:\DSS\DSS Client\Record\ by default.
	Take a snapshot on the device	Take a snapshot of the current image and save it locally. The saving path is C:\DSS\DSS Client\Picture\ by default.
	Close	Close the window.

Icon	Name	Description
	Map location	If the device has been marked on the map, click the icon to open the map in a new window to display map location of the device.
	Search by snapshot	Capture the target in the playback window. Click to select the search method, and then the system goes to the page with search results. More operations: <ul style="list-style-type: none"> • : Move the selection area. • : Adjust the size of the selection area. • Right-click to exit search by snapshot.
	Tag	Tag the videos of interest for easy search in the future.

Right-click the video, and then you can perform the following actions.

Figure 5-33 Shortcut menu




Table 5-8 Description




Parameters	Description
Select Audio Input	If the camera has more than one audio input channels, you can select one or select the mixed audio. This configuration is effective with both live view and playback.
Continuous Snapshot	Take snapshots of the current image (three snapshots each time by default). The snapshots are saved to <code>..\DSS\DSS Client\Picture</code> by default. To change the snapshot saving path, see "8.3.5 Configure File Storage Settings".
Video Adjustment	Adjust the brightness, contrast, saturation, and chroma of the video for video enhancement.
Digital Zoom	Click it, and then double-click the video image to zoom in the image. Double-click the image again to exit zooming in.
AI Overlay	The client does not show rule lines over live video by default. When needed, you can click AI Overlay and enable Rule Overlay and Bounding Box Overlay , and then the live video shows rule lines if the AI detection rules are enabled on the device. This configuration is effective with the current selected channel both in live view and playback.

Parameters	Description
SMD Overlay	Enable SMD Overlay to show target bounding box over live video. When SMD is enabled on the device, you can enable SMD Overlay for the device channel, and then the live video will display dynamic target bounding boxes. This configuration is effective with the current selected channel both in live view and playback.
Disable Privacy Masking	For a camera that supports privacy masking of human face, you can disable the masking here to view the face image.
Playback on Video Wall	Play the video of the current channel on video wall. Make sure that video wall is configured (see "5.1.5 Video Wall").
Set as Alarm Window	When selecting open alarm linkage video In Preview (in live window) from Local Settings > Alarm , then the video will be displayed on the window which is set to alarm window. If multiple alarms are triggered, the video linked to the latest alarm will be opened. If the number of alarm windows is fewer than the number of linkage videos, the video linked to the earliest-triggered alarm will be opened. After enabling Set as Alarm Window , the window frame is displayed in red.

5.1.3.3 Locking Videos

Lock the video stored on the server within a period of a specific channel. The locked video will not be overwritten when disk is full.


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2** Click the **Playback** tab.
- Step 3** Select a channel from the device tree, and then double-click it, or drag it to the window.
- Step 4** Select the storage path of recorded video from , and then click  to select the date.
The search results are displayed.



Dates with blue dot means there are video recordings.

Figure 5-34 Playback page






Step 5 Select a window that has recorded video, and then click  on the bottom of the page, and then click on the timeline to mark the start point and end point of the video clip you need.

Figure 5-35 Lock record



Step 6 Confirm the start and end time, and then click **OK**.




Related Operations

Click  on the lower-right corner, and then all the recordings locked by the user currently logged in to the client are displayed. Double-click one to quickly play the recording.

5.1.3.4 Tagging Videos

You can tag records of interest for quick search.

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2** Click the **Playback** tab.
- Step 3** Select a channel from the device tree, and then double-click it, or drag it to the window.
- Step 4** Select the storage path of recorded video from , and then click  to select the date.
The search results are displayed.



Dates with blue dot means there are video recordings.

Figure 5-36 Playback page



- Step 5 Point to the window that is playing record, and then click .
- Step 6 Name the tag, and then click **OK**.

5.1.3.5 Filtering Recording Type

Filter video according to record type, record type includes scheduled record, alarm record, and motion detection record.

Procedure







- Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2 Click the **Playback** tab.
- Step 3 Select a channel from the device tree, and then double-click it, or drag it to the window.
- Step 4 Click , select a record type (or types), and then click **OK**.
The system only displays videos of the selected type. Each section on the time bar in green indicates a recorded video of the type you selected.

Figure 5-37 Filter record type



5.1.3.6 Clipping Videos


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2** Click the **Playback** tab.
- Step 3** Select a channel from the device tree, and then double-click it, or drag it to the window.
- Step 4** Select the storage path of recorded video from , and then click  to select the date.
The search results are displayed.



Dates with blue dot means there are video recordings.

Figure 5-38 Playback page





- Step 5** Select a date with video recordings, and then click .
- Step 6** On the timeline, click the point with green shade to start clipping, drag your mouse, and then click again to stop clipping.

Figure 5-39 Download recorded video






- Step 7** Enter the password of the current user.
- Step 8** (Optional) Enable **Transcode**, and then select the file format.
- Step 9** Click **OK**.

5.1.3.7 Smart Search

With the smart search function, you can select a zone of interest on the video image to view motion records within this section. The relevant camera is required to support Smart Search; otherwise the search result will be empty.


Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center**.
- Step 2** Click the **Playback** tab.
- Step 3** Select a channel from the device tree, and then double-click it, or drag it to the window.
- Step 4** Select the storage path of recorded video from , and then click  to select the date.
The search results are displayed.



Dates with blue dot means there are video recordings.

Figure 5-40 Playback page




- Step 5** Select a window that has videos, click , and then select a type.
The smart search page is displayed, with 22 × 18 squares in the window.

Figure 5-41 Smart search



Step 6 Click the squares and select detection areas.



- Select a detection area: Point to image, click and drag to select a square.
- For the selected area, click again or select square to cancel it.

Step 7 Click to start smart search analysis.

- If there are search results, the time progress bar will become purple and display dynamic frame.
- It will prompt that the device does not support smart search if the device you selected does not support the function.



Click to select the detection area again.

Step 8 Click the play button on the image or control bar.

The system plays search results, which are marked purple on the timeline.

Step 9 Click to exit smart search.

5.1.4 Map Applications

On the map, you can view real-time videos of devices, locations of channels that trigger alarms, cancel alarms, and more.

Prerequisites

Make sure that you have configured a map. For details, see "4.2 Configuring Map".

Procedure

Step 1 Log in to the DSS Client, and on the **Home** page, select > **Monitoring Center**.

Step 2 Click .

Step 3 In the list of maps, click a map.

Step 4 View video, cancel alarms, and more.







The functions vary with the types of maps and devices. Slight differences might be found in the actual page.

Table 5-9 Function Description

Function	Description
Group talk	<p>You can engage in a group talk with MPT users.</p> <ol style="list-style-type: none"> Click next to the list of maps. The default group includes all MPT users. <p>For how to configure an MPT user, see "3.2.2 Adding User".</p> <ol style="list-style-type: none"> Click Add Group Talk. Enter a name for the group, select MPT users, and then click OK. Click the new group, and then click on the upper-right corner to join the group. <ol style="list-style-type: none"> Press the F2 key to talk to the users in the group. (Optional) Click and you can edit the users in the group. The users removed from the group will return to Default Group.
Hide Device Name	Only displays the icons of devices or channels.
Zoom in and out on the map	<p>Rotate the wheel or click and to zoom in and out on the map. When zooming out on the map, the same type of devices or channels will be merged together if they are near each other.</p>

Function	Description
Satellite Map	If you are using an online map, you can view its satellite map.
View live video	Click Pane , select devices on the map, and then click to view videos in batches; or click on the map, and then select to view videos.
Playback	Click Pane , select devices on the map, and then click to view videos in batches; or click on the map, and then select to view videos.
View alarms	Click to view all alarms that are triggered. Click an alarm and the map will zoom in to the location of the device that triggered the alarm. Alarms will be automatically canceled after 30 s.
Cancel alarms	Click a device on the map, and then select . The alarm will also be automatically canceled after 30 s.
Monitor a radar	<ul style="list-style-type: none"> The alarm area and detection area are displayed on the map by default. If a target is detected, its real-time location will be displayed in these areas. Click a radar channel, you can view its information and use the following functions: <ul style="list-style-type: none"> : View the raster map on the radar. You can use this function to check if the maps on the radar and the platform are consistent. : View the real-time videos of the linked PTZ cameras. : Search for and view recordings of the linked PTZ cameras. : View the real-time videos of the channels bound to the radar. You can use this function to monitor the area around the radar. : If the alarm area and detection area of the radar are keeping you from operating other channels, you can click this icon to hide these areas.
Show devices	Select the types of devices and channels you want to display on the map. You can click an alarm output channel to control whether it will output alarm signals.
Visual area	If a device supports visual area, click Visual Area and double-click a device on the map to show its monitoring area. This function is only available on GIS maps.
Initial angle	If a device supports initial angle, click Initial Angle and double-click a device on the map to show the initial angle. This function is only available on GIS maps.

Function	Description
Measure distance	Select Box > Length , connect two points with a line on the map (double-click to finish drawing), and then the distance between the points is shown.  This function is only available on GIS maps.
Measure area	Select Box > Area , select a region on the map (double-click to finish drawing), and then the area is measured.  This function is only available on GIS maps.
Clear	To clear all markings on the map, click Clear .
Add marks	Select Box > Add Mark , and then mark information on the map.
Reset	Select Box > Reset to restore the map to its initial position and zoom level.
Sub maps	Click  to view the information of the sub map.
	Double-click  , and then the platform will go to the sub map, where you can view the resources on it.

5.1.5 Video Wall

A video wall, which consists of multiple video screens, is used for displaying videos on the wall, instead of small PC displays.

Complete video wall settings before you can view videos on the wall.

5.1.5.1 Configuring Video Wall

5.1.5.1.1 Page Description

Before using the video wall function, you should get familiar with what you can do on the video wall

page.

Figure 5-42 Video wall




Table 5-10 Page description

No.	Function	Description
1	Device tree	<p>If you have selected Device and Channel in Local Settings > General, the device tree will display all devices and their channels. Otherwise, it will only display all channels.</p> <p>Click to view channels that you have saved to favorites.</p> <p>You can enter keywords in <input type="text" value="Search..."/> to search for the channels you want.</p>
2	Live view	View live videos from channels.
3	Detailed information	<p>View the channel information in a screen of the video wall.</p> <ul style="list-style-type: none"> Click and view the live video of the channel in Live View on the lower-left corner. This can be helpful when you need to make sure whether it is the channel you want. Click to adjust the order of channels. Click to delete the channel from the screen. Click Stay Duration (sec) or to define the for how long the live video of the channel will be displayed during each tour. Click Stream or to change the video stream of the channel.
4	Window split	Select how you want the window to split.
5	Clear screen	Clear all the screens.
6	Stopping or starting all tours	Stop or start all tours.

No.	Function	Description
7	Lock window	If multiple screens in a video wall are configured to be a combined screen, then you can perform video roaming on the window that has been locked.
8	Display mode	Display the real-time video, or a snapshot of the real-time video every 10 minutes of the bound channel in the screen. If nothing happens after operation, you can just click another screen, then click the screen you want, and then it should work properly.
9	Turning on or off screens	Turn on or off the screens configured for the currently selected video wall.
10	Decoding to wall immediately after configuration	When a task has been configured, the platform will immediately decode channels to the video wall.
11	Decoding to wall	Manually decode channels to the video wall.
12	Video wall layout	Click to view the layout of the current video wall.
13	Video wall display area	The display area for video walls.
14	Screen operations	Includes stopping tour for the screen, muting, pasting, maximizing or restoring the screen, and closing the screen,
15	Video wall plan	Configure a timed or tour plan for the video wall. For detailed procedures, see "5.1.5.1.5 Configuring Video Wall Plans".
16	Video wall selection	Select the video wall you want to configure.
17	Display task management	Add, save, and delete tasks.

5.1.5.1.2 Preparations

To display video on the wall, make sure that:

- Cameras, decoders and video wall are well deployed. For details, see the corresponding user's manuals.
- Basic configurations of the platform have been finished. For details, see "3 Basic Configurations".

During configuration, make sure that:

- ◇ When adding a camera, select **Encoder** from **Device Category**.
- ◇ When adding a decoder, select **Video Wall Control** from **Device Category**.

5.1.5.1.3 Adding Video Wall

Add a video wall layout on the platform.

Procedure

Step 1 Log in to the DSS Client, and on the **Home** page, select **Monitoring Center** > .

Step 2 From the **Video Wall** drop-down list, select **Add New Video Wall**.

Step 3 Enter **Video Wall Name**, and then select a window splicing mode.








- Select a splicing mode from among 1 × 1, 2 × 2, 3 × 3, 4 × 4 or set a custom mode by clicking .
- A multi-screen splicing mode is a combined screen by default. You can perform video roaming on it. For example, with a 2×2 combined screen, if you close 3 of them, the other one will be spread out on the combined screen. To cancel combination, click the combined screen, and then click .
- To create a combined screen, press and hold Ctrl, select multiple screens, and then click .
- To clear the created screen, click .



Figure 5-43 Add a video wall



Step 4 Click **Next Step**.

Step 5 Select the encoders which need to be bound in the device tree, and drag it to the corresponding screen.



- You can set whether to show ID in the screen,  means that the screen ID is disabled; click the icon and it becomes , which means that screen ID is enabled.
- Each screen in a combined screen must be bound with a decoding channel.

Step 6 Click **Finish**.

5.1.5.1.4 Configuring Video Wall Display Tasks


Display videos on the wall manually or in accordance with the pre-defined configuration.

Procedure

Step 1 Log in to the DSS Client, and on the **Home** page, select **Monitoring Center** > .

Step 2 In the **Task** drop-down list, select **Add**.

Figure 5-44 Add a video wall task




Step 3 From the device tree, select a camera, and then drag it to a screen, or select a window, drag the camera to the **Detail** section.




If you do not close video wall display in advance, this action will delete the bound camera and play the selected camera on the wall.


Step 4 Click .



If you have selected an existing task in the **Task** drop-down list, after dragging the video channel to the window, click  to save it as a new task, which will be played on the wall immediately.

Step 5 Name the task, and then click **OK**.

- During video wall display of a task, if you have rebound the video channel, click  to start video wall display manual.
- During video wall display, click  or  to stop or start tour display.

Step 6 Click  to start video wall display.

5.1.5.1.5 Configuring Video Wall Plans

Configuring Timed Plans


Procedure

Step 1 Log in to the DSS Client, and on the **Home** page, select **Monitoring Center** > .

Step 2 Click on the upper-right corner.

Step 3 Hover over and then select .

Figure 5-45 Set timed plan



Step 4 Enter the plan name.

Step 5 Select a video task, set start time and end time, and then click **Add**.

Repeat this step to add more tasks. The start time and the end time of tasks cannot be repeated.



Select the **Enable This Timed Plan in Remaining Time** check box, and then set the task. The video wall displays the selected task during the remaining period.


Step 6 Click **Save**.

Step 7 Click to start the plan.



You cannot display multiple plans on the wall at the same time. When a plan is enabled, the previous plan on the wall is automatically terminated.

Figure 5-46 Enable timed plan



- Modify plan:
- Delete plan:

Configuring Tour Plans

After setting video wall tasks, you can configure the sequence and interval of tasks so that they can automatically play in turn on the wall.

Procedure

- Step 1** Log in to the DSS Client, and on the **Home** page, select **Monitoring Center** >
- Step 2** Click on the upper-right corner.
- Step 3** Hover over and then select

Figure 5-47 Tour plan

Task Name	Stay Time(min)	Operation
Task 1	00:30	↑ ↓ 🗑️
Task 2	00:20	↑ ↓ 🗑️

- Step 4** Enter task name, select a video task and then set stay time. Click **Add**. Repeat this step to add more tasks.



Click to adjust task sequence; click to delete a task.

Figure 5-48 Tour information


Task 1	00:30	↑ ↓ 🗑️
Task 2	00:20	↑ ↓ 🗑️

- Step 5** Click **Save**.
- Step 6** Click to start the tour plan.



You cannot display multiple plans on the wall at the same time. When a plan is enabled, the previous plan on the wall is automatically terminated.

Figure 5-49 Enable tour plan



- Modify plan: Click .
- Delete plan: Click .

5.1.5.2 Video Wall Applications



Make sure that decoder video ports are connected to the video wall screens.

5.1.5.2.1 Instant Display

Drag a camera to the video wall screen for instant display on the wall.

Background Information

The video wall display task is configured. For details, see "5.1.5.1.4 Configuring Video Wall Display Tasks".


Procedure

- Step 1 Log in to the DSS Client, and on the **Home** page, select **Monitoring Center** > .
- Step 2 In the **Video Wall** drop-down list, select a video wall.
- Step 3 Click to start video wall display.
- Step 4 Drag a camera from the device tree to a screen, or select a window and drag the camera to the **Detail** section.



- A window can be bound to multiple video channels.
- The binding mode, which includes **Tour**, **Tile**, and **Inquiry**, can be set in **Local Settings > Video Wall**. For details, see "8.3.3 Configuring Video Wall Settings".
- For a fisheye camera, right-click it to select the installation mode for fisheye dewarping.

Figure 5-50 Bind video channel



Step 5 Select a screen, and then click **Detail** to view detailed information about the screen and channel, including stream type, preset and display sequence.

- Click to view live video of the current channel on the lower left.
- Click to adjust sequence.
- Click to delete the video channel on the current window.

5.1.5.2.2 Video Wall Task Display

Display a pre-defined task on video wall.

Procedure

Step 1 Log in to the DSS Client, and on the **Home** page, select **Tools > Video Wall**.

Step 2 In the **Task** drop-down list, select a task.

Step 3 Operations available.

- After changing the video channel that is being displayed, click at the lower-right corner before you can see the effect on video wall.
- Click to pause or stop.
- Select a screen, and then click **Detail** to view detailed information about the screen and

channel, including stream type, preset and display sequence.

5.1.5.2.3 Video Wall Plan Display

Display a pre-defined plan on video wall.







Make sure that there are pre-defined plans. For details, see "5.1.5.1.5 Configuring Video Wall Plans". The video wall automatically works as the plans have been configured. To stop the current plan, click  on the upper-right corner of the **Video Wall** page, and then it changes to . Click  to start displaying video on wall again.

Figure 5-51 Display video wall plan



5.2 Event Center

When alarms are triggered, you will receive notifications on real-time alarms. You can view their details, such as snapshots and recordings, and process them. If you miss alarms occurred during a certain period, or want to check certain alarms, such as high priority alarms occurred in the past day or all alarms that have not been processed in the past week, you can set the search conditions accordingly and search for these alarms. Based on all the alarms that were triggered, the platform will generate statistics ready for your review. This can be helpful for how you can optimize your security measures.

Make sure you have configured and enabled alarm events. To configure, see "4.1 Configuring Events".

5.2.1 Real-time Alarms

View and process real-time alarms.

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **Event Center**.

Step 2 Click .



The alarm list is refreshed in real time. To stop refreshing, click **Pause Refresh**. To continue receive alarms, click **Start Refresh**.

Figure 5-52 Real-time alarms



Alarm Time	Site Name	Alarm Category	Alarm Type	Alarm Source	Priority	Remarks	Processed by	Operation
2022-07-13 18:53:34	Current Site	Soft Trigger	Soft Trigger_1	196EVS-Channel2	High			
2022-07-13 18:53:34	Current Site	Soft Trigger	Soft Trigger_1	196EVS-Channel2	High			
2022-07-13 18:53:34	Current Site	Soft Trigger	Soft Trigger_1	196EVS-Channel2	High			
2022-07-13 18:53:34	Current Site	Soft Trigger	Soft Trigger_1	196EVS-Channel2	High			
2022-07-13 18:53:34	Current Site	Soft Trigger	Soft Trigger_1	196EVS-Channel2	High			
2022-07-13 18:53:33	Current Site	Soft Trigger	Soft Trigger_1	196EVS-Channel2	High			
2022-07-13 18:53:33	Current Site	Soft Trigger	Soft Trigger_1	196EVS-Channel2	High			

Step 3 Click  to claim an alarm.

After an alarm has been claimed, the username of your account will be displayed under the **Processed by** column.

Step 4 Process alarms.



You can use the up and down arrow keys on the keyboard to quickly select other alarms.



1. Click  or double-click the alarm.

Figure 5-53 Alarm details



The screenshot shows the 'Alarm details' view. On the left, there is a list of four 'Soft Trigger-222' alarms with their respective timestamps and source IDs. The main area is dominated by a large video feed showing a person in a warehouse-like setting. Above the video, the alarm's details are displayed: '2021-10-12 17:14:08', '94.150_2', and 'Soft Trigger 222'. On the right side, there is a control panel with 'Pending' and 'Processed' tabs, an 'Acknowledge' button, and radio buttons for 'Resolved', 'Ignore', and 'Forward'. A 'OK' button is at the bottom right.

2. The middle area displays the time when the alarm was triggered, name and location of the alarm source, alarm type, and the live video images of linked channels, alarm

videos, and alarm snapshots.



Double-click a window to view them in larger size. Click  to go back.

Figure 5-54 Alarm linkage media






3. On the right side, select how to process the alarm from **Resolved**, **Ignore**, or **Forward**. Enter comments, and then click **OK**.
Forward allows you to forward the alarm to another user who will process it.
4. (Optional) Click  to disarm the alarm. This alarm will not be triggered within the defined period.
5. (Optional) Click  to send the alarm information to other users as a prompt or an email.

Figure 5-55 Send email



5.2.2 History Alarms

Search for and process history alarms.

Procedure
























- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Event Center**.
- Step 2** Click .
- Step 3** Set search conditions, and then click **Search**.

Figure 5-56 History alarms



No.	Alarm Time	Alarm Category	Alarm Type	Alarm Source	Priority	Remarks	Processed by	Alarm Status	Operation
1	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
2	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
3	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
4	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
5	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
6	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
7	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
8	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
9	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
10	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
11	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
12	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
13	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
14	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
15	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
16	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
17	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
18	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
19	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	
20	2022-04-07 16:3...	Soft Trigger	1	IPC 4894698464...	High			Pending	

- Step 4** Claim and process alarms. For details, see "5.2.1 Real-time Alarms".



You can use the up and down arrow keys on the keyboard to quickly select other alarms.

5.2.3 Event Overview

With alarms being triggered and processed, statistics are generated to give you a clear picture of what is happening in your area, such as the number of alarms that were processed, and the type of alarms that are triggered most frequently.

Log in to the DSS Client. On the **Home** page, click , and then select **Event Center**.




- To view event overview, click .



Figure 5-57 Alarm overview



Table 5-11 Alarm overview description

No.	Parameter	Description
1	Search conditions	<ul style="list-style-type: none"> To view real-time alarm overview, click Real Time, select a site (if any), an organization, and refresh frequency. To view daily alarm overview, click Daily, configure the time, select a site, an organization, and then click Search. To view weekly alarm overview, click Weekly, configure the time, select a site, an organization, and then click Search. To view monthly alarm overview, click Monthly, configure the time, select a site, an organization, and then click Search. <p> If the time zone of the server is not the same as the DSS client, statistics will be generated based on the time zone of the server. For example, daily statistics will be generated from 00:00 to 24:00 based on the time zone of the server.</p>
2	Alarm Overview	Statistics is generated based on the alarms that the current user has access to. The number and proportion of alarm events that are pending, processed, or not processed are displayed. The data will only refresh in real-time when you are viewing daily statistics.

No.	Parameter	Description
3	Alarm Priority	<p>Statistics is generated based on the events that the current user has access to. The number of alarms of all priorities are displayed.</p> <p>The data will only refresh in real-time when you are viewing daily statistics.</p>  <p>You can click high, medium, or low to not include the number of certain alarms. For example, if you click High, the number of the alarms in this priority will not be counted.</p>
4	Top 10 Alarm Sources	<p>Top 10 alarm sources that the current user has access to are sorted by the number of alarms.</p> <p>The data will only refresh in real-time when you are viewing daily statistics.</p>  <p>You can click high, medium, or low to not include the number of certain alarms. For example, if you click High, the number of the alarms in this priority will not be counted.</p>
5	Top 10 Alarm Types	<p>Top 10 alarm types that the current user has access to are sorted by the number of alarms.</p> <p>The data will only refresh in real-time when you are viewing daily statistics.</p>
6	Alarm Trend	Displays trend of alarms of all priorities.

- To view and process alarms, click .
- To view and process alarms, click .

5.2.4 Alarm Controller

You can monitor and manage alarms controllers.

Prerequisites

Alarm controllers are added to the platform. See "3.1.2 Managing Device".

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **Event Center**.

Step 2 Click .

Step 3 In the device tree, click an organization.

All alarm controllers under this organization will be displayed on the right. You can select one or more alarm controllers, and then click **Away Arm** or **Disarm** to arm or disarm the alarm controllers you selected.



If arming failed, you can click **Force Arm** on the prompt window to arm again.

Figure 5-58 Alarm controller organization




- Step 4** In the device tree, click an alarm controller.
All subsystems under this alarm controller will be displayed on the right.



You can right-click an alarm controller, and then click **Update Alarm Controller** to update its information.

Figure 5-59 Subsystems



- Step 5** Arm or disarm subsystems.
- Away Arm** **Disarm** **Refresh**: Operate on multiple subsystems.
 - : Operate on one systems.



- See the user manual of the alarm controller for detailed description on each function.
- If arming failed, you can click **Force Arm** on the prompt window to arm again.

- Step 6** In the device tree, click a subsystem of the alarm controller.
All zones under this subsystem will be displayed on the right.

Figure 5-60 Zone

Zone Name	Partition Name	Bypass Status	Realtime Status	Fault Status	Operation
ARC9016C-zhu_1		Normal	Close	Normal	[Bypass] [Isolate] [Unbypass]
ARC9016C-zhu_2		Normal	Close	Normal	[Bypass] [Isolate] [Unbypass]
ARC9016C-zhu_3		Normal	Close	Normal	[Bypass] [Isolate] [Unbypass]
ARC9016C-zhu_4		Normal	Close	Normal	[Bypass] [Isolate] [Unbypass]

Step 7 Bypass, isolate, or unbypass zones.

- : Operate on multiple zones.
- : Operate on one zone.



- See the user manual of the alarm controller for detailed description on each function.
- If arming failed, you can click **Force Arm** on the prompt window to arm again.

5.3 DeepXplore

You can set multiple search conditions to view records of people, vehicle snapshots, access, POS, and MPT.


5.3.1 Searching for Records

In this section, you can view integrated records of people, vehicle, access control, POS transactions, and MPT devices.

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click and then select **DeepXplore**.
- Step 2** Click and then select **Record**.

Figure 5-61 Record search



Step 3 Set the search object, channel and time, and then click **Search**.

Figure 5-62 Search result



For the search result, you can perform following operations.

- Click next to the record to add it to temporary records.
- For face capture records, you can hover the mouse over the small image on the right, and then click to search for images similar to this one. For details, see "5.3.2 Searching for People".
- Click next to the record to delete it one by one.



Access records and POS records cannot be deleted.

- Click **Export** to export records to the local storage.

Step 4 Select a record, and on the right side, you can see the details. Click on the video image to view the linked recording.

click at the upper-right corner to view all records added to temporary records. Inside it, you can click to generate target track, and click to remove the record from the bank.

5.3.2 Searching for People


Based on the defined search conditions, you can view capture records of faces, bodies and other information.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore**.

Step 2 Click , and then select **Person**.

Figure 5-63 Person search



- Search object
 - ◇ **Face Capture:** Search for records in face capture database.
 - ◇ **Body Capture:** Search for records in body capture database.
 - ◇ **Person Archive:** Search for records in person information database.
- Search type
 - ◇ **Search by Feature:** Search for records by the defined features such as age, gender, clothes color, ID and more.
 - ◇ **Search by Image:** Search for records by the uploaded image, and only records above the set **Similarity** will be displayed.



Only new versions of IVSS devices support displaying similarity.

- ◇ Search channel: Select device channels of the records by clicking **Selected Channel**.

- ◇ Search time: Select time period of the records from **Today**, **Yesterday** and **This Week**.




Only available for face and body capture records.

- Search conditions: Set search conditions such as age, gender, top color, ID, name and more to search for specific records.

Step 3 Set the search object, type and conditions, and then click **Search**.

Figure 5-64 Search result



For the search result, you can perform following operations.

- Click next to **Search** to change search conditions.
- Click to change records arrangement.
- Click next to the record to add it to temporary records.
- Click next to the record to delete it one by one, or you can select records, and then click **Delete** to delete them in batches.
- Click **Export** to export records to the local storage.

Step 4 Select a record, and on the right side, you can see the details. Click the video image to view the linked recording.

Click at the upper-right corner to view all records added to temporary records. Inside it, you can click to view the target track, and click to remove the record from the bank.


Step 5 Go back to **Step 2**, and then click **Person Archive**.

Step 6 Enter the ID, name or card number of the person you want to search for.

Step 7 Double-click the record.

You can see the face capture, vehicle capture, access records and other information of the corresponding person.

Figure 5-65 Person information



5.3.3 Searching for Vehicles

Procedure




- Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore**.
- Step 2 click , and then select **Vehicle**.

Figure 5-66 Vehicle search



- Search object
 - ◇ **Vehicle Capture:** Search for records in vehicle capture database.
 - ◇ **Vehicle Archive:** Search for records in vehicle information database.

- Search type
 - ◇ Search channel: Select device channels of the records by clicking **Selected Channel**.
 - ◇ Search time: Select time period of the records from **Today, Yesterday** and **This Week**.







Only available for vehicle capture records.




- Search conditions: Set search conditions such as plate number (full plate number optional), vehicle brands, owner name and more to search for specific records.

Step 3 Set the search conditions, and then click **Search**.

For the search result, you can perform following operations.

- Click  next to **Search** to change search conditions.
- Click  to change records arrangement.
- Click  next to the record to add it to temporary records.
- Click  next to the record to delete it one by one, or you can select records, and then click **Delete** to delete them in batches.
- Click **Export** to export records to the local storage.

Step 4 Select a record, and on the right side, you can see the details. Click on the video image to view the linked recording.

Click  at the upper-right corner to view all records added to temporary records. Inside it, you can click  to generate target track, and click  to remove the record from the bank.


5.3.4 Searching for POS Transaction

You can search for POS transactions by keywords and POS fields.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select  > **DeepXplore** > **DeepXplore** > **POS Transaction**.


Step 2 Configure POS field.

- 1) Click **POS Field Config**.
- 2) Configure a POS field for its receipt field, and then click  to enable it.
- 3) Click **OK**.

Step 3 Configure the search conditions.

- 1) Configure the information you want to search for.
 - **POS Info:** Keywords in the transaction information. This can be used with one or more POS fields at the same time.
 - **POS fields:** The POS fields you have configured in step 2 will be used to search for certain information in the transactions. For example, the POS field for total price is TTL, then the platform will obtain the number for TTL and return the results.
- 2) Select POS channels, configure the period, and then click **Search**.

Figure 5-67 Search results



Step 4 Manage the search results.

- View details.

Select a transaction, and then you can view the detailed information and video at the time of transaction on the right.



If you need video at the time of transaction, you must bind POS channels with video channels, and configure recording plans for the video channels. For details, see "3.1.3 Binding Resources" and "3.1.4 Adding Recording Plan".

- Add to a case.

- Click of a transaction to add it to the temporary library.
- Click on the upper-right corner.
- Select one or more transactions, and then click **Add to Case**.
- Select a case, and then click **OK**.



In the temporary library, select one or more transactions, and then click to remove them. This operation will only remove them from the temporary library, but not delete them.

- View track.

- Click of a transaction to add it to the temporary library.
- Click on the upper-right corner.
- Select transactions, and then click . The platform will open a page and display the track based on the transactions you select.



If you need to view tracks, you must mark POS channels on the map first. For details, see "4.2.3 Marking Devices".

5.3.5 Adding Case Bank

Inside the case bank, you can integrate the records of face, plate, access and more into one complete case, and configure details of it for future investigation. The platform supports storing up to 10,000 cases.

Prerequisites

The case files can only be stored in **Incident File** disk. Make sure that you have configured such disk type in advance.

Users with access to **Case Bank**:


- Super administrator: View, edit and delete incident files.
- Administrator:
 - ◇ View incident files created by themselves and common users. No access to incident files of other administrators.
 - ◇ Edit and delete files opened.
 - ◇ Cannot edit or delete files closed.
- Common user:
 - ◇ Can only view files created by themselves.
 - ◇ Edit and delete files opened.
 - ◇ Cannot edit or delete files closed.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore**.


Step 2 click .

Step 3 Click **Add** to add a new case.

Step 4 In the **Case Icon** section, click one of the 5 small squares, drag the image file to the big square on the left, or hover the mouse over the big square, click , and then upload the image file.

The image you select will be displayed on the upper-left corner of the case you export.

Figure 5-68 Select an image for the case



Step 5 Select an image from the right side of the **Case Icon** section, which will be located at the upper-left corner of the case file generated. You can change the icon by dragging the image from the right side to the left side image area.



Only one icon can be added onto the case file.


Step 6 Enter the basic information of the case.



- **Case Type:** Used for categorize cases. You can click the drop-down list to select type or create new ones.
- **Status:** Select the case status from **Open** and **Close**. The Platform integrates cases under each status category.

Step 7 Add records, including face capture, body capture, ANPR, access record and more. Records of other categories are added in the same way. In this section, we take **Face Capture** as an example.

1. Click **Add** under **Face Capture**.
2. Select channels and time, and then click **Search**. You can click the record to view its details.

Figure 5-69 Add face capture record



3. Click  next to the record to add it to the case.
4. Click  to go back to the case adding page, you can add other type of records related to the case.

Step 8 Scroll down and click **Add** under **Attachment** to upload images and videos related to the case.







- The platform supports uploading up to 20 videos, and each video cannot exceed 300 MB. Format includes dav, mp4, avi, flv and asf.
- Up to 20 images can be uploaded. Image format includes png, jpg and jpeg.



The number of all video files and images cannot be more than 20.

Step 9 Click **OK**.

Related Operations

- Delete or replace an icon
Hover the mouse over a small square, and then click  to delete it; click a small square, and then drag an image file to the big square on the left, or hover the mouse over the big square, click , and then upload the image file to replace it.
- Enter case name in the search box at the upper-right corner, and then press Enter or click  to search for cases.
- Click  under a temporary case to view the case details. If you need to edit the details, click **Edit** and change the information as needed.
- Click  under a temporary case to download it, or you can click **Download** in the case details page. Click **Download Progress** at the lower-left corner to check the download progress.
- Click  under a case to delete it one by one, or you can select cases, and then click **Delete** to delete them in batches.


5.3.6 Viewing Track of MPT Devices

Search for and view the track of an MPT device on the map within the defined period.

Prerequisites

- Configure the vector map. For details, see "4.2.2.1 Adding Vector Map".
- Add MPT devices to the platform. For details, see "3.1.2.4 Adding Devices".
- MPT devices upload their GPS information to the platform. For details, see their user's manuals.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore > MPT Track**.

Step 2 Select an MPT device, configure the time, and then click **Search**.
The track of the MPT device will be displayed on the map.




You can only search for up to 24 hours of track in the same day. For example, 00:00 to 23:59:59, or 3:00 to 23:59:59.



5.4 Access Management

On the **Access Management** page, you can do operations on access control, lift control, attendance, video intercom, and visitor.

5.4.1 Access Control Application

You can unlock and lock doors, view details of bound videos and event, and the access control logs. Make sure that you have finished the access control configuration before application. For details, see "4.5 Access Control". You can also click  **Access Control Configur...** to go to the access control configuration page.

5.4.1.1 Viewing Videos

If you have already bound a video channel to the access control channel, you can view the real-time videos of the channels on the console. To bind video channels, see "3.1.3 Binding Resources".
Log in to the DSS Client. On the **Home** page, select  **> Access Management >**  **> Access Control Console**, and then view the linked real-time videos by the following two methods.




- On the right side of the console page, click  in the access control channel list.


Figure 5-70 Viewing video (1)



- Click  on the console page. The video page is displayed. Drag the access control channel on the left side of the screen to the live view page on the right side. The system displays videos in

real time.

Figure 5-71 Viewing video (2)



5.4.1.2 Unlocking Door

In addition to normally open status or linked unlock in specified periods, the console also supports unlocking by manually controlling the access control channel. After unlock, the door automatically locks up after a specified period (5 s by default, and 10 s in this example) set up in **Door Config**.



This section introduces the unlocking operations on the client. For unlocking by fingerprint, card, and face recognition, you can operate on devices. If advance functions have been configured, unlock doors according to the requirements of advance functions.

There are the following ways to unlock door:


- On the left side of the page, right-click an access control channel in the device list, and select **Remote Unlock** in the pop-up menu. After unlocking, a timed log will be displayed under the channel on the right.
- Click of a door channel on the right to unlock the door.
- When viewing videos bound to the channel, click on the window to unlock the door.
- Set multiple doors to be normally open

Select door channels in global control, and then you can set the door to be normally open.

1. Click on the lower left of the console page of the **Access Control Console** module.
2. Select an access control channel to be set to Always Open through global control, and click **OK**.
3. Click on the lower-left corner of the page, and then click **OK**.





If you want to go back to scheduled control or face-recognition access for these channels,



Click  to restore them to the default status.

5.4.1.3 Locking Door

In addition to normally open status or linked lock in specified periods, the console also supports locking by manually controlling the access control channel. You can lock the door in the following ways:


- On the left side of the page, right-click an access control channel in the device list, and select **Remote Lock** in the pop-up menu.
- Click  of a door channel on the right to unlock the door.
- When viewing videos bound to the channel, click  on the video page to lock the door.
- Set multiple doors to be normally closed

Select multiple door channels in global control, and then you can set them to be normally closed.

1. Click  on the lower left of the console page of the **Access Control Console**.
2. Select multiple door channels, and click **OK**.
3. Click  at lower-left of the page, and then click **OK**.



If you want to go back to scheduled control or face-recognition access for these channels,

Click  to restore them to the default status.

5.4.1.4 Viewing Event Details


View details of the events reported on door locking and unlocking, including event information, live view, snapshot, and recording.

Background Information



- Live view is only available when a video channel is bound to the access control channel. To bind video channels, see "3.1.3 Binding Resources".
- To see snapshots and videos of access control, you need to configure video linkage action for the access control channels. For details, see "4.1 Configuring Events".
- Details except locking door are displayed on the console, such as unlocking door, entry with the duress card, and no right.

Procedure

Step 1 In the event list below the console page, click  next to the event records.



For a face recognition controller, the face snapshots will be displayed in the records; for other controllers, the records display the captured image and person profile.

Figure 5-72 Event information




Table 5-12 More operations

No.	Description
1	You can choose to view the events of certain event types. For instance, if you select Normal , the list only displays normal events.
2	<ul style="list-style-type: none"> Click to stop displaying reported event information. In this case, the page no longer displays the reported new events. After clicking, the button changes to . Click to start refreshing reported event information. The page does not display events during the stopping period. After clicking, the button changes to .
3	Clear the events from the current event list without removing them from the log.
4	Click to view access control records.

Step 2 Click the corresponding tab to view the live view, snapshots, and video recordings of the linked video channel.

5.4.1.5 Viewing Access Control Records

You can view access control records on the platform or directly on a device. For records on a device, see "8.1 Managing Logs".

5.4.1.5.1 Online Records

The access control records stored on the platform.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click > **Access Management** > > **Access Control Record**.

Step 2 Set search conditions, and then click **Search**.

Figure 5-73 Search result

Time	ID	Room No.	Card No.	Device	Door	Event	Person Name	Status	Operation
2021-04-08 18:53:21	25574		2B86192A		Door1	Valid Swipe	xxg1=4243243...	In	
2021-04-08 17:00:45	25574		2B86192A		Door1	Valid Swipe	xxg1=4243243...	In	
2021-04-08 16:12:59	25574		2B86192A		Door1	Valid Swipe	xxg1	In	
2021-04-08 16:12:54	18971		CBF01E2A		Door1	Valid Swipe	xxg2	In	
2021-04-08 16:11:41	25574		2B86192A		Door1	Valid Swipe	xxg1	In	
2021-04-08 16:09:42	18971		CBF01E2A		Door1	Valid Swipe	xxg2	In	
2021-04-08 16:06:06	25574		2B86192A		Door1	Valid Swipe	xxg1	In	
2021-04-08 16:06:04	716		CBF01E2A		Door1	Valid Swipe	xxg1	In	
2021-04-08 16:01:50	25574		2B86192A		Door1	Valid Swipe	xxg1	In	
2021-04-08 16:00:23	25574		2B86192A		Door1	Valid Swipe	xxg1	In	
2021-04-08 11:52:19	25574		2B86192A		Door1	Valid Swipe	xxg1	In	

Step 3 Manage event records.

- Click and you can view live view, snapshot and recording, and person information access control events.
- Click **Export** at the upper-left corner of the page, and then export records as the screen instructs.

5.4.1.5.2 Offline Records


The access control records stored in the device when it was disconnected from the platform. After the device gets reconnected to the platform, you can retrieve the records generated during the disconnection.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click > **Access Management** > > **Access Control Record**.

Step 2 Click **Acquire Records** on the upper-left corner.

Figure 5-74 Extract records during disconnection



Step 3 Enter the login password for verification.

Step 4 Click  to set period, select **Card-swiping Records** or **Alarm Log**, and then select device.



- You can select up to one week.
- The types of logs supported include door not closed in time alarms, intrusion alarms, anti-passback alarms, duress alarms, device temper alarms, blocklist alarms, too many attempts on invalid passwords and cards alarms.

Step 5 Click **OK**.


5.4.2 Lift Control Application




You can control lifts, view linked real-time videos and event details, and the lift control records. Before using these functions, you must:

- Add lift control devices to the platform. For details, see "3.1.2 Managing Device".
- Assign lift control permissions to people. For details, see "4.3.2.1 Adding a Person".

5.4.2.1 Viewing Videos

If a lift control channel has been linked to a video channel, you can view its real-time video in the lift control console so that you can monitor what is happening near the lift. For how to link a lift control channel to a video channel, see "3.1.3 Binding Resources".

Log in to the DSS Client. On the **Home** page, select  > **Access Management** > **Lift Control** > **Lift Control Console**, and then view the linked real-time videos in the following two methods.

- Click , and then click  of a lift control channel.
- Click , and then drag a lift control channel to a window on the right, or select a window on the right, and then double-click a lift control channel.


5.4.2.2 Global Control

You can select multiple lift control channels, and then set them to the no authentication mode, authentication mode or lock mode.

Background Information




- No authentication mode: All people will have permissions to use the selected lift control channels.
- Authentication mode: All people will need to verify if they have permissions to use the selected lift control channels.
- Lock mode: No person will have permissions to use the selected lift control channels.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select  > **Access Management** > **Lift Control** > **Lift Control Console**.

Step 2 Click  next to **Global Control**.

Step 3 Select multiple lift control channels, and then click **OK**.

Step 4 Click ,  or  to set them to no authentication mode, authentication mode or lock mode.

5.4.2.3 Viewing Event Details

View details of the events reported when someone used a lift, including event information, live

video, snapshots, and record videos.



- Live videos are only available when a lift control channel has been linked to a video channel. For details, see "3.1.3 Binding Resources".
- To view snapshots and videos in an event, you need to configure the event for the lift control channels. For details, see "4.1 Configuring Events".

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select > **Access Management** > **Lift Control** > **Lift Control Console**.

Step 2 In the event list on the bottom of the page, double-click an event to view its details.

Table 5-13 More operations

Icon	Description
	You can choose to view only certain types of event. For example, if you select Normal , the list only displays normal events.
	<ul style="list-style-type: none"> • Click to stop displaying reported event information. In this case, the page no longer displays the reported new events. After clicking, the button changes to . Click it so that new events can be reported again. • Click to clear all events in the list, but it will not delete them from the lift control records. • Click to go to the lift control records page.
	Clear the events from the current event list without removing them from the log.
	Click to view access control records.

Step 3 Click the corresponding tab to view the live video, snapshots, and recorded videos.

5.4.2.4 Viewing Lift Control Records

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select > **Access Management** > **Lift Control** > **Lift Control Records**.

Step 2 Configure the search conditions, and then click **Search**.

Step 3 Manage the records.

- Click to view the information, real-time video, snapshots, and recorded video of an event.
- Click **Export** on the upper-right corner, and then follow the on-screen instructions to export records to your computer.

5.4.3 Video Intercom Application

- You can call, answer, release information and view video intercom records.
- Make sure that you have configured the video intercom configuration before application. For details, see "4.6 Video Intercom". You can also click to go to the video intercom configuration page.


5.4.3.1 Call Center

The platform, VTOs, VTHs, second-generation door station access controllers, and second-generation fence station access controllers can call each other.

Procedure


- Step 1** Log in to the DSS Client. On the **Home** page, click > **Access Management** > > **Call Center**.

Figure 5-75 Call center



- Step 2** You can call different devices.
- Call from the platform to VTO
 - Select VTO in the device list; click corresponding of VTO or dial a number on the dial pad to call the VTO. The system pops out call page. The following operations are supported during call.
 - ◇ : If VTO is connected to lock, click this icon to unlock.
 - ◇ : Click this icon to capture picture, the snapshot is saved into the default directory. To change the path, see "8.3.5 Configure File Storage Settings".
 - ◇ : Click this icon to start record, click again to stop record. The video is saved in default path. To change the path, see "8.3.5 Configure File Storage Settings".
 - ◇ : Click this icon to hang up.

Figure 5-76 Call








- Call from the platform to VTH
 - Select VTH from the device list, click  on the VTH or dial corresponding VTH on the right (such as 1#1#101). The system pops up the dialog box of **Calling now, please wait...** There are two modes for answering the call.
 - ◇ Answer by VTH, bidirectional talk between client and VTH. Press  to hang up when you answer the call.
 - ◇ If VTH fails to answer in 30 s, hangs up or is busy, then it means the call is busy.


Figure 5-77 Calling



- Call from the platform to an access control device that supports video intercom
 - Select a device from the device list, click  on it or dial its number on the right (such as 1#1#101). The system pops up the dialog box of **Calling now, please wait...** There are two modes for answering the call.
 - ◇ Answer by the device, bidirectional talk between client and the device. Press  to hang up when you answer the call.


- ◇ If the device fails to answer over 30 s, busy or hang up directly, then it means the call is busy.

Figure 5-78 Calling



- Call from VTO to the platform
 - When a VTO calls, a window pops up.
 - ◇ : Unlock the door if the VTO is connected to a door.
 - ◇ : Answer the call.
 - ◇ : Hang up.


Figure 5-79 VTO Call



- When VTH is calling the platform
 - The client pops out the dialog box of VTH calling. Click to talk with VTH.
 - ◇ Click to answer VTO, realize mutual call after connected.
 - ◇ Click to hang up.
- When an access control device that supports video intercom is calling the platform
 - The client pops out the dialog box. Click to talk with the device.


Click  to hang up.

Figure 5-80 Call from an access control device that supports video intercom



- Call through call records
All the call records are displayed in the **Call Record** at the lower-right corner of the page of **Video Intercom**. Click the record to call back.

Figure 5-81 Call records




5.4.3.2 Releasing Messages

Send message to VTHs.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click  > **Access Management** > **Video**

Intercom > Information Release.

- Step 2** Click **Add New Message**, select one or more VTHs, and then configure the information you want to send.
- Step 3** (Optional) Enable **Schedule Release**, and then configure the time.
- Step 4** Send the message.
- If no scheduled release time is configured, click **Instant Release**, or click **Save**, and then click  to send the message immediately.
 - If a scheduled release time is configured, click **Save**, and then the message will be sent on the defined time.

5.4.3.3 Video Intercom Records

View log records and you can trace recorded calls.

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click  > **Access Management** >  > **Video Intercom Record**.
- Step 2** Set conditions, and then click **Search**.

Figure 5-82 Video intercom records



Device Name	Call Type	Room No.	Start Time	Talk Time	End Status
vto202	Outgoing	14#3#1302	2021-4-9 12:41:46	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:25:53	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:22:03	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:17:52	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:11:59	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:11:59	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:10:41	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:10:41	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:10:29	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:10:29	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:09:19	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:09:19	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:06:44	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:06:44	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:06:44	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:05:35	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:05:35	00:00	Missed
vto202	Outgoing	14#3#1302	2021-4-9 10:05:35	00:00	Missed

- Step 3** Click **Export** and the records will be saved locally according to system prompt.

5.4.4 Viewing Attendance Data

View attendance data, displayed in the form of report, including card swiping record table, attendance report, abnormality table, overtime table and away table. This section takes **Card-**

swiping Record as an example.

Prerequisites


You have configured the attendance configuration before application. For details, see "4.8 Attendance Management". You can also click to go to the attendance configuration page.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click > **Access Management** > > **Attendance**.

Step 2 Click corresponding tab, set search condition, and then click **Search**.

Figure 5-83 Attendance



Step 3 Manage search results.

- Click **Export** at the upper-left corner of the page, and then export records as the screen instructs.
- When card swiping records are displayed in list, click to view the details of the corresponding user.

Related Operations

When viewing attendance report, you can manually synchronize attendance records from devices. Click **Sync Offline Records**, configure the time and channels, and then click **OK** to synchronize the records from the channels you selected to the platform. The attendance report will be updated accordingly. To automatically synchronize attendance records, see "4.5.6 Synchronizing Records".

5.4.5 Visitor Application

After appointment is made on platform, and visitor information is registered, the visitor can have

access permission. Access permission is disabled after the visitor leaves.

5.4.5.1 Preparations

- You have configured the deployment of the video intercom devices, access control devices and entrance and exit device. For details, see the corresponding user's manual.
- You have configured the basic configuration of the platform. For details, see "3 Basic Configurations".
- Make sure that you have configured the visitor configuration before application. For details, see "4.9 Visitor Management". You can also click to go to the video intercom configuration page.

5.4.5.2 Visitor Appointment

Register visitor information on the platform.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click > **Access Management** > > **Visitor Management**.
- Step 2** Click **Visitor Registration**.
- Step 3** Click the **Visitor Details** tab, enter the information of the visitor and the one to be visited.


Figure 5-84 Visitor details



Click in the appointment list to enter the **Visitor Details** tab.

- Step 4** (Optional) Click the **Authentication** tab, select the room number to be visited, and then click **Generate** to generate the QR code of the pass.
You can click to download the QR code, and click to send it to the visitor by email.

Figure 5-85 Authentication





Step 5 Click **OK**.

5.4.5.3 Checking In

When a visitor with an appointment arrives, you need to confirm their information and give them access permission. On-site registration is supported when there is a walk-in visitor. Visitors can get access by card swipe or face recognition.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select  > **Access Management** >  > **Visitor Management**.

Step 2 Enter the information of the visitor.


- 1) Go to the visit registration information page.
 - If a visitor has an appointment, find their visitor information, and then click .
 - If a visitor does not have an appointment, click **Visit Registration**.
- 2) Confirm or enter the information of the visitor.

Figure 5-86 Visitor information

Step 3 (Optional) Click the **Authentication** tab, and then set authorization information.

- 1) Select the room number.
- 2) Issue cards.

You can issue cards by entering card number manually or by using a card reader. A card number is 8-16 numbers. Only second-generation access control devices support 16-digit card numbers. When a card number is less than 8 numbers, the system will automatically add zeros prior to the number to make it 8 digits. For example, if the provided number is 8004, it will become 00008004. If there are 9-16 numbers, the system will not add zero to it.

- Issue cards by entering card numbers manually
Click **Add** next to **Card**, enter the card number, and then click **OK**.

Figure 5-87 Issue card




- Issue card by using a card reader
Click , select a card reader or device, and then click **OK**. Swipe card through the reader or device, and then a new card will be issued.

Figure 5-88 Reader manager



- 3) Set face picture. Position your face in the snapshot area, and click **Upload Picture** to select a picture or click **Snapshot** to take a photo.

Figure 5-89 Take a face photo






- 4) Click **Generate** to generate a QR code for the pass. You can click  to download the QR code, and click  to send it to the visitor by email.

Figure 5-90 Authentication




Step 4 Click the **Authorize** tab, and then select access permissions for the visitor.



If you want to set video intercom devices and entrance and exit permissions, you must set host room number and number plate for the visitor.




Figure 5-91 Authorize



Step 5 Click **OK**.

Related Operations




- End visit.

- Click  to end a visit.
- View card swiping records.
Click the **Card-swiping Record** tab, or click  in visitor record to view visitor card swiping records.
- Cancel appointment.
Click , and cancel the appointment as the screen instructs.

5.4.5.4 Checking Out

When visitors are leaving, remove their access permissions.






Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click  > **Access Management** >  > **Visitor Management**.
- Step 2 Find the appointment record of the visitor, and then click .
- Step 3 Click **OK** to remove access permission.
If you have issued a card to a visitor, make sure the visitor returns the card before leaving.

5.4.5.5 Searching for Visit Records

Search for visit records, and view visitor details and card swiping records.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click  > **Access Management** >  > **Visitor Record**.
- Step 2 Set search conditions, and then click **Search**.
The results are displayed.
- 
- In addition to entering the card number, you can also click , select a card reader and then get the card number by swiping card.
- Step 3 Click  to view visitor details and card swiping records.

5.5 Parking Lot

You can monitor vehicles that enter and exit in real time, view vehicle information, and search for on-site vehicle, exit vehicle and snapshot records, and manage parking lots intuitively through their different layers.

5.5.1 Statistics Dashboard

The platform automatically generates data on parking lots, including real-time data on the current day, number of vehicles entering and leaving parking lots, parking turnover rate, and rate of parking space usage.

Log in to the DSS Client. On the **Home** page, click  > **Parking Lot** > **Statistics Dashboard**. The

data covers only the parking lots the current user has access to. Administrators can access all parking lots by default.

Figure 5-92 Statistics dashboard





Table 5-14 Parameter description

Parameter	Description
Parking lots	Select the parking lots you want to view data on, and then the numbers of parking lots, ANPR channels, entrances, and exits.
Real-time data of the current day	Displays the real-time data on the parking lots you selected.
Counting period	<p>Configure a period you want to view data on. The graphs will adapt accordingly.</p> <p> The platform only displays the number of vehicles in parking lots for each day.</p>

Parameter	Description
Different types of data presented in graphs	Displays different types of data within the counting period you configured. <ul style="list-style-type: none"> • Vehicles that Entered and Exited: Vehicles that have entered and exited the parking lots. • Vehicle in Parking Lot: Vehicles that were inside the parking lots. • Parking Turnover Rate: Parking turnover rate = The number of vehicles that parked during the counting period / the number of parking spaces. The higher the parking turnover rate, the higher the number of vehicles parked in the parking lot. • Rate of Parking Space Usage: Rate of Parking Space Usage = The total parking duration of all the vehicles / The number of parking spaces in the parking lot × The counting period. The higher the rate of parking space usage, the better the parking lot is being used.
Auto-Refresh Interval	Select how often the data will be updated.
Export a report	Export the current page as a PDF file to your computer.

5.5.2 Entrance and Exit Monitoring

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click > **Parking Lot** > **Entrance and Exit Monitoring**.

Step 2 Select the number of windows you want from

Step 3 Click **Please click to select the entrance and exit.**, select an entrance or exit point, and then click **OK**.

The real-time video of that point will be opened in the window.

Figure 5-93 Monitor entrances and exits




Table 5-15 Page description

No.	Description
1	Select the number of windows you want. Each window can display the real-time video of one entrance or exit point.
2	The real-time video of an entrance or exit point. <ul style="list-style-type: none"> Click to open the real-time video of another entrance or exit point in the window. Click to open the barrier for vehicles. <ul style="list-style-type: none"> ◇ Open without Recording Plate Info: Open the barrier for vehicles without recording their plate numbers. If you select Count Parking Spaces at the same time, the number available parking spaces in the parking lot will decrease or increase depending on whether the vehicles are entering or leaving. This operation will not generate an enter or leave record. ◇ Open and Record Plate Info: This is applicable to when the ANPR cameras cannot recognize the number plates. You can manually enter the number plate, and a snapshot will be taken, and then the platform will generate an entrance or exit record.
3	Displays records of barriers not opened. <ul style="list-style-type: none"> Click to open the barrier for the vehicle. If the plate number is incorrect, you can click to manually edit it. Click to view the recorded video from the corresponding channel.
4	All entrance and exit records. <ul style="list-style-type: none"> : Pause or resume refreshing the entrance and exit records. : View the details and recorded video of a record.

5.5.3 Searching for Records

Search for entry and exit records, forced exit records, parking records, and snapshot records.

Log in to the DSS Client. On the **Home** page, click , and then select **Vehicle Entrance and Exit**.

Click **Entrance and Exit Config.** to go to the entrance and exit configuration page.

5.5.3.1 Searching for Entrance Records

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click > **Parking Lot** > **Info Search**.

Step 2 Click the **Entrance Records** tab.






Step 3 Configure the search conditions, and then click **Search**.



Click **Show More** and you can search by vehicle owner, company, person group, and more.

Step 4 Manage the records.

- Click the image, and then a bigger one will be displayed.

- Double-click a record or click , and the detailed information is displayed on the right. Click the play icon to play the recorded video, and then click  to download it. Click  to modify the information of the vehicle, such as the plate number, brand and color. For the dual camera mode, click each channel to view the information it captured.
- Click **Layer Info** to view the location of the channel that captured the vehicle on the layer.
- Forced exit.
If **No** is displayed under **Already Exited** when the vehicle has exited, click  to change the status to **Yes**.
- Export records.
Select the records to be exported, click **Export**, and then export them according to the on-screen instructions. You can also click **Export**, and then export all records according to the on-screen instructions.
- Click  and then select the items to be displayed.

5.5.3.2 Searching for Exit Records

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click  > **Parking Lot** > **Info Search**.





Step 2 Click the **Exit Records** tab.

Step 3 Configure the search conditions, and then click **Search**.



Click **Show More** and you can search by vehicle owner, company, person group, and more.

Step 4 Manage the records.

- Click the image, and then a bigger one will be displayed.
- Double-click a record or click , and the detailed information is displayed on the right. Click the play icon to play the recorded video, and then click  to download it. Click  to modify the information of the vehicle, such as the plate number, brand and color. For the dual camera mode, click each channel to view the information it captured.
- Click **Layer Info** to view the location of the channel that captured the vehicle on the layer.
- Export records.
Select the records to be exported, click **Export**, and then export them according to the on-screen instructions. You can also click **Export**, and then export all records according to the on-screen instructions.
- Click  and then select the items to be displayed.

5.5.3.3 Searching for Forced Exit Records

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click  > **Parking Lot** > **Info Search**.





Step 2 Click the **Forced Exit Records** tab.

Step 3 Configure the search conditions, and then click **Search**.



Click **Show More** and you can search by vehicle owner, company, person group, and more.

Step 4 Manage the records.

- Click the image, and then a bigger one will be displayed.
- Double-click a record or click , and the detailed information is displayed on the right. Click the play icon to play the recorded video, and then click  to download it. Click  to modify the information of the vehicle, such as the plate number, brand and color. For the dual camera mode, click each channel to view the information it captured.
- Click **Layer Info** to view the location of the channel that captured the vehicle on the layer.
- Export records.
Select the records to be exported, click **Export**, and then export them according to the on-screen instructions. You can also click **Export**, and then export all records according to the on-screen instructions.
- Click  and then select the items to be displayed.

5.5.3.4 Searching for Parking Records

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click  > **Parking Lot** > **Info Search**.




Step 2 Click the **Parking Records** tab.

Step 3 Configure the search conditions, and then click **Search**.



Click **Show More** and you can search by vehicle owner, company, person group, and more.

Step 4 Manage the records.

- Click the image, and then a bigger one will be displayed.
- Double-click a record or click , and the detailed information is displayed on the right, including entry and exit records. Click the play icon to play the recorded video, and then click  to download it. For the dual camera mode, click each channel to view the information it captured.
- Click **Layer Info** to view the location of the channel that captured the vehicle on the layer.
- Export records.
Select the records to be exported, click **Export**, and then export them according to the on-screen instructions. You can also click **Export**, and then export all records according to the on-screen instructions.
- Click  and then select the items to be displayed.

5.5.3.5 Searching for Capture Records

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click  > **Parking Lot** > **Info Search**.






Step 2 Click the **Capture Records** tab.

Step 3 Configure the search conditions, and then click **Search**.



Click **Show More** and you can search by vehicle owner, company, person group, and more.


Step 4 Manage records.

- Click the image, and then a bigger one will be displayed.
- Double-click a record or click , and the detailed information is displayed on the right. Click the play icon to play the recorded video, and then click  to download it. Click  to modify the information of the vehicle, such as the plate number, brand and color. For the dual camera mode, click each channel to view the information it captured.
- Restore entry
If **Yes** is displayed under **Exited** when the vehicle is still in the parking lot, click  to change the status to **No**.
- Export records.
Select the records to be exported, click **Export**, and then export them according to the on-screen instructions. You can also click **Export**, and then export all records according to the on-screen instructions.
- Click  and then select the items to be displayed.

5.5.4 Visualized Parking Lot

Quickly understand your parking lot by viewing the information on the layers.




Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click  > **Parking Lot** > **Visualized Parking Lot**.

Step 2 Select a parking lot, and then double-click a layer.

Step 3 View the information on the layer.

Table 5-16 Operation description

Icon/Parameter	Description
	View the total and available parking spaces on the layer.
	View all the resources on the layer.
	Zoom in and out on the layer.
Display Selected Layers	Select which resources you want to display on the layer.

Icon/Parameter	Description
Pane	Click and hold on the layer to select multiple devices. After you select multiple devices, you can perform the following operations: <ul style="list-style-type: none"> • : View the capture records from the selected devices. • : View the entrance records from the selected devices. • : View the exit records from the selected devices. • : View the parking records from the selected devices. • : Open a video player and you can view the real-time video of each device you selected. If you are viewing the real-time video from an entrance or exit point, you can click to open the barrier. • : Open a video player and you can search for and view the recorded videos from the devices you selected.
Reset	Reset the layer to its default size and position.
Hide Plate No.	If reserved parking spaces have been configured on the layer, you can hide partial information of the number plates displayed on the parking spaces.

5.5.5 Vehicle Location

If vehicle search is configured for parking lots, vehicle owners can find where their vehicles are parked through the vehicle search system. Operations on a computer or phone are similar. This section uses a computer as an example.

Procedure

Step 1 Go to the link of the vehicle search system in the browser.



For the links and QR codes used to access the vehicle search system, see "4.10.2.5 Vehicle Finder".

Step 2 Search for vehicles.

- Search for vehicles with license plates.
Enter a license plate, and then click **Search** to view the location of the vehicle, including the name of the parking lot, floor number, parking space number, and layer information. If there are multiple results, click one to view its details.



To view layer information of vehicles, you must configure the layer first. For details, see "4.10.2.3 Parking Lot Layer".

- Search for vehicles without license plates.
Click **Unlicensed Vehicle Search** to view all vehicles without licenses. If there is only one result, the system will directly display its details. If there are multiple results, click one to view its details.

5.6 Intelligent Analysis

View real-time and history people counting data, heat maps, and number of people in an area.

5.6.1 People Counting

View the real-time and historical people count from all the devices in a people counting group.

5.6.1.1 Real-time Count


Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click > **Intelligent Analysis** > > **Real-time Count**.

Step 2 Double-click a group or drag it to a window on the right to display its real-time data.

- **Occupancy:** The number of people currently inside this group, which will be reset to the defined value at the defined calibration time.
- **Entered:** The number of people entered this group, which will be reset to zero at the defined calibration time.
- **Exited:** The number of people who left this group, which will be reset to zero at the defined calibration time.
- Color of the light:
 - ◇ Red light: $\text{Occupancy} \geq \text{red light threshold}$.
 - ◇ Yellow light: $\text{Yellow light threshold} \leq \text{occupancy} < \text{red light threshold}$.
 - ◇ Green light: $\text{Occupancy} < \text{yellow light threshold}$.

Figure 5-94 Real-time count




Step 3 Hover you mouse on the window displaying real-time data, and then click .

Step 4 You can enter a number of people to overwrite the current data, and customize the

content to be displayed for green, yellow and red light.


Figure 5-95 Edit the content and data



Step 5 Click **OK**.

5.6.1.2 Historical Count


Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click  > **Intelligent Analysis** > **People Counting** > **Historical Count**.
- Step 2 Select the groups you want in **Groups**, or select the channels in **Resources**.
- Step 3 Configure the search settings, and then click **Search**.
- **Groups**: Groups are people counting groups, which allow you to combine and calculate the people flow data from multiple rules across different devices and channels. You can search for historical people flow data from one or more people counting groups.
 - **Resources**: Search for historical people flow data from one or more channels. The data from all the rules of a channel will be included.





If a device is offline, it will upload all the data to the platform when it is online again.

Figure 5-96 Historical people counting data



Related Operations

- 

 : Change the display format of the data.



Only weekly report supports will display the number of retention.

- Export:** Export the data into a .zip file to your computer.

5.6.2 Heat Maps



View heat maps generated by devices. A heat map shows the distribution of people flow by different colors, such as red for many people have visited an area and blue for only a few people have visited an area. The platform supports generating general heat maps and advanced heat maps. Only fisheye cameras support advanced heat maps.

Prerequisites

Configure the channel feature for either type of heat maps. For details, see "3.1.2.5.2 Modifying Device Information".

- General heat map: Select the **General Heat Map** from the channel features.
- Advanced heat map: Select the **Advanced Heat Map** from the channel features.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click  > **Intelligent Analysis** > .
- Step 2** Select a channel, and then generate a heat map.



You can generate a heat map with data from up to one week.

- Generate a general heat map.
Configure the time, and then click **Search**.
- Generate an advanced heat map.
 - 1) Select how you want to generate the heat map, **Number of People** or **Time**.
 - 2) Configure the threshold.



- When you select **Number of People**, the area with the closest number of people to the threshold will be in red.
 - When you select **Time**, the area where people stay for a duration closest to the threshold will be in red.
- 3) Set the time, and then click **Search**.

Step 3 Click **Export** on the upper-right corner to export the heat map to your PC.

5.6.3 In-area People Counting

View statistics on the number of in-area people.

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click > **Intelligent Analysis** > **In Area No. Analysis**.

Step 2 Select a channel and configure the search settings, and then click **Search**.




If a device is offline, it will upload data within the past 24 hours to the platform when it is online again.

Figure 5-97 In-area people number statistics



Related Operations

- 
 : Change the display format of the data.
- Export:** Export the data to your PC.

5.7 Maintenance Center

You can view the overall running status of the platform, including server, channel, and device. Clear view of fault information allows you to locate the fault source and type, and then fix it in time. You can also update the programs of devices.

5.7.1 Viewing System Status



Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **Maintenance Center**.

Step 2 View the status of the system.



On any page, click **Generate Report** or **Export** to export the information on the page to your computer.

- Click **Overview** to view the overall running status of the platform, including the status of devices on main and sub servers, storage, status of servers, and fault trends. The data is refreshed every minute.
- Select **Resource Monitoring** > **Server Status**, and then click a server or service to view its running status and history information, including faults occurred in the last 7 days and logs generated on the current day. Click **View All** to jump to corresponding pages for more information.
- Select **Resource Monitoring** > **Device Status**. Click a device type, and then the status of all the devices are displayed on the right. Click  to view detailed information.
 - ◇ **Channel Status Info:** Information such as the channel name, online or offline, recording days, and video integrity status.
 - ◇ **Hard Disk Status Info:** If it is a storage device, you can view the information of its hard disks in this section. Click  to view the RAID information of the hard disks.
 - ◇ **History Info:** Displays faults occurred in the past 7 days and logs of the current day. Click **View All** to view all information.
- Select **Maintenance Management** > **Faults**. On the top of the page, all faults occurred in the last 7 days are displayed by default. Click a server or a device type to view all faults occurred in the last 7 days for that server or the devices under that type.

5.7.2 Updating Device Program


Add a plan to update the programs of selected devices in batches.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **Maintenance Center > Maintenance Management > Device Update**.

Step 2 Click **Add**.

Figure 5-98 Add an update plan



Step 3 Enter a name for the plan, and then select the device category, type, model, and program version.

The platform will only display corresponding devices.



You can only update the programs of IPCs and access control devices of Dahua access protocol and added with an IP address.

Step 4 Select the devices you want to update. Click  to cancel selecting all devices.

Step 5 Configure when to update the devices.

- **Now:** Update the devices immediately after the plan is added.
- **Custom:** Update the devices at the defined time.

Step 6 Click **Upload File** to upload the update program.







- Make sure that the uploaded program matches the models and current program versions of selected devices.
- Make sure that the network is stable and the power properly connected for all devices. Otherwise, they might not work properly.

Step 7 Click **OK**.

Related Operations

In the list of update plans, you can view the information of each plan, including name, update program, update start time, and update status.

- Click  to delete a plan one by one; select multiple plans, and then click **Delete** to delete them in batches.
- Click  to view the update status of the devices in a plan.
 - ◇ Click  to remove a device from the plan; select multiple devices, click **Delete** to remove them in batches.
 - ◇ If one or more devices failed to update, click  to update a device again one by one, or select multiple devices, and then click **Update Again** to update them in batches.

6 General Application

This chapter introduces the general businesses, including target detection, face recognition, and ANPR.

6.1 Target Detection


View and search for the metadata of people, vehicle, and non-motor vehicle.



Target detection can be done by video metadata cameras + a platform, or IPCs + IVSSs + platform.

6.1.1 Typical Topology

Figure 6-1 Typical topology



- General cameras record videos.
- Video metadata cameras such as panoramic + PTZ camera record videos and analyze people, and motor and non-motor vehicles.
- IVSS manages cameras and analyzes people, and motor and non-motor vehicles.
- The platform centrally manages IVSS and cameras, receives analysis results from cameras and displays the reports.

6.1.2 Preparations

Make sure the following preparations have been completed:

- Cameras and IVSS are correctly deployed, and video metadata is enabled on them. For details, see corresponding user's manuals.
- Basic configurations of the platform have been finished. To configure the parameters, see "3 Basic

Configurations".

- ◇ When adding a camera or IVSS, select **Encoder** for device category.
- ◇ After adding the camera or IVSS to the platform, select **Target Detection** from **Features** of the device.

6.1.3 Live Target Detection

Procedure









- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitoring Center > Monitor**.
- Step 2** Select a window, double-click the channel or drag the channel to the window.

Figure 6-2 Live view




- Step 3** Click  and then click  to view live metadata events.
- Step 4** View live video, and human body, vehicle, and non-motor vehicle information.
- Click an event record to view the event snapshot. You can play back the video of the event. Different events support different operations.
 - When playing back video, click  to download the video to a designated path.
 - Click  to play back the video before and after the snapshot.
 - Click  to delete event information.
 - Click  to view the most recent events.

6.1.4 Searching for Metadata Snapshots

Search for metadata snapshots by setting search criteria or uploading images.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore**.

Step 2 Click .

Step 3 Set search criteria.

You can search for metadata snapshots in the **Record**, **Person** or **Vehicle** section. For details, see "5.3 DeepXplore".


6.2 ANPR

View automatic number plate recognition in real time or search for records. You can view the moving track of a vehicle. This is useful for road monitoring.

- Automatic number plate recognition
The platform displays vehicle snapshots and ANPR results in real time.
- Vehicle records
Search for vehicle records according to the filtering conditions you have set.
- Vehicle track
According to the ANPR camera locations that a vehicle has passed through, the platform displays the driving track of the vehicle on the map.

6.2.1 Typical Topology

Figure 6-3 Typical topology



- ANPR cameras (ITC camera) capture and recognize vehicles.
- DSS centrally manages ANPR cameras, receives and displays vehicle snapshots and information uploaded from the cameras.

6.2.2 Preparations

Make sure that the following preparations have been made:

- ANPR cameras are added to the platform, and the ANPR function is configured. For details, see corresponding user's manuals.
- Basic configurations of the platform have been finished. To configure, see "3 Basic

Configurations".

- ◇ When adding an ITC camera, select **ANPR** for device category, and then select **ANPR Device** for **Device Type**.
- ◇ ANPR snapshots are only stored on **ANPR Picture** disks. On the **Storage** page, configure at least one **ANPR Picture** disk. Otherwise vehicle pictures cannot be viewed.

6.2.3 Live ANPR

Background Information

View ANPR live video and plate snapshots.

Procedure







- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitor Center** > **Monitor**.
- Step 2** Select a window, double-click the channel or drag the channel to the window.

Figure 6-4 Live view



Step 3 Click  and then click .

Step 4 View live ANPR events.

- Click an event record to view event snapshots. You can also play back the video of the event. Different events support different operations.
- When playing back a video, click  to download the video to a designated path.
- Click  to play back the video before and after the snapshot.
- Click  to delete event information.
- Click  to view the most recent events.

6.2.4 Searching for Vehicle Snapshot Records

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore**.

Step 2 Click

Step 3 Configure the search conditions.

You can search for vehicle snapshots in the **Record** or **Vehicle** section. For details, see "5.3 DeepXplore".

6.3 Face Recognition


Configure face recognition settings on the device and the platform before you can view face recognition results on the platform.

6.3.1 Typical Topology

The face recognition feature is available on select models of NVR, IVSS and FR cameras.


- Face recognition by NVR/IVSS

Figure 6-5 Typical topology (NVR/IVSS)



- ◇ Cameras record videos.
 - ◇ NVR/IVSS is used for face recognition and storage.
 - ◇ DSS centrally manages cameras, NVRs, and the face database, and provides live view and face search.
- Face recognition by camera

Figure 6-6 Typical topology (camera)



- ◇ Cameras record face videos, and detect and recognize faces.
- ◇ DSS centrally manages cameras, NVRs, and the face database, and provides live view and face

search.

6.3.2 Preparations

Make sure that the following preparations have been made:

- Face recognition devices are correctly configured. For details, see corresponding user's manuals.
- Basic configurations of the platform have been finished. To configure, see "3 Basic Configurations".
 - ◇ When adding face recognition devices, select **Encoder** for device category.
 - ◇ After adding a face recognition NVR or IVSS, select **Face Recognition** for **Features** of the corresponding channels.
 - ◇ After adding face recognition cameras or face detection cameras, select **Face Recognition** or **Face Detection** for **Features**.
 - ◇ Face snapshots are stored in the **Face/Alarm and Other Pictures** disk. Configure at least one local disk for picture storage. Otherwise, the platform cannot display snapshots.

6.3.3 Arming Faces

Before arming faces, you need to add the persons to face recognition group. For details, see "4.4.1 Face Watch List".


6.3.4 Live Face Recognition



Procedure







Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **Monitor Center** > **Monitor**.

Step 2 Select a window, double-click the channel or drag the channel to the window.

Figure 6-7 Live view



Step 3 Click  and then click  to view live face recognition information.

- Step 4 View live video, and human body, vehicle, and non-motor vehicle information.
- Click an event record to view event snapshots. You can play back the video of the event. Different events support different operations.
 - When playing back video, click  to download the video to designated path.
 - Click  to play back the video before and after the snapshot.
 - Click  to refresh events; click  to pause refreshing.
 - Click  to delete event information.
 - Click  to view the most recent events.

6.3.5 Searching for Face Snapshots

Search for face snapshots by setting search criteria or uploading images.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore**.

Step 2 Click .

Step 3 Configure the search conditions.

You can search for vehicle snapshots in the **Record** or **Person** section. For details, see "5.3 DeepXplore".

6.4 POS

View POS live video and records.

- Live view

View live POS video and the transaction details overlapped on the video.


- Playback

Search for POS transaction records and play the recorded video. The POS video clip can start 10

seconds before or after the POS receipt printing.

6.4.1 Typical Topology

Figure 6-8 Typical topology



- Cameras record videos of each POS transaction.
- NVRs are connected with cameras and POS machines, and store videos.
- POS machines record transaction details and generate receipts. They connect to the platform through NVRs.
- The platform centrally manages NVRs and cameras, and provides live videos and POS transaction video records.


6.4.2 Preparations

Make sure that the following preparations have been made:

- Cameras, NVRs and POS machines are correctly configured. For details, see the corresponding user's manuals.
- Basic configurations of the platform have been finished. To configure, see "3 Basic Configurations".
 - ◇ When adding an NVR, select **Encoder** for device category.
 - ◇ At least one POS channel is connected to NVR.
 - ◇ On the **Bind Resource** page, bind video channels to the POS channels. See "3.1.3 Binding Resources".

6.4.3 Setting POS End Sign

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.
- Step 2 Click the **POS End Sign** tab.
- Step 3 Set the end line of POS receipt.
- Step 4 Click **OK**.

6.4.4 POS Live View

View real-time POS transaction video and details.

Prerequisites

Make sure that the POS channel has been bound to video channel. For details, see "6.4.4 POS Live View".

Procedure




- Step 1** Log in to the DSS Client. On the **Home** page, click , and then select **Monitor Center > Monitor**.
- Step 2** In the **POS** list in the **Resources** section, select a channel, device or organization, double-click or drag it to the window.

Figure 6-9 POS video



- Step 3** (Optional) Set POS information style.
 - 1) Right-click and select **Set POS Style**.

Figure 6-10 POS style setting





- 2) Set **Overlap Pattern**, **Font Size**, **Background Transparency** and **Font Color**.
- 3) Point to POS information overlay area, press mouse left button and move it to adjust POS information overlay position.
- 4) Click **OK**.

6.4.5 Searching for POS Receipts

Search for POS receipt to view related video of receipt. You can search for the video half an hour before and half an hour after the time when POS receipt is printed, and you can start to play video 30 s before the time when POS receipt is printed.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then select **DeepXplore**.
- Step 2 Click .
- Step 3 Select channel and time, select **POS Record**, and then click **Search**.
- Step 4 Double-click a POS record to view related snapshot and video. For more operations, see "5.3.1 Searching for Records".

7 System Configurations

This chapter introduces system parameters configuration, license, service management and backup and, restore.

7.1 System Deployment

The platform supports managing server information and adjusting the upper-level server of a server or device.

7.1.1 Distributed Deployment

Background Information

Set the server type, and assign devices to different servers.

Procedure













- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Deployment**.
- Step 2** Click .
- Step 3** Manage servers.
- Click  to view server details.
 - Click  corresponding to a server to define the server type. A server can be set to sub server or standby server when it is not in use.
 - Click  to enable the server.  means the server is enabled.
 - Click  to delete the server.

Figure 7-1 Servers




Server Name	IP Address	Type	Server Status	Operation
192.168.1.1	192.168.1.1	Main Server	Running	
192.168.1.2	192.168.1.2	Sub Server	Running	  

- Step 4** Assign devices to different servers.
- Manually
 - Click **Allocate Resources**, and then select devices or channels on the left side, and drag them to the server on the right. The number of corresponding devices in the target server increases, and the devices in the original server reduces.




- ◇ Click **Default**, the servers are sorted in the order in which they were added.
- ◇ Click **Sort By Device Quantity**, the servers will be sorted by the number of devices.

Figure 7-2 Resource allocation



- Automatic allocation
Allocate the same type of devices evenly to different servers.
 1. Click **Auto Distribution**.
 2. Select **Device Type**. Multiple types are supported.
 3. Select the server to which the devices belong. Multiple servers can be selected.
 4. Click **OK**.

Figure 7-3 Auto allocation



7.1.2 Cascade Deployment

Cascade deployment allows you to add a lower-level platform to an upper-level platform. After cascading, you can view the live video and recorded video of the lower-level platform from the upper-level platform. Also, you can display the videos on the lower-level platform on wall from the upper-level platform. 3 levels can be added at most.

Prerequisites

Make sure that the deployment of all relevant platforms has been completed.

Background Information

- You need to configure the lower-level platform information on the upper-level platform.
- Supports adding DSS Express to lower-level platform.

Procedure

- Step 1** Log in to client of the upper-level DSS platform. On the **Home** page, click and then in the **System Config** section, select **System Deployment**.
- Step 2** Click .
- Step 3** Click **Add**, and then configure parameters.
- Step 4** After configuration, click **OK**.


Figure 7-4 Add cascade


Table 7-1 Description of cascade parameters

Parameter	Description
Name	The name that identifies the platform to be added.
Organization	The organization that the added (lower-level) platform belongs to. The devices and channels of the added platform can be viewed on the upper-level platform from the organization that you have defined.
IP Address/Domain	The IP address or domain name, and the port of the added (lower-level) platform.
Port	

Parameter	Description
Username	The username and password for logging in to the added (lower-level) platform.
Password	

7.2 License Information

Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **License**.

Click  of an activation code to view its details, such as time of activation and resources you can connect to the platform.

7.3 License

The system controls channel and function availability through the license. User can buy a license according to the channels and functions as needed.



The platform is unlicensed by default after being deployed.

License Types

- Trial
A trial license is limited in capacity and expires in 90 days.
- Paid
To acquire full control of the features and permanent use, you need to buy a formal license. After activating the first paid license, if you want to increase your license capacity, you can buy more license codes. For example, if you have 500 channels currently, you can buy another 500 channels. After activating the new 500 channels, you will have 1,000 channels in total.
- Unlicensed
Lack permissions to use the system. This occurs after deactivating.



For expired trial version and unlicensed version, all modules are displayed as unauthorized, except for the resources, license, tools, and management modules.

Activation Methods

- Normal online activation
When the platform server is connected to the Internet, it can connect to the license server, which supports online license activation by verifying the activation code.
- Normal offline activation
When the platform server is on a local area network, it cannot connect to the license server. You need to obtain the license file from a computer with Internet access, and then import the license

- file to the platform to activate it.
- Upgrade from DSS Express to DSS Pro
 - ◇ Online activation

When the platform is upgraded from Express to DSS Pro, and the original Express has a purchased license, and the platform server has Internet access, you can activate through verifying the new activation code and Express activation code (or importing Express deactivation file).
 - ◇ Offline activation

When the platform is upgraded from Express to DSS Pro, and the original Express has a purchased license, the platform server cannot visit the license server. You can activate through verifying the new activation code and Express activation code (or importing Express deactivation file) and then importing the license obtained from a computer with Internet access.

7.3.1 Activating License

You can get the desired features or number of channels only after you load the corresponding license.

For details about activating a license, see "2.1.6.2 Activating License".

7.3.2 Deactivating License


After deactivation, the platform will be unauthorized. A deactivated license can be activated again on other servers, allowing users to change servers. The license can be deactivated with online and offline deactivation. If the server is connected to the network, use online deactivation. Otherwise use offline deactivation.

7.3.2.1 Online Deactivation

Background Information


Select this method if your platform sever is connected to a network.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **License**.


Step 2 In the **Deactivate License** section, click **Online Deactivate License**.



The license is reusable. We recommend copying the license code by clicking  and then saving it locally.

Step 3 Click **Deactivate Now**, and then follow the onscreen instructions to finish deactivation.

Figure 7-5 Online deactivation



7.3.2.2 Offline Deactivation

Background Information

Select this method if your platform server has no Internet access.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **License**.
- Step 2** In the **Deactivate License** section, click **Offline Deactivate License**.

Figure 7-6 Offline deactivation



- Step 3** Click **Export** to export and save the license deactivation file locally.



After the license deactivation file is exported, the platform will become unauthorized, and you cannot use any function.

- Step 4** Move the request file to a computer with Internet access. On that computer, open the system email that contains your license, and then click the attached URL go to the license management page.
- Step 5** Select **DSS > Deactivate License**.
- Step 6** Upload the license request file obtained from **Step 3**, and then follow on-screen instructions to finish the process.

7.4 System Parameters

Configure security parameters, storage retention duration, email server, time sync, remote log, login



method, and more.

7.4.1 Configuring Security Parameters

Background Information

- HTTPS (Hyper Text Transfer Protocol over Secure Socket Layer) is a safe HTTP transmission protocol. It is safe and stable, and guarantees the security of user information and devices. When HTTPS certificate is configured, you can log in to the platform through HTTPS protocol to ensure transmission security.
- Protect your data by verifying login password when download or export information, and encrypting the export files.
- After the firewall of the server is enabled, you need to add the IP address of the computer where the DSS Client is installed to the HTTP allowlist so that it can access the server.
- After the firewall of the server is enabled, only the IP addresses in the RSTP allowlist can request video stream through the media gateway service. The IP addresses of decoders will be added automatically. If there are other IP addresses that need to request video stream through media gateway service, you need to manually add them to the RSTP allowlist.


Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter** > **Security Parameter**.
- Step 2 Click  to upload the SSL certificate and private key, and then click **Save**.
- Step 3 Enable **File Export or Download Password Authentication** and **Encrypt Exported File**, and then click **Save**.
- **File Export or Download Password Authentication:**
 - ◇ You need to enter the password of the current account to export or download files.
 - ◇ For all users that log in to the platform, they do not need to enter the password when exporting or downloading files.
 - **Encrypt Exported File:** When you use the exported file, you need to verify the password.
- Step 4 Add IP addresses to the HTTP and RSTP allowlist.

7.4.2 Configuring Retention Period of System Data

Set the retention periods for logs, alarm messages, face recognition records, vehicle passing records, access snapshot records, video communication records, visitor records, POS messages, and more. Records beyond the defined retention period will be automatically deleted.

Procedure


- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.
- Step 2 Click **Message Retention Period**.
- Step 3 Double-click a number to change its value.
- Step 4 Click **Save**.

7.4.3 Time Synchronization

Background Information


Synchronize the system time of all connected devices, PC client, and the server. Otherwise the system might malfunction. For example, video search might fail. The platform supports synchronizing the time of multiple devices, which have the same time zone as the platform. You can synchronize the time manually or automatically.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.

Step 2 Click the **Time Sync** tab. Enable the sync methods, and then set parameters.

Figure 7-7 Enable time synchronization



- Scheduled Time Sync: Enable the function, enter the start time in time sync for each day, and the interval.
- Sync Time When Device Comes Online: Syncs device time when the device goes online.
- NTP Time Sync: If there is an NTP server in the system, you can enable this function to let the system enable time with the NTP server.

Step 3 Click **Save**.


Step 4 (Optional) Enable time synchronization on DSS Client.

- 1) Log in to the DSS Client, and then in the **Management** section, click **Local Settings**.
- 2) Click the **General** tab, select the check box next to **Time Sync**, and then click **Save**.



The system immediately synchronizes the time after you restart the client to keep the time of the server and the PC client the same.

Figure 7-8 Enable time sync



3) Restart the client for the configuration to take effect.

7.4.4 Configuring Email Server

Procedure


- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.
- Step 2 Click the **Email Server** tab, enable **Email Server**, and then configure parameters as required.

Figure 7-9 Set email server

Table 7-2 Description of email server parameters

Parameter	Description
SMTP Server Type	Select according to the type of SMTP server to be connected. The types include Yahoo , Gmail , Hotmail , and UserDefined .
Sender Email Address	The sender displayed when an email is sent from DSS.
SMTP Server	IP address, password, and port number of the SMTP server.
Password	
Port	
Encryption Method	Supports no encryption, TLS encryption, and SSL encryption.
Test Recipient	Set the recipient, and then click Email Test to test whether the mailbox is available.
Email Test	

Step 3 Click **Save**.

7.4.5 Configure Device Access Parameters

To ensure that you can safely use the devices, we recommend using the security mode if devices support this mode to avoid security risks. The platform also supports enabling and disabling adding devices through P2P.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter** > **Device Adding Config**.

Step 2 Select a device login mode, and then click **Save**.

Step 3 Enable or disable the P2P function.

If disabled, you cannot add devices to the platform through P2P.

7.4.6 Customizing POS End Sign

Configure the sign that prompts the end of a POS receipt.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.
- Step 2** Click the **POS End Sign** tab.
- Step 3** Enter the POS end sign, and then click **OK**.

Figure 7-10 POS end sign



7.4.7 Remote Log

To ensure safe use of the platform, the system sends administrator and operator logs to the log server for backup at 3 A.M. every day.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.
- Step 2** Click the **Remote Log** tab.
- Step 3** Enable the function, and then set parameters as required.
The **Platform No.** must be the same on the remote server and the platform.

Figure 7-11 Enable remote log



Step 4 Click **Save**.

7.4.8 Configuring Active Directory

When domain is deployed, and domain users are DSS platform users, you can import users quickly with this function.

Procedure




- Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.
- Step 2 Click the **Active Directory** tab.
- Step 3 Click  to enable the function, and then configure the parameters.
- 1) Enter domain information, including domain name, IP address, port, username, and password, and then click **Get DN** to automatically get basic DN information.
 - 2) Click **Test** to check whether the domain information works.
 - 3) Click **Save**.

Figure 7-12 Active directory



Active Directory

SSL Private Key:

Domain Name:

IP Address: Port:

Username: Password:

Base DN:

Step 4 Import domain users.



- 1) Log in to the DSS Client. On the **Home** page, click , and then in the **Basic Config** section, select **User**.
- 2) Click the **User** tab.
- 3) Click **Import Domain User**.
- 4) Select the users to be imported, or search for and select the users, and then click **Next Step**.
- 5) Select role, and set permissions for the users.
- 6) Click **OK**.

Figure 7-13 Add domain users



7.4.9 Configuring Independent Database

The platform supports connecting to an independent database and storing data in it, including face images, video metadata, events, and ANPR information. But when you search for related data, the data in both the independent database and the platform database will be searched. Only official licenses support this function.

Prerequisites

You have prepared a ready-to-run database.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **System Parameter**.
- Step 2** Click the **Independent Database Deployment** tab.
- Step 3** Click  to enable the function, and then configure the parameters.

Figure 7-14 Configure the independent database

Table 7-3 Parameter description

Parameter	Description
Database Type	Only supports MySQL.
IP Address	Enter the IP address of the database.
Port	Enter the port of the database.
Username/Password	Enter the username and password used to log in to the database.

Step 4 Click **Save**.



An independent database can only connect to one platform.

7.4.10 Configuring Push Notification and Certificate for App

Enable or disable the push notification function, and manage the VoIP certificate for App. The certificate is used to push calls to App when it is offline.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, click and then in the **System Config** section, select **System Parameters > Mobile App Config**.

Step 2 Enable or disable push notification.
If disabled, the app will not receive any notifications, such as alarms and calls.

Step 3 Update the VoIP certificate.

- 1) Contact technical support to obtain the certificate.
- 2) Click **Update Certificate**, and upload the certificate according to on-screen instructions.
After upload, the platform will display the expiration time of the certificate.

7.5 Backup and Restore

The platform supports backing up configuration information and saving it to a computer or server, so that you can use the backup file for restoring settings.

7.5.1 System Backup

Background Information

Use the data backup function to ensure the security of user information. Data can be manually or automatically backed up.

- **Manual backup:** Manually back up the data, and the DSS platform will save it locally.
- **Automatic backup:** The DSS platform automatically backs up the data at a defined time, and saves it to the installation path of the platform server.

Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **Backup and Restore**.
- Step 2** Click the **Backup** tab.
- Step 3** Back up data.
- **Manual backup:** In the **Manual Backup** section, select the data saving path, click **Backup Now**. The **Login Password** is the same as the system user's. Create an **Encryption Password** to protect data.

Figure 7-15 Manual backup




- **Auto backup:** In the **Auto Backup** section, configure backup parameters, and then click **OK**. The **Login Password** is the same as the system user's. Create an **Encryption Password** to protect the data. The platform automatically backs up data according to the defined time and period. The backup path is the installation path of the platform

server by default.



Max Number of Backup Files means you can only save defined number of backup files in the backup path.

Figure 7-16 Auto backup



7.5.2 System Restore

Restore the data of the most recent backup when the database becomes abnormal. It can quickly restore your DSS system and reduce loss.


Background Information

- Local Restore: Import the backup file locally.
- Server Restore: Select the backup file from the server.



- Stop users from using the platform before performing system restore.
- Restoring the system will change system data. Please be advised.

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, click , and then in the **System Config** section, select **Backup and Restore**.

Step 2 Click the **Restore** tab.

Step 3 Restore data.

- Restore from local backup file: In the **Restore from Local Backup File** section, select the backup file path, click **Restore Now**, and then enter the passwords (the **Password** is the same as the system user's. The **Encryption Password** is the one created when the file was backed up).

Figure 7-17 Local restore






- Restore from backup file on the server: In the **Restore from Backup File on the Server** section, click , enter the passwords (the **Password** is the same as the system user's. The **Encryption Password** is the one created when the file was backed up), and then click **OK**. After restoration, the platform will automatically restart.

Figure 7-18 Restore from backup files on the server



You can click  to download the backup file.

8 Management


8.1 Managing Logs

View and export operator logs, device logs and system logs, and enable the service log debug mode for troubleshooting.

8.1.1 Operation Log

View and export logs that record users' operations, such as viewing the real-time video of a channel.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, select **Management > Logs > Operation Logs**.
- Step 2 Click , select one or more types of log you want to search for, specify the time and keywords, and then click **Search**.
- Step 3 To export the logs, click **Export** and follow the on-screen instructions.

8.1.2 Device Log


View and export logs generated by devices.

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, select **Management > Logs > Device Logs**.
- Step 2 Select a device and time, and then click **Search**.
- Step 3 To export the logs, click **Export** and follow the on-screen instructions.

8.1.3 System Log

Procedure

- Step 1 Log in to the DSS Client. On the **Home** page, select **Management > Logs > System Logs**.
- Step 2 Click , and then select one or more types of logs you want to search for.
- Step 3 Configure the time and enter the keyword, and then click **Search**.
- Step 4 (Optional) Click **Export** and follow the on-screen instructions.


8.1.4 Service Log



Services will generate logs when they are running. These logs can be used for troubleshooting. If you need even more detailed logs, enable the debug mode so that the platform will generate detailed

logs.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select **Management > Logs > Extract Service Logs**.

Step 2 Click  to download the logs of the service within a specified period to your computer.

Step 3 (Optional) Click  to enable the debug mode of a service, and then click  to download the detailed logs within a specified period to your computer.



After the debug mode is enabled, the platform will generate a large amount of logs that occupy more disk space. We recommend you disable the debug mode after you have finished troubleshooting.

8.2 Downloading Videos

Background Information

You can download videos stored on the server or the device. They can be saved in are in .avi, .mp4, or .asf formats. Three ways to download videos are:

- Download a portion of a video by selecting a duration on the timeline.
- Download videos by files. The system will generate files every 30 minutes from the time the video starts. If the video does not start on the hour or the half hour, the first file will start from the earliest start time to the half hour or the hour. For example, if a video starts from 4:15, the first file will be from 4:15 to 4:30.
- Download a period before and after a tag.

Procedure



Step 1 Log in to the DSS Client. On the **Home** page, select **Management > Download Center**.

Step 2 Configure the search conditions, and then click **Search**.


Step 3 Download videos.



You need to verify your password by default before download. You can configure whether to verify the password. For details, see "7.4.1 Configuring Security Parameters".

- Download a video by selecting a duration on the timeline.
Click the **Timeline** tab, and then select a period on the timeline.
You can also click **Select All** on the upper-left corner, and then you can select and download the same period of all videos at the same time.
- Download a video by file.
Click the **File** tab, and then click  of a file.
You can also select multiple files, and then click **Download Selected File** on the upper-left corner to download them at the same time.
- Download a period of a video before and after a tag.
Click the **Tag** tab, click  of the file you want to download.
You can also select multiple tags, and then click **Download Selected Tagged File** to

configure and download them at the same time.

Step 4 (Optional) Click , select the format of the video, and then click **OK**.


- **Timeline:** You can further adjust the start and end time of the duration.




If you set the **Search Type of Device Video Stream** to **Main Stream and Sub Stream 1**, you can download videos recorded in main stream or sub stream for videos stored on devices. For details, see "8.3.2 Configuring Video Settings".

- **File:** If you download multiple files at the same time, you cannot configure the formats of the videos you want to save.
- **Tag:** You can configure how many seconds or minutes before and after the tag you want to download.




After download, you can click  to delete the tag.



Step 5 When downloading clipped videos, in the **Download Recorded Video** dialogue box, confirm the time span, and then, if necessary, click  to select a video format. Click **OK**.

Related Operations

- You can pause, resume, and delete a download task.

Figure 8-1 Download progress



- After download completes, click  to go to the path where the video is saved to, or click  in the prompt on the upper-right corner to play the video directly in **Local Video**. For details, see "8.4 Playing Local Videos".

8.3 Configuring Local Settings

After logging in to the client for the first time, you need to configure the following fields under system parameters: Basic settings, video parameters, record playback, snapshot, recording, alarm,

video wall, security settings and shortcut keys.

8.3.1 Configuring General Settings

Configure client language, client size, time, and more.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, select **Management > Local Settings**.
- Step 2** Click **General**, and then configure the parameters.

Figure 8-2 General parameters





Table 8-1 Parameter description

Parameters	Description
Default Client Size	Select a proper resolution for the client according to PC display screen.

Parameters	Description
Display time zone in client and event records	When selected, the client and the time of alarms will show both the time and time zone.
Device Node Info Display	Select that the device tree displays devices and their channels or only channels.
Display live view thumbnails when hovering over channels on the device tree	When selected, you can hover the mouse over a channel in the device tree in Monitoring Center and a snapshot of its live video image will be displayed.
Time Sync	If enabled, the client starts to synchronize network time with the server to complete time synchronization.
Auto run at startup	<ul style="list-style-type: none"> • If Remember Password has been selected on the Login page, select Auto restart after reboot, and the system will skip the login page and directly open the homepage after you restart the PC next time. • If Remember Password is not selected on the Login page, select Auto restart after reboot, the client login page will appear after you restart the PC.
Auto Login	<p>Enable the system to skip the login page and directly open the homepage when logging in next time.</p> <ul style="list-style-type: none"> • If Remember Password and Auto Login have been selected on the Login page, the function is already enabled. • If Remember Password has been selected while Auto Login is not selected on the Login page, select Auto Login on the Basic page to enable this function. • If neither Remember Password nor Auto Login has been selected on the Login page, select Auto Login on the Basic page and you then to enter the password when logging in next time to enable the function.
CPU Alarm Threshold	The user will be asked to confirm whether to open one more video when the CPU usage exceeds the defined threshold.
Audio and video transmission encryption	Encrypt all audio and video to ensure information security.
Auto Lock Client	<p>The client will be locked after the defined period and you cannot perform any operation. Click Click to Unlock Client and verify the password of the current account to unlock the client.</p>  <p>You can configure up to 60 minutes.</p>
Self-adaptive audio talk parameters	If enabled, the system automatically adapts to the device sampling frequency, sampling bit, and audio format for audio talk.

Step 3 Click **Save**.

8.3.2 Configuring Video Settings

Configure window split, display mode, stream type and play mode of live view, and instant playback length.


Procedure



- Step 1** Log in to the DSS Client. On the **Home** page, select **Management** > **Local Settings**.
- Step 2** Click **Video**, and then configure the parameters.

Figure 8-3 Video parameters

Table 8-2 Parameter description

Parameters	Description
Default Window Split	Set split mode of the video window.
Window Display Scale	Select from Original Scale and Full Screen .
Stream Switching Rule	When the number of window splits is greater than the defined value, the live video will switch from the main stream type to sub stream type.

Parameters	Description
Real-time Stream Acquisition Mode	<p>Select the one according to your situation. If you select Acquire directly from the device, clients will acquire video streams directly from the channel. If direct acquisition fails, the platform will forward the video streams to clients.</p>  <p>When the device and clients are properly connected to the network, direct acquisition can reduce the use of the platform's forwarding bandwidth. If too many clients are acquiring video streams from a channel, acquisition might fail due to insufficient performance of the device. Video streams will be forwarded to clients by the platform.</p>
Double-click on the video to maximize the window and switch to main stream	<p>If selected, you can double-click a video window to maximize it and switch from sub stream to main stream. Double-click again to restore the window size, and then the system will switch it back to sub stream.</p>
Play Mode	<ul style="list-style-type: none"> • Real-time Priority The system might lower the image quality to avoid video lag. • Fluency Priority The system might lower the image quality and allow for lag to ensure video fluency. The higher the image quality, the lower the video fluency will be. • Balance Priority The system balances real-time priority and fluency priority according to the actual server and network performance. • Custom The system adjusts video buffering and lowers the impact on video quality caused by unstable network. The bigger the value, the more stable the video quality will be.
Decoding Mode	<ul style="list-style-type: none"> • Software Decoding by CPU: All videos will be decoded by the CPU. When you are viewing live videos from large amount of channels, it will take up too much resources of the CPU that affects other functions. • Software Decoding by GPU: All videos will be decoded by the GPU. The GPU is better at concurrent operation than the CPU. This configuration will free up resources of the CPU significantly. • Performance Mode (CPU First): All videos will be decoded by the CPU first. When the resources of the CPU is taken up to the defined threshold, the platform will use the GPU to decode videos.
CPU Threshold	
Display previous live view after restart	<p>If selected, the system displays the last live view automatically after you restart the client.</p>

Parameters	Description
Close videos being played after long period of inactivity	The system closes live view automatically after inactivity for a pre-defined period of time. Supports up to 30 minutes.
Inactivity Time	
Instant Playback Time	Click  on the live view page to play the video of the previous period. The period can be user-defined. For example, if you set 30 seconds, the system will play the video of the previous 30 seconds.
Search Type of Device Video Stream	Select a default stream type when you play back recordings from a device.  If Only Sub Stream 2 is selected, but the device does not support sub stream 2, then recordings of sub stream 1 will be played.
Extract frames when playing back HD videos	If selected, when the playback stream is big due to high definition, certain frames will be skipped to guarantee fluency and lower the pressure on decoding, bandwidth and forwarding.
Continuous Snapshot Interval	Set the number and interval between each snapshot. For example, if the Continuous Snapshot Interval is 10 seconds and the Number of Continuous Snapshots is 4, when you right-click on the live/playback video and select Snapshot , 4 images will be taken every 10 seconds.
Number of Continuous Snapshots	

Step 3 Click **Save**.

8.3.3 Configuring Video Wall Settings

Configure the default binding mode and stream type of video wall.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select **Management** > **Local Settings**.

Step 2 Click **Video Wall**, and then configure the parameters.

Figure 8-4 Configure video wall settings




Table 8-3 Parameter description

Parameter	Description
Default Stream Type	Select Main Stream , Sub Stream 1 , Sub Stream 2 or Local Signal as the default stream type for video wall display.
Stream Switching Rule	When the number of window splits is greater than the defined value, the live video will switch from the main stream type to sub stream type.
Double-click on the video to maximize the window and switch to main stream	Double-click the video to maximize the window, and then its stream type will switch to main stream.
Video Source Play Duration	Set the default time interval between the channels for tour display. For example, if 5 seconds is configured and you are touring 3 video channels, the live video image of each channel will be played 5 seconds before switching to the next channel.
Mode of Video Decoding to Wall	<ul style="list-style-type: none"> • Tour: Multiple video channels switch to decode in one window by default. • Tile: Video channels are displayed in the windows by tile by default. • Ask Every Time: When dragging a channel to the window, the system will ask you to select tour or tile mode.

Step 3 Click **Save**.

8.3.4 Configuring Alarm Settings

Configure the alarm sound and alarm display method on the client.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select **Management** > **Local Settings**.

Step 2 Click **Alarm**, and then configure the parameters.

Figure 8-5 Configure alarm settings





Table 8-4 Parameter description

Parameters	Description
Default	All types of alarms will use the same default alarm sound when triggered.
Custom	Click Modify Alarm Sound , and then you can change the alarm sound and its play mode of each type of alarm.
Open alarm linkage video when alarm occurs	If selected, the platform will automatically open linked video(s) when an alarm occurs.
Open Alarm Linkage Video	<ul style="list-style-type: none"> • As Pop Up: The alarm video will be played in a pop-up window. • Open in Live View: The alarm video will be played in a window in Monitoring Center.  <p>For this function to work properly, you must enable When an alarm is triggered, display camera live view on client when configuring an event. For details, see "4.1 Configuring Events".</p>
Device on the map flashes when alarm occurs	Set one or more alarm types for alarm notification on the map. When an alarm occurs, the corresponding device will flash on the map.

Step 3 Click **Save**.

8.3.5 Configure File Storage Settings

Configure the storage path, naming rule, file size, and format of recordings and snapshots.

Procedure

- Step 1** Log in to the DSS Client. On the **Home** page, select **Management > Local Settings**.
- Step 2** Click **File Storage**, and then configure the parameters.

Figure 8-6 Configure file storage settings

Table 8-5 Parameter description

Parameters	Description
Video Naming Rule	Select a naming rule for manual recordings.
Video Storage Path	Set a storage path of manual recordings during live view or playback. The default path is C:\Users\Public\DSS Client\Record.
Video File Size	Configure the maximum size of a single recording file.
Image Format	Select a format for snapshots.
Image Naming Rule	Select a naming rule for snapshots.

Parameters	Description
Image Storage Path	Set a storage path for snapshots. The default path is C:\Users\Public\DSS Client\Picture.

Step 3 Click **Save**.

8.3.6 Viewing Shortcut Keys


View shortcut keys for operating the client quickly.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select **Management > Local Settings**.

Step 2 Click **Shortcut Key** to view shortcut keys of the PC keyboard and USB joystick.

Figure 8-7 View shortcut keys



Function	Shortcut Keys
Move Up	Up
Move Down	Down
Move Left	Left
Move Right	Right
Iris -	Insert
Iris +	Delete
Focus -	Home
Focus +	End
Zoom -	PgUp
Zoom +	PgDn
Open Single Window	Enter
Close Single Window	Enter
Open Full Screen	Ctrl+F
Exit Full Screen	Esc
Pause/Continue Tour	Ctrl+T
Lock Client	Ctrl+L


8.4 Playing Local Videos

You can play local videos directly on the platform.

Procedure


Step 1 Log in to the DSS Client. On the **Home** page, select **Management > Local Video**.

Figure 8-8 Local video



Step 2 Click to select one or more files, or to open all files in a folder.

Figure 8-9 Play list



Step 3 Drag a file to the window on the right or right click it to play.

Related Operations

Table 8-6 Interface operation

Icon/Function	Description
Right-click menu	<ul style="list-style-type: none"> • Continuous Snapshot: Take snapshots of the current image (three snapshots each time by default). The snapshots are saved to <code>..\DSS\DSS Client\Picture</code> by default. To change the snapshot saving path, see "8.3.5 Configure File Storage Settings". • Video Adjustment: Adjust the brightness, contrast, saturation, and chroma of the video for video enhancement. • Digital Zoom: Click it, and then double-click the video image to zoom in the image. Double-click the image again to exit zooming in.
	Close all playing videos.
	Split the window into multiple ones and play a video in full screen.
	Take a snapshot of the current image and save it locally. The path is <code>C:\DSS\DSS Client\Picture\</code> by default.
	Close the window.
	Stop/pause the video.

Icon/Function	Description
	Fast/slow playback. Max. supports 64X or 1/64X.
	Frame by frame playback/frame by frame backward.
	Capture the target in the playback window. Click to select the search method, and then the system goes to the page with search results. More operations: <ul style="list-style-type: none"> • : Move the selection area. • : Adjust the size of the selection area. • Right-click to exit search by snapshot.


8.5 Quick Commands

Customize HTTP commands and execute them quickly. Request methods of GET, POST, PUT and DELETE are supported.

Procedure

Step 1 Log in to the DSS Client. On the **Home** page, select **Management** > **Quick Commands**.


Figure 8-10 Quick commands



Step 2 Click .


Step 3 Click **Add**.

Figure 8-11 Add a quick command



Step 4 Configure the parameters, and then click **OK**.

Figure 8-12 Execute a quick command



- Step 5 Click the name of a quick command to execute it.
If successful, a prompt message will appear at the upper-right corner.

Appendix 1 Service Module Introduction

Appendix Table 1-1 Service module introduction

Service Name		Function Description
Access Service	NGINX	Reverses user requests to distributed system management services.
System Management Service	SMC	Manages services and provides access to various pages.
Device Discovery Service	HRS	Broadcasts platform information to discover devices.
Data Cache Service	REDIS	Stores temporary business data from the platform.
Database	MySQL	Stores platform business data.
Message Queue Service	MQ	Transfers messages between platforms.
Configuration Service	CFGS	Manages disks, such as read-and-write operations.
Alarm Dispatch Service	ADS	Sends alarm information to different objects according to defined plans.
Media Transmission Service	MTS	Gets audio/video bit streams from front-end devices and then transfers the data to DSS, the client and decoders.
Media Gateway	MGW	Sends MTS address to decoders.
Storage Service	SS	Stores, searches for and plays back recordings.
Object Storage Service	OSS	Manages storage of face snapshots and intelligent alarm pictures.
Object Storage Service	SubOSS	Mainly manages storage evidence recordings and pictures.
Picture Transfer Service	PTS	Manages picture transmission.
Device Search Service	SOSO	Searches for device information.
Device Management Service	DMS	Registers encoders, receives alarms, transfers alarms, and sends out the sync time command.
Auto Register Service	ARS	Listens, logs in, or gets bit streams to send to MTS.
ProxyList control Proxy Service	PCPS	Logs in to ONVIF device, and then gets the stream and transfers the data to MTS.
Access Control Service	ACDG	Manages access control and other related operations.

Service Name		Function Description
Access Controller Access Service	MCDDOOR	Manages access controller access and related operations.
External LED Device Access Service	MCDLED	Manages LED access and other related operations.
External Alarm Controller Access Service	MCDALARM	Manages alarm controller access and other related operations.
Power Environment Server	PES	Manages access of dynamic environment monitoring devices.
Video Matrix Service	VMS	Logs in to the decoder and sends tasks to the decoder to output on the TV wall.
Video Intercom Switch Center	SC	Manages PC client and App client login as SIP client, and also forwards audio-talk streams.
Device Update Service	UPDATE	Updates devices.
Group Talk Service	DA_POC	Manages the group talk functions and related devices.
DA Management Service	DAMS	Manages DA_BSID and DA_POC.
Link Management Service	DA_BSID	<ol style="list-style-type: none"> 1. Accesses devices that uses the 4G network. 2. Downloads files from devices to the platform. 3. Redirects to the webpage of devices added through automatic registration.

Appendix 2 Cybersecurity Recommendations

Security Statement

- If you connect the product to the Internet, you need to bear the risks, including but not limited to the possibility of network attacks, hacker attacks, virus infections, etc., please strengthen the protection of the network, platform data and personal information, and take the necessary measures to ensure the cyber security of platform, including but not limited to use complex passwords, regularly change passwords, and timely update platform products to the latest version, etc. Dahua does not assume any responsibility for the product abnormality, information leakage and other problems caused by this, but will provide product-related security maintenance.
- Where applicable laws are not expressly prohibited, for any profit, income, sales loss, data loss caused by the use or inability to use this product or service, or the cost, property damage, personal injury, service interruption, business information loss of purchasing alternative goods or services, or any special, direct, indirect, incidental, economic, covering, punitive, special or ancillary damage, regardless of the theory of liability (contract, tort, negligence, or other), Dahua and its employees, licensors or affiliates are not liable for compensation, even if they have been notified of the possibility of such damage. Some jurisdictions do not allow limitation of liability for personal injury, incidental or consequential damages, etc., so this limitation may not apply to you.
- Dahua's total liability for all your damages (except for the case of personal injury or death due to the company's negligence, subject to applicable laws and regulations) shall not exceed the price you paid for the products.

Security Recommendations

The necessary measures to ensure the basic cyber security of the platform:

1. Use Strong Passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters.
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols.
- Do not contain the account name or the account name in reverse order.
- Do not use continuous characters, such as 123, abc, etc.
- Do not use overlapped characters, such as 111, aaa, etc.

2. Customize the Answer to the Security Question

The security question setting should ensure the difference of answers, choose different questions and customize different answers (all questions are prohibited from being set to the same answer) to reduce the risk of security question being guessed or cracked.

Recommendation measures to enhance platform cyber security:

1. Enable Account Binding IP/MAC

It is recommended to enable the account binding IP/MAC mechanism, and configure the IP/MAC of the terminal where the commonly used client is located as an allowlist to further improve access security.

2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

3. Turn On Account Lock Mechanism

The account lock function is enabled by default at the factory, and it is recommended to keep it on to protect the security of your account. After the attacker has failed multiple password attempts, the corresponding account and source IP will be locked.

4. Reasonable Allocation of Accounts and Permissions

According to business and management needs, reasonably add new users, and reasonably allocate a minimum set of permissions for them.

5. Close Non-essential Services and Restrict the Open Form of Essential Services

If not needed, it is recommended to turn off NetBIOS (port 137, 138, 139), SMB (port 445), remote desktop (port 3389) and other services under Windows, and Telnet (port 23) and SSH (port 22) under Linux. At the same time, close the database port to the outside or only open to a specific IP address, such as MySQL (port 3306), to reduce the risks faced by the platform.

6. Patch the Operating System/Third Party Components

It is recommended to regularly detect security vulnerabilities in the operating system and third-party components, and apply official patches in time.

7. Security Audit

- Check online users: It is recommended to check online users irregularly to identify whether there are illegal users logging in.
- View the platform log: By viewing the log, you can get the IP information of the attempt to log in to the platform and the key operation information of the logged-in user.

8. The Establishment of a secure Network Environment

In order to better protect the security of the platform and reduce cyber security risks, it is recommended that:

- Follow the principle of minimization, restrict the ports that the platform maps externally by firewalls or routers, and only map ports that are necessary for services.
- Based on actual network requirements, separate networks: if there is no communication requirement between the two subnets, it is recommended to use VLAN, gatekeeper, etc. to divide the network to achieve the effect of network isolation.

More information

Please visit Dahua official website security emergency response center for security announcements and the latest security recommendations.

ENABLING A SAFER SOCIETY AND SMARTER LIVING

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.

Address: No.1199 Bin'an Road, Binjiang District, Hangzhou, P. R. China | Website: www.dahuasecurity.com | Postcode: 310053

Email: overseas@dahuatech.com | Fax: +86-571-87688815 | Tel: +86-571-87688883